



LTE Band 2 - Ant 0, Channel Bandwidth: 20 MHz




7.5.2 LTE Band 4

LTE Band 4 - Ant 0, Channel Bandwidth: 1.4 MHz




Note: The signal at 9 kHz is IF signal from spectrum analyzer.

LTE Band 4 - Ant 0, Channel Bandwidth: 1.4 MHz




LTE Band 4 - Ant 0, Channel Bandwidth: 3 MHz




Note: The signal at 9 kHz is IF signal from spectrum analyzer.

LTE Band 4 - Ant 0, Channel Bandwidth: 3 MHz




LTE Band 4 - Ant 0, Channel Bandwidth: 5 MHz




Note: The signal at 9 kHz is IF signal from spectrum analyzer.

LTE Band 4 - Ant 0, Channel Bandwidth: 5 MHz




LTE Band 4 - Ant 0, Channel Bandwidth: 10 MHz



Note: The signal at 9 kHz is IF signal from spectrum analyzer.

LTE Band 4 - Ant 0, Channel Bandwidth: 10 MHz




LTE Band 4 - Ant 0, Channel Bandwidth: 15 MHz




Note: The signal at 9 kHz is IF signal from spectrum analyzer.

LTE Band 4 - Ant 0, Channel Bandwidth: 15 MHz




LTE Band 4 - Ant 0, Channel Bandwidth: 20 MHz




Note: The signal at 9 kHz is IF signal from spectrum analyzer.

LTE Band 4 - Ant 0, Channel Bandwidth: 20 MHz




7.5.3 LTE Band 5

LTE Band 5 - Ant 0, Channel Bandwidth: 1.4 MHz



Note: The signal at 9 kHz is IF signal from spectrum analyzer.

LTE Band 5 - Ant 0, Channel Bandwidth: 1.4 MHz



LTE Band 5 - Ant 0, Channel Bandwidth: 3 MHz




CH 20415 (825.5 MHz)



CH 20525 (836.5 MHz)



CH 20635 (847.5 MHz)



Note: The signal at 9 kHz is IF signal from spectrum analyzer.

LTE Band 5 - Ant 0, Channel Bandwidth: 3 MHz

