



LTE Band 12 - Ant 0, Channel Bandwidth: 3 MHz



LTE Band 12 - Ant 0, Channel Bandwidth: 5 MHz



CH 23035 (701.5 MHz)




CH 23095 (707.5 MHz)




CH 23155 (713.5 MHz)

Note: The signal at 9 kHz is IF signal from spectrum analyzer.

LTE Band 12 - Ant 0, Channel Bandwidth: 5 MHz




LTE Band 12 - Ant 0, Channel Bandwidth: 10 MHz




Note: The signal at 9 kHz is IF signal from spectrum analyzer.

LTE Band 12 - Ant 0, Channel Bandwidth: 10 MHz




7.5.6 LTE Band 13


LTE Band 13 - Ant 0, Channel Bandwidth: 5 MHz



CH 23205 (779.5 MHz)




CH 23230 (782 MHz)




CH 23255 (784.5 MHz)

Note: The signal at 9 kHz is IF signal from spectrum analyzer.

LTE Band 13 - Ant 0, Channel Bandwidth: 5 MHz




LTE Band 13 - Ant 0, Channel Bandwidth: 10 MHz




Note: The signal at 9 kHz is IF signal from spectrum analyzer.

LTE Band 13 - Ant 0, Channel Bandwidth: 10 MHz




FULL CH 23230 (782 MHz)




1RB CH 23230 (782 MHz)


7.5.7 LTE Band 14

LTE Band 14 - Ant 0, Channel Bandwidth: 5 MHz






CH 23330 (793 MHz)




Note: The signal at 9 kHz is IF signal from spectrum analyzer.

LTE Band 14 - Ant 0, Channel Bandwidth: 5 MHz




LTE Band 14 - Ant 0, Channel Bandwidth: 10 MHz




Note: The signal at 9 kHz is IF signal from spectrum analyzer.

LTE Band 14 - Ant 0, Channel Bandwidth: 10 MHz



7.5.8 LTE Band 17

LTE Band 17 - Ant 0, Channel Bandwidth: 5 MHz



Note: The signal at 9 kHz is IF signal from spectrum analyzer.