

PAGE SIZE: 140mm x 200mm

7

7

A line drawing of a remote control and a radio-controlled car. The remote control is a handheld device with a long antenna on top and a face with several buttons. The radio-controlled car is a four-wheeled vehicle with a steering wheel, a roll-over protection structure, and a rear spoiler.

✶ After playing, remove all the batteries from the transmitter and explorer. Drain out all the water form the explorer and dry completely before storing away.

- Do not immerse battery operated toys. Wipe clean only.

1

 If you press these button(s), the undersea explorer will:

↑

dive forward

↻

dive to the right

↻

dive to the left

↓

Surface in the rear direction

↻

Surface in the rear right

↻

Surface in the rear left

⬇

stop the explorer's buoyancy (will make it surface gradually)

↻

Spin turn to the right

↻

Spin turn to the left

280mm

NOTE:

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV
INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS
EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER AUTHORITY
TO OPERATE THE EQUIPMENT.