


Appendix 5. Block Diagram

Total



NOW-WL is the external HDD that can be connected to Desktop or Notebook PC via 100BaseT Ethernet or IEEE 802.11g/b Wireless LAN. It is working as an another Local HDD. (It doesn't need IP Address.)

RF Board

