

PHOTOGRAPHS OF THE TEST CONFIGURATION

CONDUCTED EMISSION TEST
(For Adapter: DSA-5P-05 FUS 050100)




CONDUCTED EMISSION TEST
(For Adapter: For Adapter: DSC-51F-52P US)



CONDUCTED EMISSION TEST
(For Adapter: For Adapter: DSA-10P-05 050050)



RADIATED EMISSION TEST
(For Adapter: DSA-5P-05 FUS 050100)



RADIATED EMISSION TEST
(For Adapter: DSC-51F-52P US)



RADIATED EMISSION TEST
(For Adapter: DSA-10P-05 050050)

