

尺寸: 70X100MM, 材质 : 100g书纸 , 1C+1C , 风琴折页

<div data-bbox="476 420 615 763"></div> <div data-bbox="431 814 673 849">Bluetooth Speaker</div> <div data-bbox="431 864 673 915">USER MANUAL</div> <div data-bbox="463 925 615 953">BT223DS-N</div>	<div data-bbox="873 272 1052 291">Package Includes</div> <div data-bbox="873 300 1089 382"><ul style="list-style-type: none">• 1 x Speaker• 1 x Micro-USB Cable• 1 x AUX Cable (Φ3.5mm)• 1 x User Manual</div> <div data-bbox="884 405 1092 424">Overview of the Speaker</div> <div data-bbox="844 483 1316 725"><div data-bbox="844 586 968 668"><p>Screw hole for mounting bike</p><p>Aux-In</p><p>Micro SD port</p><p>USB Charging Port</p></div><div data-bbox="1134 548 1316 668"><p>Power-on/off LED</p><p>Volume Down</p><p>Play/Pause/Mute (Aux-in mode)</p><p>Volume UP</p></div></div>	<div data-bbox="1389 272 1481 291">Charging</div> <div data-bbox="1389 300 1826 382"><ol style="list-style-type: none">1. Before first time use, fully charge the built-in battery.2. Connect the Micro-USB Cable (included) between<ul style="list-style-type: none">• the DC IN port on the speaker, and• a USB port on a computer or USB AC Adapter.</div> <div data-bbox="1381 396 1808 515"><table><tr><th>LED Indicator</th><th>Battery Status</th></tr><tr><td>Flash Blue & Green</td><td>Low battery (<10%)</td></tr><tr><td>Solid Red</td><td>Under Charging</td></tr><tr><td>Solid Green</td><td>Full charged</td></tr></table></div> <div data-bbox="1389 525 1826 567"><p>Note: When the battery charge <3%, the speaker will power off automatically.</p></div> <div data-bbox="1389 586 1492 605">Power On</div> <div data-bbox="1389 614 1781 656"><p>Press ⏻ button until hear a rising tone and LED indicator light on.</p></div> <div data-bbox="1389 662 1492 681">Power Off</div> <div data-bbox="1389 691 1792 733"><p>Press ⏻ button until hear a descending tone and LED indicator light off.</p></div> <div data-bbox="1389 738 1600 757">Bluetooth connection</div> <div data-bbox="1389 767 1808 809"><p>Make sure that the speaker is within 10 meters from your mobile device.</p></div> <div data-bbox="1389 814 1818 915"><ol style="list-style-type: none">1. Press ⏻ button until hear a rising tone and LED indicator fast blinking blue.2. Go to the Bluetooth settings on your mobile device, search and select " BT223 " from the list.3. Once paired, the LED indicator turns solid blue.</div>	LED Indicator	Battery Status	Flash Blue & Green	Low battery (<10%)	Solid Red	Under Charging	Solid Green	Full charged	<div data-bbox="1908 272 1958 291">Note:</div> <div data-bbox="1908 300 2363 430"><ul style="list-style-type: none">• When power on, the speaker automatically reconnects to the last mobile device it was connected to. (The speaker can memorize maximum of 8 paired devices).• The speaker will automatically shut down after 10 minutes in pairing mode if no devices are paired for power saving.</div> <div data-bbox="1908 468 2045 487">Music Control</div> <div data-bbox="1908 496 2321 616"><p>Play / Pause..... Click ⏻</p><p>Volume Down..... Click +</p><p>Volume Down..... Click -</p><p>Next track..... Press and Hold +</p><p>Previous track..... Press and Hold -</p><p>Switch Bluetooth mode/ Aux-in mode.....Click ⏻</p></div> <div data-bbox="1908 649 2303 668">Speakerphone (in Bluetooth Connection)</div> <div data-bbox="1908 677 2295 757"><p>Answer an incoming call.....Click ⏻</p><p>Reject an incoming call..... Press and Hold ⏻</p><p>End the current call..... Click ⏻</p><p>Redial last-called number.....Press and Hold ⏻</p></div> <div data-bbox="1908 790 2150 809">Bluetooth Disconnection</div> <div data-bbox="1908 818 2358 915"><p>Press + , - buttons simultaneously until hear a tone and LED Indicator fast blinking blue to disconnect the into connected device,current and go new Bluetooth-paring mode.</p></div>
LED Indicator	Battery Status										
Flash Blue & Green	Low battery (<10%)										
Solid Red	Under Charging										
Solid Green	Full charged										

<div data-bbox="321 1087 465 1106">TWS Function</div> <div data-bbox="321 1115 802 1340"><p>It supports True Wireless Stereo for connecting two speakers via Bluetooth.</p><p>Turn ON two speakers, double press the ⏻ on one of the speakers for 2 seconds until the LED flashes blue & green. The speaker now is in a stereo pairing mode. After 3-5 seconds, the speakers will be successfully paired to True Wireless Stereo mode. The main speaker LED flashes blue while the sub-speaker LED is ON blue.</p><p>Note: In TWS mode, the calls can be answered only through the main speaker.</p></div> <div data-bbox="321 1353 381 1372">Reset</div> <div data-bbox="321 1382 742 1467"><p>long press the power button for 15 seconds if the speaker malfunctions. The speaker must be semi-charged in order to reset, so make sure it has battery left.</p></div> <div data-bbox="321 1481 742 1500">Listening music from external audio source</div> <div data-bbox="321 1509 779 1610"><ol style="list-style-type: none">1.Power on the speaker.2.Using the AUX Cable(Φ3.5mm), connect your external device to AUX-in port on speaker.3.It will automatically turn to AUX-in mode, the LED Indicator turns solid green.</div> <div data-bbox="321 1616 810 1658"><p>Note: Under AUX-IN mode, skip songs and speakerphone function are not workable.</p></div>	<div data-bbox="847 1087 989 1106">Specifications</div> <div data-bbox="847 1125 1326 1416"><ul style="list-style-type: none">• Bluetooth Version: 4.2• Suport:A2DPV1.2,AVRCPV1.4,HPV1.6,HSPV1.2• Wireless work distance:10meters• Rated Power: 2 x 5W• Driver Unit: 2 xΦ40mm (4Q,6W)• Frequency response: 180Hz-18kHz• Signal-to-noise ratio: >80dB• Battery type: Lithium-ion (3.7V/2000mAh)• DC input voltage/current: 5V/1A• Playtime: 6-8 hours (varies by volume level and content)• Battery charge time: 3-4 hours• Dimensions: 158.5 x 65 x62.5 mm• Weight: 355g</div> <div data-bbox="847 1435 923 1454">Caution</div> <div data-bbox="847 1464 1334 1705"><ul style="list-style-type: none">• Keep the speaker and its accessories away from the reach of kids as they might cause a choking hazard.• Keep the speaker away from fire, water, liquids, extreme heat, and strong magnetic fields.• Do NOT use this speaker at high volume for extended periods, as this may cause permanent hearing damage or loss.• Do NOT drop or knock the speaker on hard surfaces.• Do NOT use chemicals or detergents to clean the speaker.• Do NOT scrape the surface with sharp objects.• Do NOT make unauthorized alterations to this product.</div>	<div data-bbox="1376 1087 1539 1106">Troubleshooting</div> <div data-bbox="1376 1115 1529 1134">Cannot power on</div> <div data-bbox="1376 1144 1847 1163"><p>Charge the speaker and make sure it has enough battery.</p></div> <div data-bbox="1376 1172 1652 1191">Cannot connect with the device</div> <div data-bbox="1376 1201 1850 1302"><ul style="list-style-type: none">• Please check the follows:• The Bluetooth device supports A2DP profile• The speaker is within 10m from the device.• The speaker is in pairing mode, the LED indicator blinking blue.</div> <div data-bbox="1376 1315 1466 1334">No Sound</div> <div data-bbox="1376 1344 1826 1424"><ul style="list-style-type: none">• Make sure the music volume is at audible level on both your device and speaker• Make sure your device is successfully paired with the speaker, the LED indicator turn solid blue.</div> <div data-bbox="1376 1448 1544 1467">Poor sound quality</div> <div data-bbox="1376 1477 1816 1519"><p>Move the device closer to this speaker or remove any obstacle between them.</p></div> <div data-bbox="1376 1544 1826 1744"><p>NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in</p></div>	<p>accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none">- Reorient or relocate the receiving antenna.- Increase the separation between the equipment and receiver.-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.-Consult the dealer or an experienced radio/TV technician for help <p>Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:</p> <ol style="list-style-type: none">(1) this device may not cause harmful interference, and(2) this device must accept any interference received, including interference that may cause undesired operation.
---	---	--	--