Outdoor Wifi Smart Outlets
--App User Manual

This product includes 3 outlets, which control lights and animated holiday decorations. Compatible with CFL, LED & Incandescent lighting.

Input Voltage:120V~/50/60Hz
Working Voltage: 125V~/60Hz
Max.: 15A/1875W(Resistive);
10A/1250W(Tungsten); TV-5 1/2HP
Wireless Type: Wi-Fi 2.4GHz

Works with amazon alexa

IFTTT

Works with the Google Assistant

Only supports 2.4GHz Wi-Fi network



Simplified steps to install app on your smart device and pair with Amazon Alexa, Google Assistant and IFTTT using Smart Life App on Apple Store/Google Play Store.
Compatible with any smart phone or tablet including both Android and iOS systems.

Wi-Fi Controlled Appliances **Set Time**

Scheduling Program **Share with family members**

- Instead of reaching for outlets and plugs every time, you can easily switch your electronics, set timer and countdown, create scenes, share the device with your families at your fingertip. Perfect for hard-to-reach appliances & devices without ON/OFF switches.
- Manage Your Home Remotely: Instantly control devices connected to the Smart Plug wherever you have Internet using the free app on your smart phone, Enjoy peace of mind by checking on your devices remotely and always coming home to a well-lit house.Works with Alexa and google assistant for voice control.
- Set Timer: Schedule the Smart Plug to automatically power electronics on and off as needed, like setting lights to come on at time you back home.
- Create Unique Scenes: Schedule the smart switch to automatically power electronics on and off as needed, like setting lights to come on at dusk or turn off at sunrise.

For Optimal Use:

1. If the indictor on wifi plug doesn't flashing when you plug into the power socket for first connection, please hold and press the switch button which on the side of the smart plug for about 5-10seconds to see if it's start flashing;
2. If the smart device can't be connected to WiFi, please long press ON/OFF button for 5~10 seconds to reset the smart plug;
3.The smart device only work with 2.4 GHz network. If your router broadcasts both 2.4 and 5GHz, please selected the 2.4GHz network with the app. If connection still failed, we recommend you call your ISP and had them completely shut off the 5 GHz network on the router; You are free to change the network to 5 GHz again after connecting;
4. Please try to make the smart plug and router as close as possible when first connection, you can change the place after connecting successfully.

What's the meaning of each status of LED indicator on socket?

LED Status	Function
RED LED is on	Power is on
RED LED is off	Power is off
Blue LED blinks rapidly	Resetting / Enter into network configuration
Blue LED blinks slowly until off	Configuration is successful

- Short press the power button, the RED power led indicator will be ON or OFF correspondingly.
- Long press the power button for about 5 seconds until the blue indicator flashes rapidly, means the socket begins to enter into the network configuration mode.
- Blue indicator flashes slowly means the network connection is abnormal, please check the router or network configuration.

NO.1 Download App

To download the app, search for "Smart Life" in any app store , or scan the QR code below

NO.2 Registration/Login/Password Retrieval



Fig. 1

Fig. 2

Registration

If you do not have an app account, you may choose to register or log in by text message authentication. The registration process is described on this page and the next.
1. Click 'Create account'to go to the Smart Living privacy policy page. Click Agree to proceed to the mobile phone number registration page
2. The system will identify automatically the country/region you are in, or you may choose to select manually a country/region. Enter your mobile phone number or email and click 'Next', as shown in Fig. 2

NO.2 Registration/Login/Password Retrieval



Fig. 1



Fig. 2



Fig. 3

2. The system will identify automatically the country/ region you are in, or you may choose to select manually a country/region.Enter your mobile phone number or email and click "Get code", as shown in Fig. 1
3. Enter the authentication code you received. Then enter the password and click "OK" to complete registration.



Account ID + Password Login

If you already have an app account, click 'Log in with existing account' to proceed to the login page
1. The system will identify automatically the country/region you are in, or you may also choose to select manually a country/region
2. Enter the mobile phone number or email you have registered and enter the password in to log in

Third-Party Social Login (China only)

If you have already installed WeChat on your mobile phone, click the WeChat icon in Social Login and proceed through the authorization page to log in.

NO.2 Registration/Login/Password Retrieval



Fig. 1



Fig. 2



Fig. 3

Mobile Phone Number + Authentication Code Login

1. Click 'Authentication Code Login'in Fig. 1 to go to the next page.
2. The system will identify automatically the country/ region you are in, or you may also choose to select manually a country/region
3. Enter your mobile phone number or email and click 'Get code', as shown in Fig. 2
4. Enter the authentication code in the text message or email to log in, as shown in Fig. 3

Forgot Password

If you forgot your app password, you can reset your password by following the Password Retrieval procedure
1. Click 'Forgot Password', as shown in Fig. 1
2. The system will identify automatically the country/ region you are in, or you may choose to select manually a country/region. Enter the mobile phone number or email you used to register and click 'Get code', as shown in Fig.

NO.2 Registration/Login/Password Retrieval



Fig. 1



Fig. 2

3. Enter the authentication code sent to your mobile phone number or email, as shown in Fig. 3
4. Enter the new password and click 'OK' to log in, as shown in Fig. 4



Fig. 3



Fig. 4

NO.3.1 Household/Member Management

1. When logged in, click 'Activate Smart Living' to go to the "Add Household" page, as shown in Fig. 1
2. "Household Name" can be entered manually, as necessary. Click "Household Location" to go to the map. Move the household icon manually to change the address. Click "OK" to confirm the address, as shown in Fig.2
3. Click "Add Room" to add a room, as shown in Fig.3 Click "OK" at the top right corner to complete room settings. Room settings can be changed anytime by clicking on "My Household", as shown in Fig.4



Fig. 1



Fig. 2



Fig. 3



Fig. 4

NO.3.1 Household/Member Management

Click the pull-down arrow at the top left corner of 'My Household'to add a household and manage households. One account can manage multiple households at the same time. The user can operate a device in a household by selecting it in the household menu.



Click Chen's Household to go to the household settings, as shown in the figure



Combine and classify administrative access of different individuals to devices. All devices and smart scenarios in a household can be shared among household members without having to complete the sharing settings each time

Other household members can enjoy control of smart devices in the household, but will not be able to modify, add, or delete a device

Add/Delete rooms in a household and manage all room settings in a household in one place

Administrators have the highest level of access, which allows them to manage access to devices or access granted to other household members

NO.3.2 Adding Devices - All Devices

Click "Add Device" on the app home page or the "+" sign at the top right corner to go to the "All Devices" page, where devices can be selected and added as necessary



There are two network configuration modes: Default Mode(Quick mode) and AP Mode(Compatibility mode) are available for you to choose before adding the device to app. Default Mode (Quick mode) is recommended.

Default Mode (Quick mode):

1. If you configure the network in Default Mode(Quick mode),please confirm that the device blue indicator is blinking rapidly (2 times/second), then click the confirm button to go to the next step.
2. If the blue indicator is not blinking rapidly (once every 3 seconds),then click'How to make indicator rapidly blink' to see the procedure or press and hold the power button on the smart plug for about 5 seconds until the indicator blinks rapidly.
3. Follow the in-app instructions to connect the Smart device to your WI-FI network.

5.Select the Wi-Fi in the work area of a device that can enable successful Internet connection, enter the Wi-Fi password, and click "OK" to proceed to configuration


Back
Add Device
AP Mode
Power on the device and confirm that indicator light rapidly blinks
How to make indicator rapidly blink
Confirm indicator rapidly blink
Cancel
Enter Wi-Fi Password
Change Network
Confirm
The App is supported only 2.4GHz Wi-Fi Channels

6. If Default mode(Quick mode) is selected, app configuration will be completed as shown in Fig. 1. Successful configuration will appear as shown in Fig. 2. Names of devices that have been configured successfully can be changed, and the locations of the rooms where the corresponding devices are can be selected.



Fig. 1



Fig. 2

5.Select the Wi-Fi in the work area of a device that can enable successful Internet connection, enter the Wi-Fi password, and click "OK" to proceed to configuration



6. If Default mode(Quick mode) is selected, app configuration will be completed as shown in Fig. 1. Successful configuration will appear as shown in Fig. 2. Names of devices that have been configured successfully can be changed, and the locations of the rooms where the corresponding devices are can be selected.



Fig. 1



Fig. 2

5.Select the Wi-Fi in the work area of a device that can enable successful Internet connection, enter the Wi-Fi password, and click "OK" to proceed to configuration



6. If Default mode(Quick mode) is selected, app configuration will be completed as shown in Fig. 1. Successful configuration will appear as shown in Fig. 2. Names of devices that have been configured successfully can be changed, and the locations of the rooms where the corresponding devices are can be selected.



Fig. 1



Fig. 2

7. Click'Done',now you can control the smart device through 'Smart Life' App.
8. Once the configuration is completed successfully, the indicator light will turn to solid red and the device will be added to the ' Device List'.

AP Mode (Compatibility mode):

1.To select "Compatibility mode",please make sure the indicator light on the smart device is flashing slowly (blinking once every three seconds) and then click the button to proceed to the next step.
2. If it blinks blue rapidly (twice per second),press and hold the power button on the smart device for 6 seconds until the indicator light blinks slowly, or click "How to set indicator light to slow flashing" to view the instructions.
3. Click 'AP Mode' at the top right corner will be in AP mode,


Add Device
Power on the device and confirm that indicator light slowly blinks
How to make indicator slowly blink
Confirm indicator slowly blink
Cancel
Connect phone to device's wifi hotspot
1. Open WLAN Settings
Smart Life_XXXX
2.Back to the App and continue to add device
Connect Now

4. When in Compatibility (slow flashing) mode, you can select hotspot configuration, but connection must be made with the Wi-Fi hotspot whose name begins with 'SmartLife', as shown in the figure
Note: Some hotspot names may be user-defined

NO.6 My Household


For users with multiple households
Able to switch between/add households
One-key activation for smart scenarios
Easy switch between everyday scenarios
Add various types of devices
Supports voice command
Switch between rooms in a household
View status of smart devices in each room
Leo
31.0 °C
Middle
Leave home
Low temperature
All Devices
Living Room
Master Room
light2
light1
socket
Common Functions
My Home
Smart Scenes
Profile

NO.7 Profile(Me) page

Personal settings is the user's portal to managing personal information and shows the following information:
1. Household Management
2. Message Center: feedback results, shared news,and devices supporting notification
3. ScanQR Code: Some devices support QR code scanning.
4. FAQ: Frequently Asked Questions
5. Feedback: Report problems encountered during usage here.
6. Settings



NO.7 Settings-About



The About page displays app information as follows:
1. Click "Rate us" to go to the app store and rate the app.
2. Privacy Policy
3. Open Source License
4. Current Version

The Integration page displays " Amazon alexa", "Google Assistant", "IFTTT", and so on operation instructions. You only need to click " Find More" will be the operation details reference.

NO.7 Personal -Settings

The Personal Settings page shows your account information. Here you can change your password, link your mobile number to your account, configure your gesture password, and terminate your account



NO.7 Personal Settings-Gesture Password

Click "Gesture Unlock" to set up a gesture password. Once a gesture password is activated, you will have to use the gesture to access the app. If you forgot your gesture password, click "Forgot Gesture Password" to have an authentication code sent to your registered mobile phone number. Enter the code and set up a new gesture password to continue.



Troubleshooting and FAQ

1. What devices can I control with the Mini Smart Plug?

You can control lights,animated holiday decorations and any small devices in accordance with the Smart Outlet specifications.

2. What should I do when I cannot turn Mini Smart Plug on or off?

- Make sure your mobile devices and the Mini Smart Plug are connected to the same Wi-Fi network.
- Make sure the devices connected to the Mini Smart Plug are turned on.

3. What should I do when device configuration process has failed?

You could:

- Check whether the Mini Smart Plug is powered on or not.
- Check whether your mobile device is connected to 2.4GHz Wi-Fi network.
- Check your network connectivity. Make sure the router is working properly:
  - If the router is dual-band router, select 2.4G network and then add Mini Smart Plug.
  - Enable the router's broadcasting function.
  - Configure the encryption method as WPA2-PSK and authorization type as AES, or set both as auto.
  - Wireless mode cannot be 11n only.

- Check for Wi-Fi interference or relocate the Mini Smart Plug to another location within the signal range.
- Check whether the router's connected devices reach the amount limit. Please try to turn off some devices' Wi-Fi function and configure Mini Smart Plug again.
- Check if router's wireless MAC filtering function is enabled. Remove the device from filter list and make sure the router is not prohibiting Mini Smart Plug from connection.
- Make sure the password of your Wi-Fi network entered in App is correct when adding Mini Smart Plug.
- Make sure the Mini Smart Plug is in ready for App-Config: the indicator light is quick blinking blue (twice per second) for quick mode configuration, slow blinking blue (once every 3 seconds) for AP mode configuration.
- Repeat the App-Config process.
- Factory reset the Mini Smart Plug and try to add it again.

4. Can I control device through 2G/3G/4G cellular network?

The Mini Smart Plug and the mobile device are required to be under same Wi-Fi network when adding the Mini Smart Plug for the first time. After successful device configuration, you can remotely control the device through 2G/3G/4G cellular network.

5. How to reset this device?

Factory reset: After Mini Smart Plug is plugged into a power socket, press and hold(for 6 seconds) the power button for factory reset until the indicator light blinks blue rapidly.Indicator Lighting pattern:

- Quick blinking blue (twice per second): Quick mode configuration is initiated.
- Slow blinking blue (once every 3 seconds): AP mode configuration is initiated.
- Solid blue: The Mini Smart Plug is connected to the Wi-Fi network.
- Solid red: Power socket of the Mini Smart Plug is switched on. The indicator light could turn to solid red from any other status (quick/slow blinking blue, solid blue or off) by pressing the power button once and return to the previous status from solid red status (power socket is switched off) by pressing power button once again.
- Off: The Mini Smart Plug is switched off and no Wi-Fi network

Attention:

Waterproof for outdoor use: Watertight construction provides protecting outlets timer form weather conditions. Heavy duty material and three grounded outlet makes it safe and durable.

Should you have any issues or questions regarding your New product, feel free to contact our Customer Support Team. Your satisfaction is ours.

FCC Waring:
Any Changes or modifications not expressly approved by the party responsible for compliance could avoid the user's authority to operate the equipment.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
FCC Radiation Exposure Statement:
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment .This equipment should be installed and operated with minimum distance 20cm between the radiator& your body.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

Model No.: BHC1804-WiFi
CONFORMS TO UL STD 60730-1
CERTIFIED TO CSA STD E60730-1
Made in China