



OUTDOOR
CONSUMER

OUTDOOR
INSTRUCTOR

POCKET GUIDE
EN/FR/SP

SOUND BY




DYNAMIC
MESH
COMMUNICATION



OPERATED BY
NATURAL VOICE

cardo[®] CONNECT APP



Cardo Connect
App



Download on the
App Store



GET IT ON
Google Play

1-2

Getting Started | Démarrage | Guía de Inicio

3

Cardo Connect App

4

General | Fonctions Générales | General

5

Music | Musique | Música

6

Phone Call | Appel Téléphonique | Llamada Telefónica

7


DMC Intercom | Intercom DMC | Intercomunicador DMC

8

Reset | Réinitialiser | Reiniciar

9-11

Voice Commands - Always On! | Commandes vocales - Toujours Activé ! |
Comandos de Voz: ¡Siempre Activos!




Press & Hold |
Appuyez & Maintenez |
Mantener Pulsado el Botón




Number of Taps |
Nombre de Clics |
Número de Pulsaciones




On | On | Encender



Off | Off | Apagar




Phone Pairing | Appairage au Téléphone | Vincular Teléfono



LED Red & Blue | LED Rouge & Bleu | Ledes en Rojo y Azul



Stop Phone Pairing | Arrêter L'appairage du Téléphone |
Detener el Emparejamiento del Teléfono





Cardo Connect App



Download | Télécharger | Descargar




Register | S'enregistrer | Registrar



Choose Language | Choisir Langue | Seleccionar Idioma




Update Software | Actualisation du Logiciel | Actualizar Software







Volume Up | Augmenter le Volume | Subir Volumen



Volume Down | Baisser le Volume | Bajar Volumen




Mute Audio | Couper L'audio | Silenciar Audio




Fast Roll
Roulement rapide
Rollo rápido




Unmute Audio | Réactiver L'audio | Activar Micrófono



Voice Assistant | Assistant Vocal | Asistente de Voz




▶ On | On | Encender




x1
Tap

|| Off | Off | Apagar




▶ Next | Suivant | Siguiente



x1
Tap

◀ Previous | Précédent | Anterior




x2
Tap


Phone Call | Appel Téléphonique | Llamada Telefónica




Answer | Répondre | Contestar




Ignore | Ignorer | Ignorar




End Call | Raccrocher | Finalizar Llamada



Speed Dial | Numérotation Rapide | Marcación Rápida



 Grouping | Regroupement | Agrupar



LED Red & Green | LED Rouge & Vert | LED Rojo y Verde




Grouping Success | Regroupement Réussi |
Agrupado Correctamente


LED Purple | LED Violet | LED Púrpura



 Mute / Unmute Microphone | Activer / Désactiver Le Micro | Silenciar /
Activar Micrófono



 DMC Intercom OFF/ON | Interphone DMC OFF/ON |
Intercom DMC OFF/ON




Automatically ON together with the unit |
Activé automatiquement avec l'unité |
Encendido automático con la unidad |


Reset | Réinitialiser | Reiniciar



Reboot | Redémarrer | Reiniciar



Factory Reset | Réinitialisation des Paramètres D'usine |
Restablecer Valores de Fábrica



E English



- **Answer**
- **Ignore**
- "Hey Cardo, **speed dial**"
- "Hey Cardo, **redial number**"



- "Hey Cardo, **music on**"
- "Hey Cardo, **music off**"
- "Hey Cardo, **next track**"
- "Hey Cardo, **previous track**"



- **"Hey Siri"**
- **"OK Google"**
- **"Hey Google"**



- "Hey Cardo, **volume up**"
- "Hey Cardo, **volume down**"
- "Hey Cardo, **mute audio**"
- "Hey Cardo, **unmute audio**"
- "Hey Cardo, **mute microphone**"
- "Hey Cardo, **unmute microphone**"



- "Hey Cardo, **battery status**"

F Français



- Réponds
- Ignore
- "Hey Cardo, **numéro favori**"
- "Hey Cardo, **rappelle le numéro**"



- "Hey Cardo, **allume la musique**"
- "Hey Cardo, **éteins la musique**"
- "Hey Cardo, **morceau suivant**"
- "Hey Cardo, **morceau précédent**"



- "Hey Siri"
- "OK Google"
- "Hey Google"



- "Hey Cardo, **augmente le volume**"
- "Hey Cardo, **baisse le volume**"
- "Hey Cardo, **coupe le son**"
- "Hey Cardo, **active le son**"
- "Hey Cardo, **coupe le micro**"
- "Hey Cardo, **active le micro**"



- "Hey Cardo, **niveau de batterie**"

S Español



- **Contestar**
- **Ignorar**
- "Hey Cardo, **marcación rápida**"
- "Hey Cardo, **remarcar número**"



- "Hey Cardo, **enciende la música**"
- "Hey Cardo, **apaga la música**"
- "Hey Cardo, **pista siguiente**"
- "Hey Cardo, **pista anterior**"



- **"Hey Siri"**
- **"OK Google"**
- **"Hey Google"**



- "Hey Cardo, **sube el volumen**"
- "Hey Cardo, **baja el volumen**"
- "Hey Cardo, **silenciar el audio**"
- "Hey Cardo, **reactivar el audio**"
- "Hey Cardo, **silenciar el micrófono**"
- "Hey Cardo, **reactivar el micrófono**"



- "Hey Cardo, **nivel de la batería**"

PACKTALK OUTDOOR

All Year Round





cardosystems.com/outdoor



Follow Cardo Outdoor

.....



Cardo Connect
App

cardosystems.com/update
cardosystems.com/support



Measurements


booklet close
90mm

180mm



180mm

booklet open
180mm





TYPE APPROVAL			
P/N	MAN00633		
DESCRIPTION	POCKET GUIDE		
FILE NAME	MAN00633 OUTDOOR CONSUMER STANDARD POCKET GUIDE IN EN/FR/SP_A03		
LANGUAGE	EN/FR/SP		
PRODUCT TYPE	MANUAL		
MATERIAL	P2 C4+4 105-115gr glossy art paper folded - Booklet with pins		
PRINTING PROCESS	COLOR: CMYK		
SECONDARY PROCESS			
ATTACHED FILES	1. GRAPHIC FILE - PDF		
MEASUREMENT	OPEN :180mm*180mm , CLOSE: 90mm -180mm		
CLIENTS/ DISTRIBUTOR			
SPECIAL REQUIREMENT			
REVISION	DESCRIPTION	DATE	NAME
A03	PVT	30.05.2022	Danna

Rev	Change Description	Date	Approved by
A01	DRAFT	09.01.2022	Guy
A02	DVT		DANNA
A03	PVT	30.05.2022	DANNA