



## 802.11be-EHT160 – Ant 0

## Channel 47 (6185MHz)

## The Reference Level




## The Mask Data




## Channel 79 (6345MHz)

## The Reference Level




## The Mask Data




## Channel 143 (6665MHz)

## The Reference Level




## The Mask Data



## 802.11be-EHT320 – Ant 0

## Channel 63 (6265MHz)

## The Reference Level




## The Mask Data




## 802.11ax-HE20 – Ant 1

## Channel 33 (6115MHz)

## The Reference Level




## The Mask Data




## Channel 61 (6255MHz)

## The Reference Level




## The Mask Data




## Channel 93 (6415MHz)

## The Reference Level




## The Mask Data




## 802.11ax-HE20 – Ant 1

## Channel 117 (6535MHz)

## The Reference Level




## The Mask Data




## Channel 149 (6695MHz)

## The Reference Level




## The Mask Data




## Channel 181 (6855MHz)

## The Reference Level




## The Mask Data




## 802.11ax-HE40 – Ant 1

## Channel 35 (6125MHz)

## The Reference Level




## The Mask Data




## Channel 59 (6245MHz)

## The Reference Level




## The Mask Data




## Channel 91 (6405MHz)

## The Reference Level




## The Mask Data




## 802.11ax-HE40 – Ant 1

## Channel 123 (6565MHz)

## The Reference Level




## The Mask Data




## Channel 147 (6685MHz)

## The Reference Level




## The Mask Data




## Channel 179 (6845MHz)

## The Reference Level




## The Mask Data




## 802.11ax-HE80 – Ant 1

## Channel 39 (6145MHz)

## The Reference Level




## The Mask Data




## Channel 55 (6225MHz)

## The Reference Level




## The Mask Data




## Channel 87 (6385MHz)

## The Reference Level




## The Mask Data




## 802.11ax-HE80 – Ant 1

## Channel 135 (6625MHz)

## The Reference Level




## The Mask Data




## Channel 151 (6705MHz)

## The Reference Level




## The Mask Data




## Channel 167 (6785MHz)

## The Reference Level




## The Mask Data




## 802.11ax-HE160 – Ant 1

## Channel 47 (6185MHz)

## The Reference Level




## The Mask Data




## Channel 79 (6345MHz)

## The Reference Level




## The Mask Data




## Channel 143 (6665MHz)

## The Reference Level




## The Mask Data




## 802.11be-EHT20 – Ant 1

## Channel 33 (6115MHz)

## The Reference Level




## The Mask Data




## Channel 61 (6255MHz)

## The Reference Level




## The Mask Data




## Channel 93 (6415MHz)

## The Reference Level




## The Mask Data




## 802.11be-EHT20 – Ant 1

## Channel 117 (6535MHz)

## The Reference Level




## The Mask Data




## Channel 149 (6695MHz)

## The Reference Level




## The Mask Data



## Channel 181 (6855MHz)

## The Reference Level



## The Mask Data

