

CM-BTBV01 Remote Controller User Manual

Thanks for purchasing CM-BTBV01 remote controller, may you will enjoy it.
Please read the “Safety Instructions” before using the product for your
safety and correct use

Caution

DO NOT drop or apply shock to the product. Such act may cause irreparable damage to the product.
--


DO NOT expose the product to open flame or under the direct sunlight for a prolonged period of the time. Such environment may cause malfunction or fire.
--

Conversation on the cell phone when driving is extremely dangerous. Please go out of the road for doing the telephone call.

If anything unusual such as smoke, heat or bad smell is detected, please disconnect immediately the power and stop the usage. Continuing the use may cause electric shock or fire.
--

DO NOT lick, bite or put the product into the mouth. Such act may result in serious injuries/accidents. Take utmost caution around children.
--

Please use only qualified accessories which have been authenticated by us, in order to guarantee the product correct functioning.



Function:

- 1) after pressing the PTT key for 5 seconds, the green light is on, and after releasing it, you enter the pairing. If you do not connect successfully within 50 seconds, you will flash the green light for 3 seconds and then shut down automatically.
- 2) after the successful connection, the flashing green light will go out, and if you press the PTT key to launch the walkie-talkie, the green light will flash; after loosening, the walkie-talkie will stop launching and the green light will go out.
- 3) after disconnecting, the Bluetooth PTT will enter the pairing mode (50 seconds), during which time press the PTT key for 3 seconds to shut down the phone.
- 4) in the case of connection, press the PTT key 5 times quickly to turn off the computer.
- 5) Bluetooth PTT is powered by a special battery and the voltage cannot be higher than 3.6V.
- 6) when the voltage is lower than 2.3V, there will be a low electric alarm (Isolated for 3 seconds, the red light is on twice.).

Technical Specification:

Bluetooth Remote Controller Specifications
Bluetooth Chip: Telink 825X
Bluetooth Version: Bluetooth 5.0
Supported Bluetooth Profiles: BLE
Bluetooth RF Spec: Class 2
RF Power: 3dB
RF Sensitivity: -96db
RF Frequency: 2.402GHZ-2.480GHZ
Battery Capacity:220mA
Working Time:50H
Stand by Time:210H
Appearance Colour: Black
Operating temperature: -15℃ ~50 ℃
Storage Temperature: -25℃ ~60℃

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.