






OPERATION INSTRUCTION

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the User's authority to operate the equipment.



Use 3 "G13" (LR 44) Size Batteries (Batteries Included)

