



4. Internal Photograph of the Host


Host: Notebook Computer (Acer / Q5LJ1 / Aspire M5-581T, Aspire M5-581TG)




Host: Notebook Computer (Acer / Q5LJ1 / Aspire M5-581T, Aspire M5-581TG)



Host: Notebook Computer (Acer / Q5LJ1 / Aspire M5-581T, Aspire M5-581TG)



Host: Notebook Computer (Acer / Q5LJ1 / Aspire M5-581T, Aspire M5-581TG)



Host: Notebook Computer (Acer / Q5LJ1 / Aspire M5-581T, Aspire M5-581TG)

WLAN Main Antenna <Tx/Rx>



Host: Notebook Computer (Acer / Q5LJ1 / Aspire M5-581T, Aspire M5-581TG)

WLAN Aux. Antenna <Tx/Rx>



Host: Notebook Computer (Acer / Q5LJ1 / Aspire M5-581T, Aspire M5-581TG)

