


6. SETUP PHOTOS

DYNAMIC FREQUENCY SELECTION MEASUREMENT SETUP



DFS SIDE PHOTO (EUT)



DFS FRONT PHOTO (CLIENT MODE SETUP)



DFS FRONT PHOTO (CLIENT-TO-CLIENT COMMUNICATIONS
MODE SETUP)



END OF REPORT