EN IMPORTANT: Read these instructions. **DO NOT DISCARD.**
Please read these carefully before using.
- Only adults should install and replace batteries.
- Rechargeable batteries are only to be charged under adult supervision.
- Rechargeable batteries are to be removed from the toy before being charged.
- Do not mix alkaline, standard (carbon zinc) or rechargeable (nickel cadmium) batteries.
- Do not mix old and new batteries.
- Batteries are to be inserted with the correct polarity.
- Only batteries are to be used as specified or equivalent as recommended are to be used.
- The supply terminals are not to be short-circuited.
- Exhausted batteries are to be removed from the toy.
- Batteries are to be removed from the toy, if it is not to be used for a long time.
- Batteries may explode or leak if mixed.
- Do not dispose of batteries in fire, batteries may explode or leak.
- Batteries may explode or leak if mixed.
- Supply terminals are not to be short circuited.

FR IMPORTANT: Conserver ces instructions. NE PAS LES ÉLIMINER.
Attention :
- Les piles doivent obligatoirement être remplacées par un adulte.
- Les batteries rechargeables doivent être retirées du jouet avant d'être rechargées.
- Les batteries rechargeables ne doivent pas être rechargées que par les adultes.
- Les piles usagées doivent être retirées du jouet.
- Les piles non rechargeables ne doivent pas être rechargées.
- Les piles de types différents ou neuves et usagées ne doivent pas être mélangées.
- Les piles doivent être installées en respectant la polarité.
- Les bornes d'alimentation ne doivent pas être court-circuitées.
- Retirer les piles usagées du jouet.
- Retirer les piles du jouet si celui-ci ne doit pas être utilisé pendant une période prolongée.
- Ne pas jeter les piles au feu : elles risquent d'exploser.
- Ne pas jeter les piles au feu : elles risquent d'exploser.
- Ne pas mélanger des piles neuves et usagées.
- Ne pas mélanger des piles alcalines standard (zinc-carbone) ou rechargeables (cadmium-nickel).
- Ne pas mélanger des piles de types différents (zinc carbone) ou rechargeables (cadmium-nickel).
- Il faut retirer les piles du jouet.
- Il faut retirer les piles du jouet si celui-ci ne doit pas être utilisé pendant une période prolongée