

Owner's Manual

Item No. 3279

Power up your Little Tikes R/C Pre-school

For transmitter:

1. Slide ON/OFF on the transmitter to OFF.
2. Unscrew and remove the battery cover at the bottom of the controller.
3. Insert one 9V battery (not included) into the battery compartment of the controller according to the polarity symbols.
4. Replace the battery cover and tighten the screw.

For the vehicle

1. Slide ON/OFF on the car to OFF.
2. Unscrew and remove the battery cover at the bottom of the car
3. Insert three "AA" batteries (not included) into the battery compartment of the tank according to the polarity symbols.
4. Replace the battery cover and tighten the screw.

Please note:

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon zinc), or rechargeable (nickel-cadmium) batteries.

Driving your vehicle

1. Slide ON/OFF on the car to ON
2. Press the forward button to make the car move forward. Press the backward button to make the car to reverse with spin action

FCC NOTE

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

FCC Warning Statement for FCC ID Label Requirements

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:

- (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND
- (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.