

CMYK

■ 6, 91, 62, 1

■ 74, 65, 63, 81

■ 74, 65, 63, 81

■ 0, 0, 0, 0

■ 0, 0, 0, 50

■ 0, 0, 0, 12

■ 0, 0, 0, 0

■ 100, 69, 24, 7

Background color (front and the top of the back side)

■ 0, 0, 0, 12

