



Label Location HUAWEI G630-U251, G630-U251



**HUAWEI**

 Micro-SIM

 MicroSD

HUAWEI Ascend G630 MODEL:G630-U251

Cautions:

- Follow the instructions in the right side figures to install or remove your microSD card.
- Do not remove the built-in battery yourself. To replace the battery, please contact a Huawei authorized service center.
- Do not insert or remove the microSD or micro-SIM card when your phone is powered on.
- Pressing and holding the power button for more than 10 seconds will restart your phone.

Use only power supplies listed in the user manual.

 **0682**

 **FCC ID:QISG630-U251**

 **MADE IN CHINA**

 **HUAWEI TECHNOLOGIES CO.,LTD.**













**HUAWEI**

 Micro-SIM

 MicroSD

HUAWEI Ascend G630 MODEL:HUAWEI G630-U251

Cautions:

- Follow the instructions in the right side figures to install or remove your microSD card.
- Do not remove the built-in battery yourself. To replace the battery, please contact a Huawei authorized service center.
- Do not insert or remove the microSD or micro-SIM card when your phone is powered on.
- Pressing and holding the power button for more than 10 seconds will restart your phone.

Use only power supplies listed in the user manual.

 **0682**

 **FCC ID:QISG630-U251**

 **MADE IN CHINA**

 **HUAWEI TECHNOLOGIES CO.,LTD.**















