

APPENDIX M: EXTERNAL PHOTOGRAPHS



PHOTOGRAPH 5: FRONT OF WI-FI SWITCH SHOWING SLOT ANTENNAS




PHOTOGRAPH 6: BACK VIEW RIGHT SIDE WI-FI SWITCH



PHOTOGRAPH 7: BACK VIEW LEFT SIDE WI-FI SWITCH




PHOTOGRAPH 8: BOTTOM VIEW LEFT SIDE WI-FI SWITCH




PHOTOGRAPH 9: BOTTOM VIEW MIDDLE SECTION WI-FI SWITCH




PHOTOGRAPH 10: BOTTOM VIEW RIGHT SIDE WI-FI SWITCH




PHOTOGRAPH 11: TOP OF WI-FI SWITCH



PHOTOGRAPH 12: TOP VIEW LEFT SIDE WI-FI SWITCH



PHOTOGRAPH 13: TOP VIEW MIDDLE SECTION WI-FI SWITCH



PHOTOGRAPH 14: TOP VIEW RIGHT SIDE WI-FI SWITCH



PHOTOGRAPH 15: SIDE OF WI-FI SWITCH



PHOTOGRAPH 16: SIDE OF WI-FI SWITCH