




Using Your headset

How to charge:

STEP:

- 1 Connect the charger to the cradle and to the mains.
- 2 Insert the headset into the charging cradle. Make sure the connector plates are aligned with the connector plates in the Bluespoon™ headset.
- 3 Gently press the headset into place.
- 4 Slide the blue release catch wing over the headset.
- 5 When the Bluespoon™ is placed correctly the indicator light on the charging cradle will show a steady red light.
- 6 When the charging is complete, the red light on the charging cradle turns off.




Using Your headset

How to charge:

STEP:

- 7 To remove the headset from the cradle, slide the blue release catch wing backwards and gently lift up the headset.



Please refer to the Bluespoon™ mini cd-rom for further information and a complete animation of how to charge the Bluespoon™.

A fully charged headset battery provides up to:

- o talk time- 6 hours
- o standbytime- 100 hours

The performance of all rechargeable batteries will improve if they are completely discharged and then afterwards fully recharged once a month.

A new or rarely used rechargeable battery must be fully recharged and then afterwards completely discharged a couple of times to get optimal talk time.

Using Your headset


Wearing the headset.

Placing the headset in Your ear.

The headset is configured for wear on the right ear only.

STEP:

- 1 Hold the Bluespoon™ in your right hand with your three first fingers. The soft spring should be bent by your index finger.
- 2 Insert the Bluespoon™ in your right ear, while twisting it counter clockwise approximately 60°. The soft spring should be placed in the upper bend of your ear.
- 3 With your index finger make sure that the soft spring is in place. The soft spring ensures that the Bluespoon™ is kept in place.



Using Your headset

Wearing the headset.

Please refer to the Bluespoon™ mini cd-rom for further information and a complete animation of how to insert the Bluespoon™ in the ear.

Comfort

Two springs have been supplied. One white (soft) and one black (harder). If the black spring feels uncomfortable, please replace with white spring.

If the white spring is uncomfortable, please bend it before inserting in the ear.

The spring should be bent, while twisting it. This will put less pressure on your ear.

If the spring jumps out of the ear, the tip of the spring can be bent upwards before inserting in the ear.

Using Your headset

Pairing Your headset & phone

Note: You must pair your headset and phone before you can make a call.

You establish a Bluetooth™ link between your headset and phone with a paired link. When you set up a paired link, the phone remembers the headset's ID. Once your headset and phone are paired, your headset automatically connects to your phone any time, you turn your headset on.

Paired Link

With the headset and phone in close proximity:

STEP:

- 1 Turn headset OFF
- 2 Press and hold down both the Multifunction Buttons for 7 seconds.
- 3 Perform a device discovery from the phone.

RESULT:

Both the blue and red headset indicators will show a quick flash of light.

Both the blue and the red indicator lights starts blinking.

When the scan is complete, the phone displays 'found Bluespoon'.

For details on device discovery for your phone, refer to the user's guide for the phone.

- 4 Press the YES key on the phone to bond to the headset.
 - 5 When "Enter Bluetooth Passkey" appears, enter the passkey 3333, then press OK on the phone to pair the headset with the phone.
- The device ID is now stored in the phone's memory. When pairing is successful the red indicator light stops blinking and the blue indicator light starts blinking once every 20 seconds.

Please refer to the Bluespoon™ mini cd-rom for further information.

Using Your headset


Controlling headset volume.

Increasing and Decreasing Volume

Note : Adjusting volume can only be done during an active call.


To **increase** speaker volume, press the **right** Multi Function button repeatedly until you reach the desired volume level.

When the maximum volume level is reached you will hear a single beep.



To **decrease** speaker volume, press the **left** Multi Function button repeatedly until you reach the desired volume level.

When the minimum volume level is reached you will hear a single beep.



Using Your headset

Placing and receiving a call

You can place a call with your headset in these two ways:

- using voice activation
- dialling a number from the phone

In both cases, you must first link your headset and phone as described in "Pairing Your Headset & Phone" on page 19.

Using Voice Activation

Note: To use voice activation, you must turn on Voice Dial in your phone's Bluetooth™ link menu.

STEP:

- 1 Press and hold one of the Multifunction

Buttons for one second while the headset is on.

RESULT:

A tone sounds to prompt you to speak the name of the person you wish to call (as entered in the phone's phonebook).

- 2 Say the voicetag name.

Your phone finds the entry, pauses, and then places the call.

Please refer to the Bluespoon™ mini cd-rom for further information.

Using Your headset

Notes

- Voice tags must be stored in the phone. Consult your phone's User Guide for more information.
- If the voice tag name is not recognized, you will hear a sequence of high/low tones.

Dialling a Number from the Phone

STEP:

- 1 Using the phone's keypad, dial the phone number.
- 2 To send the call:
 - Press the standard key for sending calls from your phone.

Ending a Call from the Headset

To end a call, press both the headset's Multifunction Buttons. A sequence of high/low tones indicates that the call has ended.

Receiving a Call

With the Headset On and paired.

When you receive an incoming call with the headset on and paired, a ring tone is generated in your headset. To pair your headset and phone, see "Pairing Your Headset & Phone" on page 19. Answer the call by pressing one of the headset's Multifunction Buttons.

Using Your headset

Receiving a call

With the Headset Off (Paired Link Only)

When you receive a call with the headset **OFF**, you first have to turn the headset **ON**. See 'Bluespoon™ Basics'. When you have turned the headset on, push one of the headsets Multifunction Buttons **once** to receive the call.

Transferring a Call

Headset to Phone

The transfer must be initiated by the phone. (See the user's guide for your phone.)

Phone to Headset

If the Bluespoon™ is already turned **ON** and the call is on the phone, push one of the headsets Multifunction Buttons once.

Disconnecting the Bluetooth™ Link

To terminate the Bluetooth™ connection between the headset and phone, turn the headset **OFF** by holding down both buttons for two seconds, see page 9.

Using Your headset

Using Your Headset and charging cradle Indicators

Headset indicator with charger plugged in:

CHARGING CRADLE INDICATOR:

ON

OFF

HEADSET:

charging in progress

charging complete

BLUE HEADSET INDICATOR:

OFF

flashes at a 20 - second interval

flashes at a 10 - second interval

HEADSET:

power off

turned on (not on a call)

connected (on a call)

RED HEADSET INDICATOR:

OFF

flashes at a 20 - second interval

flashes at a 10 - second interval

HEADSET:

power off

turned on (not on a call) - Battery low

connected (on a call) - Battery low

BLUE AND RED HEADSET INDICATOR:

Both blue and red headset indicator flashing repeatedly

HEADSET:

pairing mode

Note : Both blue and red headset indicator shows a quick flash when the headset is turned off.

Using Your headset

Audio Tones

AUDIOTONES:

- a single high tone when button released
- two rapid high tones, repeated every 30 seconds (only during conversation)
- no audio indications; deteriorating audio quality
- ring tone
- a single tone
- several tones high to low
- several tones high to low
- several tones high to low
- several tones from low to high
- several tones high to low

HEADSET STATUS:

- volume min. or max.
- low battery
- out of range
- incoming call
- initiate voice activation
- voice tag not recognized
- end call
- audio link closed
- power ON
- power OFF

Using Your headset

Audio Tones

AUDIOTONES:

a single high tone when button released

two rapid high tones, repeated every 30 seconds (only during conversation)

no audio indications; deteriorating audio quality

ring tone

a single tone

several tones high to low

several tones high to low

several tones high to low

several tones from low to high

several tones high to low

HEADSET STATUS:

volume min. or max.

low battery

out of range

incoming call

initiate voice activation

voice tag not recognized

end call

audio link closed

power ON

power OFF

Using Your headset

Resetting the Headset

If the phone and headset fail to communicate, you may need to reset the headset.

STEP:

- 1 Place the headset in the charging cradle (see "How to Charge" on page 15).
- 2 Unplug the charging cradle from the adapter.
- 3 *Wait 2 seconds.*
- 4 Put the plug back into the charging cradle.
- 5 Remove the headset from the charging cradle.
- 6 Place the headset in the charging cradle.

Note: Resetting the headset does not affect paired links or device data.

Please refer to the Bluespoon™ mini cd-rom for further information.

