





### 2.1.7 Setup Photos




30 - 200 MHz




200 - 1000 MHz







### 2.2.7 Setup Photos




### 2.1.7 Setup Photos



**Mode 1 Configuration 1 / Setup 3**



**Mode 1 Configuration 2 / Setup 1**



**Mode 1 Configuration 2 / Setup 2**



**Mode 1 Configuration 2 / Setup 3**



**Mode 2 Configuration 1 / Setup 1**



**Mode 2 Configuration 1 / Setup 2**



**Mode 2 Configuration 1 / Setup 3**




**Mode 2 Configuration 2 / Setup1**



**Mode 2 Configuration 2 / Setup 2**




**Mode 2 Configuration 2 / Setup 2**




1 - 12 GHz Setup1




1 - 12 GHz Setup 2



1 - 12 GHz Setup 3



1 - 12 GHz Setup 4



## 2.2.7 Setup Photos

