


## <Photographs of EUT>



### <Antenna Location>



The separation distance for antenna to edge:

| Antenna    | To Left Side (mm) | To Right Side (mm) | To Top Side (mm) | To Bottom Side (mm) |
|------------|-------------------|--------------------|------------------|---------------------|
| WWAN Ant-0 | 0                 | 0                  | 82               | 0                   |
| BT         | 0                 | 50                 | 66               | 21                  |


## <Photographs of SAR Setup>



**Right Cheek**



**Right Tilted**



**Left Cheek**



**Left Tilted**



**Front Face of EUT with 1.0 cm Gap**



**Rear Face of EUT with 1.0 cm Gap**

## **Shenzhen UnionTrust Quality and Technology Co., Ltd.**

Address: 16/F, Block A, Building 6, Baoneng Science and Technology Park, Qingxiang Road No.1, Longhua New District, Shenzhen, China  
 Tel: +86-755-28230888 Fax: +86-755-28230886 E-mail: [info@uttlab.com](mailto:info@uttlab.com) <http://www.uttlab.com>