

1. Photographs of Radiated Emissions Test Configuration


Test Configuration: Above 1GHz

For Radio 1:


Test Mode: Mode 1

For Radiated Emission:

FRONT VIEW




REAR VIEW




For Band Edge Emission:

For Test Mode: 1T1S, 2T2S Mode:

FRONT VIEW




REAR VIEW




For Test Mode: 4T1S, 4T4S Mode:

FRONT VIEW



REAR VIEW




Test Mode: Mode 2

For Radiated Emission

For 5G Band 2-4T1S Mode:

FRONT VIEW




REAR VIEW



For 5G Band 3-4T1S Mode:

FRONT VIEW




REAR VIEW



For Band Edge Emission:

For Test Mode: 2T2S, 4T1S, 4T4S Mode:

FRONT VIEW




REAR VIEW



For Test Mode: 1T1S Mode:

FRONT VIEW



REAR VIEW




Test Mode: Mode 3


For Radiated Emission:

For 5G Band 2-4T1S Mode:

FRONT VIEW




REAR VIEW




For 5G Band 3-4T1S Mode:

FRONT VIEW




REAR VIEW




For Band Edge Emission:

For Test Mode: 1T1S, 2T2S Mode:

FRONT VIEW




REAR VIEW




For Test Mode: 4T1S, 4T4S Mode:

FRONT VIEW



REAR VIEW



For Radio 2:

Test Mode: Mode 1

For Radiated Emission:

FRONT VIEW



REAR VIEW



For Band Edge Emission:

For Test Mode: 1T1S, 2T2S, 4T1S, 4T4S Mode:

FRONT VIEW



REAR VIEW




Test Mode: Mode 2

For Radiated Emission

For 5G Band 2-4T1S Mode:

FRONT VIEW




REAR VIEW



For 5G Band 3-4T1S Mode:

FRONT VIEW




REAR VIEW



For Band Edge Emission:

For Test Mode: 1T1S, 2T2S, 4T1S, 4T4S Mode:

FRONT VIEW



REAR VIEW




Test Mode: Mode 3


For Radiated Emission:

For 5G Band 2-4T1S Mode:

FRONT VIEW




REAR VIEW




For 5G Band 3-4T1S Mode:

FRONT VIEW




REAR VIEW




For Band Edge Emission:

For Test Mode: 2T2S Mode:

FRONT VIEW




REAR VIEW




For Test Mode: 1T1S, 4T1S, 4T4S Mode:

FRONT VIEW



REAR VIEW



————THE END————