


## Back of the EUT



Label located in the battery compartment and is visible to the users as they install the SIM card.