


1. External Photograph of the Host

Host: Tablet

Model Name: F120,


F120Y (Y= 10 characters, Y can be 0-9, a-z, A-Z, “-“, “_” or blank for marketing purpose and no impact safety related critical components and constructions.))














SKU C













2. Photograph of Accessory for the Host

List of Accessory for Host (Tablet):


Specification of Accessory		
AC Adapter 1	Brand Name	FSP GROUP INC
	Model Name	FSP065-RBBN3
AC Adapter 2	Brand Name	Getac
	Model Name	MTA190474W4
Battery 1	Brand Name	Getac
	Model Name	BP2S1P4070P
Battery 2	Brand Name	Getac
	Model Name	BP3S1P4070P
Touch Pen	Brand Name	Getac
	Model Name	GT-090S
Power Cable 1	Brand Name	I-SHENG
	Model Name	SP-305B+IS-034
Power Cable 2	Brand Name	I-SHENG
	Model Name	SP-305B+IS-14N


Remark: For accessories equipped with this EUT, please refer to the following photos.

AC Adapter 1















AC Adapter 2













Battery 1

