

GETTING TO KNOW YOUR COOLPAD DIAMANTE™


Navigate your new **Coolpad Diamante™** easily and effortlessly the instant you turn it on. Witness how the phone's features lend themselves smoothly to your life every time you manage your apps—with just a tap. Who needs complicated? Achieve the ultimate ease while uploading videos to your favorite social media sites using your **Coolpad Diamante™**. Now it's exactly how it should've always been: simple and smooth. Now it's **Coolpad Diamante™**.



POWER UP

Get off to a running start with your new **Coolpad Diamante™**. First, attach the charger cable to the phone and plug in for a complete charge.

Turn on your phone by pressing and holding the power key for a few seconds. Now tap the **Unlock** icon and swipe to the right to unlock your phone. To change Screen-lock Security options, tap **Settings** > scroll down to **PERSONAL** > tap **Security** > **Screen Lock**. Select the option you want by tapping it.




SETTING UP & SENDING EMAILS

Tap **Settings** > tap **Email**. Now simply enter your existing email address, or add a new one, then enter your password. Select the account type from the 3 options.

In the Email screen, Press **Menu Key** > **Settings** to customize your Email Settings. You can add more email accounts by tapping “**ADD ACCOUNT**” in the **Settings**.

To send an email, in the Inbox screen, Tap **Email** icon. After entering an email address and your message, tap **Send** to send.




NOW YOU'RE HOME: CUSTOMIZE YOUR APPS

Check out your Home Screen and customize it with your favorite Apps by pressing down and holding your desired App icon(s) within the Apps Menu. From there, your selected App will quickly appear on your Home Screen.

To remove an App icon from your Home Screen, press & hold the **App** to be removed while sliding it to the top of the screen and depositing it into the trash icon labeled **Remove**.


If moving an App, simply press down and hold the chosen App while sliding it to the desired location on your phone.



SENDING TEXTS

To send a text, tap **Messages** on your Home Screen. Enter the recipient's phone number, type your message, and then tap the **Send** icon to the right to Send.

To attach a file or any media such as photos or videos, tap the **Attach** icon on the right upper-hand corner of the screen before sending your message, then tap **Send**.
Note: Your messages are automatically saved as drafts.




CONNECTING TO WI-FI & BLUETOOTH, & BROWSING THE INTERNET

For Wi-Fi, tap **Settings** and go to **Wireless Networks**, from there tapping the Wi-Fi icon. Select the Wi-Fi network by tapping it. Enter your secure password > tap **Connect**.

For Bluetooth, select the **Settings** > **Wireless Networks** Menu will appear. Tap **Bluetooth** to get to **CP3700A** connectivity. Tap **CP3700A** again to be visible (or not visible) to nearby Bluetooth devices.

For Internet browsing, tap the Google search bar at the top of your screen or tap **Chrome** in the Home Screen.



CREATING AND SHARING VIDEOS AND PHOTOS

To capture a video, simply tap the **Video** icon from your Home Screen. Then tap the icon on the lower left of the screen to expand the list and select **Video**.

Now tap the **Red** record button while using the screen to see your video. Tap the **Red** button to stop.

To take a picture, tap **Photo** icon. Again tap the **Photo** icon on the lower part of your screen. Focus by looking through the phone screen. Press the Blue button to snap a picture.

To share a video or a photo, go to **Apps** on your Home Screen > tap **Share** icon. Tap your selected video, and then the **Share** icon to the right of the video title. From the drop-down options, select your method of sharing by tapping on it. It really is that easy!

LEARN MORE...

- **Download** new Apps by tapping the Play Store icon on the Home Screen.
- **Sync** your Google/Gmail account by tapping Existing (or New) Gmail account. Here you can download apps, games, music, movies and other media by following the online instructions.

NOW, STAY CONNECTED:

- **Get** updates, user guides and online manual for your **Coolpad Diamante™** at www.coolpadamericas.com
- **Discover** what's going on right now in cell phone news, trends, techniques and other cool stuff by connecting with us on:

- Facebook www.facebook.com/CoolpadAmericas
- YouTube www.youtube.com/CoolpadAmericas
- Twitter www.twitter.com/CoolpadAmericas



Subscribe Our Newsletter List to stay connect with Coolpad and other techy news and updates!

Devices, screen images are simulated, See **Terms and Conditions** at www.coolpadamericas.com for more details.

All materials in this document including, without limitation, the design, the text, and any and all marks (unless otherwise indicated) are the property of Coolpad Technologies, Inc. Copyright © 2014 Coolpad Technologies, Inc. All Rights Reserved. Coolpad and the Coolpad logo are registered trademarks Yulong Computer Telecommunication Scientific (Shenzhen) Co., Ltd. Google, Android, Gmail, Google Talk, Google Play, and YouTube and other related marks are trademarks of Google Inc. The Facebook icon is a trademark of Facebook Inc. The Twitter icon is trademark of Twitter Inc.

ATTENTION: Pictures shown are for illustration purpose only and do not represent actual devices.