

Sylvania

Bluetooth Mini LED Speaker

MODEL NO.: BTS-S02

INSTRUCTION MANUAL

* The picture is only provided for reference. Please refer to the actual unit!
SYLVANIA is a registered trademark of OSRAM Sylvania Inc., used under license.

Instructions for use

Please read all instructions carefully

Getting started

Remove the unit from the box
Remove any packaging from the product.
Place the packaging inside the box and store for safekeeping

In the box

Bluetooth neon light up speaker
Micro USB charging cable
3.5mm Aux cable
Instruction Manual

Features

- streams music wirelessly
- Bluetooth wireless connection functionality
- translucent body changes colors
- Built-in rechargeable battery
- Microphone echo effect and volume adjustment
- Support TF card playback
- built-in FM radio & Aux jack

Safety Instructions

- Keep the unit away from heat sources, direct sunlight, humidity, water and any other liquids.
- Do not use the unit if it has been dropped or damaged in any way.
- Repairs to electrical equipment should only be performed by a qualified electrician, Improper repairs may place the user at serious risk.
- Do not put objects into any of the openings.
- Keep the unit free from dust, lint etc.
- Do not use this unit for anything other than its intended use.
- Keep the unit out of reach of children,
- This product is not a toy.
- Do not use abrasive cleaning solvents to clean.
- To minimize the risk of fire or electrical shock, avoid operating in wet conditions such as rain or humidity.
- Do not operate around water (e.g.bathroom, swimming pool ect.)
- Do not expose to excessive heat such as sunshine, fire ect.
- Never immerse the unit in water or any other liquid for cleaning purposes.

Product Diagram

1	Aux jack	Aux-in jack-plays music through auxiliary connection
2	Power on /off switch	Turn on /off the speaker
3	USB flash drive Slot	Plays music from USB flash drive (not included)
4	DC charging port	DC charging port-to charge the speaker
5	Led light indicator	Indicates the recharging status
6	>>>	Short press the button will skip to the next track or next FM radio station. Hold press the button will increase volume level.
7	LED button	Short press each time for changing 3 different lighting patterns and off within Playing operation;
8	M/M/F	MODE-long press for changing mode of operation (Bluetooth/AUX/TF/AUX) or short for searching FM station, short press will pause or restart the music . call answer/reject call /call end /redial button at Bluetooth phone conversation.
9	<<<	Short press the button will return to the previous track or previous FM radio station. Hold press the button will decrease volume level.
10	Micro SD (TF) card slot	Play music from micro SD (TF) Card (not included)

INSTRUCTION FOR USE

Charging the speaker

This unit has a built in rechargeable battery.
Before using it for the first time we recommend you use the USB cable to charge the battery fully.
Connect the USB cable to the micro USB port or USB wall charger (Not included).ANDA connect other side to the USB charging slot of the speaker. The red battery charging LED indicator illuminates while the speaker is being charged. When the battery is fully charged, the red LED indicator will be OFF.

Pairing your device with Bluetooth speaker

Pairing the Portable Karaoke Player with Bluetooth devices (phone or music device)
Slide the power ON/OFF switch to ON position.
You would hear the indication tone and see led light bright, the speaker is now in pairing mode.
Place the speaker and Bluetooth device (phone or music device) so that they are no further than 30 feet apart;
Activate the Bluetooth function on your Bluetooth device (phone or music device). Please refer to the manufacturer's instructions for instructions on enabling Bluetooth on your device.
Once you have activated Bluetooth on your device, select the pairing name " BTS-S02 " from the list of available Bluetooth devices.
If required, enter the password '0000' to confirm to pairing.
Once paired successfully, you will hear a Ding Dong tone indicating pairing successful.
You can now start to use the speaker.

Once you have paired the speaker with a device, the speaker will remember this device and will pair automatically when the device's Bluetooth is activated and in range. You do not need to re-pair any previously connected devices.

The speaker will attempt to automatically connect to the last device it was paired with when Bluetooth mode turn on. If you want to pair it with a new device, please turn OFF your last Bluetooth device (phone or music device) then use your new device to search and select the pairing name.
Once the speaker is paired with your device the music will transmit directly to the speaker, Please refer to your device's user manual for further information.

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.