

Bluetooth Speaker



BTS-631A

INSTRUCTION MANUAL

PLEASE READ ALL INSTRUCTIONS CAREFULLY AND RETAIN FOR FUTURE USE

Getting Started

- Remove the speaker from the box.
- Please retain all packaging until you have checked and counted all the parts and the contents against the parts list.

Package Contents

- Beatbox Wireless Speaker
- USB charging cable
- Auxiliary cable
- Instruction Manual

Key Features

- BEATBOX – Fashionable Wireless Speaker with high quality fabric speaker grill
- Connect & stream wireless music from any Bluetooth enabled device anytime, anywhere
- Built-in high-end speaker that delivers crisp and clear sound
- Built-in FM Radio
- Connect your MP3/MP4 players, disc man etc through 3.5mm auxiliary cable (included)
- Play music directly from your Micro SD memory card or USB Flash drive
- Built-in microphone allows hands-free calls
- Built-in rechargeable battery

Note: Micro SD memory card & USB flash drive are not included

SAFETY INSTRUCTIONS

- Read these instructions.
- Keep these instructions.
- Heed all warnings.
- Follow all instructions.
- Do not use this apparatus near water.
- Clean only with dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Description of Parts



1	Skip Forward/Volume Increase Button
2	ON/OFF/Mode Button
3	Multi-colored LED
4	Skip Backward/Volume Decrease Button
5	Play/Pause/Phone Button
6	USB Slot
7	Auxiliary Port
8	LED Indicator/Built-in mic
9	Charging Port
10	Micro SD (TF) Card Slot

INSTRUCTIONS FOR USE

Charging the speaker

The speaker has built-in rechargeable battery. When the battery is drained out, speaker would turn OFF automatically. Please recharge the battery every time it drains out.

Plug the Micro USB end of the included USB charging cable into the charging port. Plug the other end into a USB port on your computer or other devices made for USB charging. Red LED Light illuminates indicating that the device is being charged.

Connect using Bluetooth Technology

- Press and hold the ON/OFF button for 2 seconds to turn on. You would hear an indication tone and multi-colored LED Lights would turn on, indicating that you are now in Bluetooth Pairing Mode.
- Activate the Bluetooth function on your source device (Mobile Phone or Tablet). Please refer to manufacturer's instructions for instructions on enabling Bluetooth on your device.
- Search for available Bluetooth devices and you would find "SL BEATBOX" – Pair it with this device.
- If required, enter the password "0000" to pair with the device.
- Once paired successfully, you will hear another indication tone.
- You can now stream wireless music on your speaker through your source device.

Talking using the Bluetooth Speaker

Please ensure that you are paired with the Bluetooth Speaker to use the below functions.

Function	Operation	Button
Answer Incoming Call	Incoming Call	Press the Phone once to answer an incoming call.
Reject incoming call	Incoming Call	Press and hold the Phone button for 2 seconds
End Call	Incoming Call	After your phone conversation, short press the Phone button
Increase Volume	During a call	Press and hold the + button to increase the volume
Decrease Volume	During a call	Press and hold the - button to decrease the volume
Redial last number	Standby mode and connected to a device	Short press the Phone button twice

Listening to Music Wirelessly

Please ensure that your device (iPhone, Tablet or Other Smart Phone) is paired with the Bluetooth Speaker to stream music wirelessly. Once it is paired, play music from your device.

Function	Operation	Button
Increase Volume	Playing music	Press and hold the + button to increase the volume
Decrease Volume	Playing music	Press and hold the - button to decrease the volume

(Note: An indication tone will alert you when the volume is adjusted to the maximum level. In Auto mode, besides the volume increase/decrease, you will need to control through your source device.)