



EUT INTERNAL PHOTOS


EUT UNCOVER VIEW 1




EUT UNCOVER VIEW 2




EUT UNCOVER VIEW 3



EUT UNCOVER VIEW 4




Antenna location map




Antenna	Description	Support Bands
Antenna 0	2/3/4/5G TX Antenna	GSM 850/900 WCDMA Band 5/8 LTE Band 5/8/12/13/17/18/19/26/28 NR n5/12/26
Antenna 1	2/3/4/5G TX Antenna	GSM 850/900 WCDMA Band 5/8 LTE Band 5/8/12/13/17/18/19/26/28 NR n5/12/26
Antenna 3	2/3/4/5G TX Antenna	GSM 1900 WCDMA Band 2/4 LTE Band 2/4/7/66/38/41 NR n2/7/66/38/41
Antenna 4	2/3/4/5G TX Antenna	GSM 1900 WCDMA Band 2/4 LTE Band 2/4/7/66/38/41 NR n2/7/66/38/41
Antenna 5	4/5G TX Antenna	LTE Band 4/7/66/38/41/48 NR n7/66/38/41
Antenna 6	4G TX Antenna	LTE Band 48
Antenna 7	4G TX Antenna	LTE Band 48
Antenna 8	WiFi 2.4G TX Antenna WiFi 5G TX Antenna Bluetooth TX Antenna	2.4G WiFi 5G WiFi Bluetooth
Antenna 10	4G TX Antenna	LTE Band 48


MAIN BOARD TOP VIEW (WITH SHIELDING)




MAIN BOARD TOP VIEW (WITHOUT SHIELDING)




MAIN BOARD REAR VIEW (WITH SHIELDING)




MAIN BOARD REAR VIEW (WITHOUT SHIELDING)




SECONDARY BOARD 1 TOP VIEW




SECONDARY BOARD 1 REAR VIEW



BATTERY



REAR VIEW



--BLANK BELOW--