

Photographs of EUT Setup and Antenna Location


The photographs of EUT and setup for SAR testing are shown as follows.

NB _ Antenna Location

1. Antenna Host Platform Location Information

Include a dimensioned photo(s) or dimensioned drawing(s) of Main and Aux antenna placements (measurements are not required for receive-only antenna).

Any antenna that transmits must show dimensions to bottom of laptop. Provide a description of the materials that are used for supporting or surrounding transmit antennas; for example, non-conductive plastics vs. conductive coated plastic or metallic materials.




Minimum Separation Distance			
Item	Antenna	Position	Distance (mm)
A	WLAN-Main	to Top	6.0
B		to Right	48.25
C		to Left	231.65
D		to Bottom	205.17
F	Main-Aux	Main to Aux	163.4
G	WLAN-Aux	to Top	6.0
H		to Right	231.65
I		to Left	48.25
J		to Bottom	205.17
L	NB	Bumper thickness	1.8

2. Antenna dimensional information for SAR evaluation

Include a dimensioned photo(s) or dimensioned drawing(s) showing the distance (mm) between the transmit antennas and the user. For notebook/laptop hosts show lapheld position (example below). For tablet hosts show all orientations including lapheld, primary & secondary portrait, primary & secondary landscape positions.

Antennas on the panel section




TB _ Antenna Location

3. Antenna Host Platform Location Information

Include a dimensioned photo(s) or dimensioned drawing(s) of Main and Aux antenna placements (measurements are not required for receive-only antenna).

Any antenna that transmits must show dimensions to bottom of laptop. Provide a description of the materials that are used for supporting or surrounding transmit antennas; for example, non-conductive plastics vs. conductive coated plastic or metallic materials.




Minimum Separation Distance			
Item	Antenna	Position	Distance (mm)
W	WLAN-Main	to Front	5.65
X		to Rear	18.45
Y	WLAN-Aux	to Front	5.65
Z		to Rear	18.45

4. Antenna dimensional information for SAR evaluation

Include a dimensioned photo(s) or dimensioned drawing(s) showing the distance (mm) between the transmit antennas and the user. For notebook/laptop hosts show lapheld position (example below). For tablet hosts show all orientations including lapheld, primary & secondary portrait, primary & secondary landscape positions.

Antennas on the panel section



<Photographs of Body SAR Test Setup>




Bottom of Laptop Mode Tested at 0 mm

<Photographs of Body SAR Test Setup>



Rear Face of Tablet Mode Tested at 0 mm



Left Side of Tablet Mode Tested at 0 mm



Right Side of Tablet Mode Tested at 0 mm



Top Side of Tablet Mode Tested at 0 mm



Bottom Side of Tablet Tested at 0 mm

<Photographs of Power Density Test Setup>

