


5.5.8. Photographs of Conducted Emission Test Configuration

FRONT VIEW



REAR VIEW



5.6.11. Emission Test Configuration

MODE1

FRONT VIEW




REAR VIEW



MODE2

FRONT VIEW



REAR VIEW

