

Instruction Manual

HOW TO RECHARGE

- * The Ni-MH battery pack (9.6V) is not charged. Recharge before playing.
- 1. Plug the Ni-MH battery pack into the battery compartment of the battery charger
- 2. Plug the charger into an ordinary household outlet.
- * average charging time is approximately 4 hours but 10 hours for the first time.
- 3. When the recharging is over, remove the charger from the household outlet.
- 4. Push the lever of battery charger and disconnect the battery pack from the battery charger.

Caution

- This charger is only suitable for charging Ni-MH battery. Other types of rechargeable batteries may burst causing injury to person and damage.
- Never let the charger or battery pack wet or damp.
- Overcharging can damage the battery pack. Follow the indicated recharging time.
- Do not recharge in high temperatures or bring the battery pack near a flame.
- Check the batteries regularly for leakage.
- Remove empty batteries from the vehicle.
- Never try to charge non-rechargeable batteries.
- Removable batteries which can be recharged must be removed from the vehicle prior to charging.
- Do not take the charger or battery pack apart.
- Do not recharge the battery pack while it is still heated after use. Wait until it has been cooled down.
- Rechargeable batteries may be charged under the supervision of an adult.
- Use only the recommended batteries or batteries of equal quality.

Cleaning and maintenance:

This toy vehicle needs periodic maintenance and cleaning.

Warning to the parents:

The charger for the Ni-MH battery pack needs periodic inspection to see that the lead wires, plugs, out case, and other parts are not damaged in any way. If any of parts are damaged, do not use the charger until it is completely repaired.

Caution

Keep out of reach of small children under 36 months old as there is danger of getting hurt.

RADIO INTERFERENCE: Sometimes erratic behavior or loss of control of vehicle is the result of interference which is caused by high tension wires, high voltage transformers, certain types of building, concrete walls or narrow places where radio signal can be easily affected. If you encounter this type of behavior or loss of control, CHANGE TO A DIFFERENT LOCATION for playing the toy. You will encounter INTERFERENCE if ANOTHER radio controlled vehicle or CB radio is operating in the vicinity on your SAME FREQUENCY.

- Extend the telescopic antenna to it's full length.
- Set Power Switch of the car to "ON"
- Set the transmitter switch to "ON"
- Steering to the left, right or straight or reverse direction is controlled by the steering control stick.
- Remember to switch off the power switch after use.
- When operating the vehicle with a 9.6V rechargeable battery pack. Please follow the charging instructions on the pack. Please Note: The battery pack will become HOT during use, so care must be taken whenever you handle it.
- When charging the battery for the first time, you should expect the initial charge might require 4 hours and last 8-10 minutes in the intense operation of the vehicle. Each time you charge the battery, you should get longer performance as you "break in" your battery, until you enjoy operation that is twice as long as that of the initial charge.
- **THE TOY IS NOT INTENDED FOR CHILDREN UNDER 3 YEARS OLD;**
- **THE TOY MUST ONLY BE USED WITH THE RECOMMENDED TRANSFORMER;**
- **THE TRANSFORMER IS NOT A TOY;**
- **TOY LIABLE TO BE CLEANED WITH LIQUID ARE TO BE DISCONNECTED FROM THE TRANSFORMER BEFORE CLEANING.**
- **RECHARGEABLE BATTERIES ARE TO BE REMOVED FROM THE TOY BEFORE BEING CHARGED (IF REMOVEABLE)**
- **ANY BATTERY CHARGER TO BE USED WITH THE TOY SHOULD BE REGULARLY BY EXAMINED FOR POTENTIAL HAZARDS, SUCH AS DAMAGE TO THE CABLE OR CORD, PLUG, ENCLOSURE OR OTHER PARTS, AND THAT, IN THE EVENT OF SUCH DAMAGE, THE TOY MUST NOT BE USED UNTIL THAT DAMAGED HAS BEEN PROPERLY REMOVED.**
- **NON-RECHARGEABLE BATTERIES ARE NOT TO BE RECHARGED**
- **DIFFERENT TYPES OF BATTERIES OR NEW AND USED BATTERIES ARE NOT TO BE MIXED.**
- **ONLY BATTERY OF THE SAME OR EQUIVALENT TYPE AS RECOMMENDED ARE TO BE USED.**
- **BATTERIES ARE TO BE INSERTED WITH THE CORRECT POLARITY**
- **EXHAUSTED BATTERIES ARE TO BE REMOVED FROM THE TOY. THE SUPPLY TERMINALS ARE NOT TO BE SHORT-CIRCUITED**
- **PACKING HAS TO BE KEPT SINCE IT CONTAINS IMPORTANT INFORMATION**

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ☐ Reorient or relocate the receiving antenna.
- ☐ Increase the separation between the equipment and receiver.
- ☐ Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
- ☐ Consult the dealer or an experienced radio/TV technician for help.

Shielded cables must be used with this unit to ensure compliance with the Class B FCC limits.



SKYTEAM TECHNOLOGY (H.K.) LTD.
RM. 211, 2/F.,
SOUTH SEAS CENTRE, TOWER II,
75 MODY ROAD,
T.S.T. EAST, KLN., HONG KONG
E-MAIL : sales@skyteamtechnology.com / sales@skytechhk.com
WORLDWIDE WEB : <http://www.skyteamtechnology.com>
<http://www.skytechhk.com>

ALL MATERIAL FOR PACKING OF FASTENING PURPOSES ARE NOT PARTS OF THE TOYS AND SHOULD BE DISCARD FOR CHILDREN'S SAFETY.

- MANUFACTURED FOR SKYTEAM TECHNOLOGY (H.K.) LTD., ALL RIGHTS RESERVED.
- MADE IN CHINA
- CONFORMS TO ASTM F963 AND EN71
- COLORS AND DECORATIONS MAY VARY FROM THOSE SHOWN.

CAUTION : SMALL PARTS NOT RECOMMENDED FOR CHILDREN UNDER 3 YEARS OLD.

"WARNING. THE DEMONSTRATION BATTERIES IN THIS TOY MAY HAVE A SHORT LIFE DUE TO CONSUMER TESTING WHILE ON DISPLAY. YOU ARE ADVISED TO REPLACE WITH NEW BATTERIES AS SOON AS THE FUNCTION BECOMES IMPAIRED"

