

Update History			
	Ver1.1C	Ver1.2C	
R1	NO	YES	
S1	NO	YES	
S2	NO	YES	
S3	NO	YES	
LowBatteryIndicator	Pin3	Pin10	
R15	2.4V	240Kohm	TBD
	4.5V	470Kohm	
	6.0V	560Kohm	
R16	2.4V	220Kohm	TBD
	4.5V	220Kohm	
	6.0V	220Kohm	

- Notice:(1)the components that marked "*" are not used temporary
- (2)If the battery Voltage is +6V or +4.5V(four or three batteries), the components that in red dashed line can be not used and S2 must be on!
- (3)If the battery Voltage is +3V or lower(two batteries), the components that in blue dashed line can be not used

Title		
Ucomm_RF_DancePad_Device		
Size	Number	Revision
A3		Ver1.2C
Date:	14-Jun-2004	Sheet of 1 / 1
File:	F:\backup\buckup	Drawn By: CXW

