

User Manual

1. Power : Turn I- Drive On/OFF
2. Adi FM Radio Frequency
3. + or - : *Press + or - buttons to fine tune the frequency
*Press and hold the + or – scan buttons to increment frequency at a faster frequencies

Caution:changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment