

正面




BH22QT15A

开放式真无线耳机




使用前, 请下载安装QCY手机APP客户端
以获得更便捷的耳机操控体验

认识耳机




本说明书中的图片均为示意图, 可能与实物有偏差, 请以实物为准。

耳机佩戴



耳机配对

开盖, 取出耳机机会自动开机, 打开手机蓝牙搜索 "QCY Crossky GTR" 并点击连接 (若有连接记录, 开机机会自动重连最后连接的设备)




一键进入配对模式

1. 耳机已经与手机配对。
2. 耳机放盒子里, 打开充电盒盖子, 长按充电盒按键3秒至充电盒白灯长亮, 耳机断开与手机的连接, 取出耳机, 进入配对模式。

恢复出厂设置


双耳在充电盒里, 长按充电盒按键10秒, 耳机闪5次白灯, 复位完成后耳机开机。



充电盒亮灯提示 (开盖或按一下充电盒按键)
亮灯闪烁: 充电盒中满电量
亮红灯闪烁: 充电盒低电量

充电盒充电
充电中: 红色指示灯长亮
充满电: 白色指示灯长亮

功能操作



- ① 开 机: 长按触控面板约1.5秒
- ② 关 机: 把耳机放入充电盒
- ③ 接听/挂断: 双击触控面板
- ④ 拒接电话: 长按触控面板约1.5秒
- ⑤ 上一曲: 长按左触控面板约1.5秒
- ⑥ 下一曲: 长按右触控面板约1.5秒
- ⑦ 语音互动: 三击左耳触控面板
- ⑧ 播放/暂停: 双击触控面板播放/暂停
- ⑨ 低延迟模式: 三击右耳触控面板

QCY蓝牙耳机售后服务

QCY蓝牙耳机售后服务中心: 严格按照《中华人民共和国消费者权益保护法》、《中华人民共和国产品质量法》实行售后三包服务, 服务内容如下:
1. 自购买之日起7日内, 任何质量问题, 均可享受免费退换货服务。退换货时, 须保留原包装、配件、赠品等。
2. 自购买之日起15日内, 本产品出现质量问题, 经QCY售后服务中心鉴定为产品质量问题, 可享受免费退换货服务。
3. 自购买之日起12个月内, 本产品出现质量问题, 经QCY售后服务中心鉴定为产品质量问题, 可享受免费退换货服务。
三包服务与说明:
退换货: 自产品购买之日起12个月(消费者保留购买凭证);
免费维修: 在产品保修期内, 凡属产品本身质量问题引起的故障, 经用户凭购买凭证与经销商联系确认后, 可享受免费维修服务。
退换货: 退换货时, 须保留原包装、配件、赠品等, 并填写退换货申请表, 经经销商审核后, 方可办理退换货。
1. 退换货: 退换货时, 须保留原包装、配件、赠品等, 并填写退换货申请表, 经经销商审核后, 方可办理退换货。
2. 退换货: 退换货时, 须保留原包装、配件、赠品等, 并填写退换货申请表, 经经销商审核后, 方可办理退换货。
3. 退换货: 退换货时, 须保留原包装、配件、赠品等, 并填写退换货申请表, 经经销商审核后, 方可办理退换货。

三包凭证

产品信息:
产品型号: _____ 订单编号: _____
用户信息:
用户姓名: _____ 联系电话: _____
用户地址: _____
退换货原因: _____
购买信息:
销售单位: _____

FAQ

- 1.Q: 只有一只耳机有声音怎么解决?
A: 将两只耳机放回充电盒关机, 再重新取出, 查看双耳是否有声音, 若还是只有单耳耳机有声音, 请对两只耳机重新出厂设置。
- 2.Q: 手机提示无法连接怎么解决?
A: 将手机上的配对记录删除, 删除后重新进行搜索配对连接即可。
- 3.Q: 听歌/通话没声音怎么解决?
A: 安卓手机在蓝牙连接名字的右边有个设置图标, 点击进入, 关闭手机音频和媒体音频, 再重新开机, 若还是无声, 请将耳机重新与手机配对连接。
- 4.Q: 为什么电脑/游戏有延迟?
A: 受使用环境、网络、手机编解码等因素的影响, 会引起手机传送音频数据到耳机时有不同程度的延迟。
- 5.Q: 听到的声音卡顿/断线怎么解决?
A: 在使用时若周围有大量的Wi-Fi、5G/4G信号、大功率电器等等产生干扰, 可能会引起卡顿、断线的情况, 换个环境或者重新配对连接就可以解决了。

若有售后服务需求, 请联系客服
电话: 4008-3056-708 网址: www.qcy.com
制造商: 东莞市乐电电子有限公司
地址: 广东省东莞市道滘镇粤晖路325号

产品中有害物质的名称及含量

部件名称	有害物质									
	Pb	Hg	Cd	Cr VI	PBB	DEHP	DBP	BBP	BBP	BBP
耳机主体	X	O	O	O	O	O	O	O	O	O
电 池	O	O	O	O	O	O	O	O	O	O
耳 塞	O	O	O	O	O	O	O	O	O	O
配 件	O	O	O	O	O	O	O	O	O	O
充 电 线	X	O	O	O	O	O	O	O	O	O

本表格依据SJ/T 11364的规定编制
O: 表示该有害物质在部件所有均匀材料中的含量均在(EU)2015/863规定的限量要求以下。
X: 表示该有害物质在部件所有均匀材料中的含量超过(EU)2015/863规定的限量要求, 但目前行业无成熟的替代方案, 在豁免范围内符合欧盟RoHS指令的环境要求。

使用指南
如本手册所述, 在正常使用条件下, 本产品的环保使用期限为10年。在此期间, 产品不会释放任何有害物质, 本产品可以回收, 必须按照当地法规处理。



提示

1. 使用产品前请仔细阅读本使用说明书并妥善保管;
 2. 首次使用时, 请先将本产品充满电;
 3. 如果产品长期(超过2个星期)不用, 请将其充电;
 4. 必须选择正规厂家生产且经过国家CCC认证的充电器;
 5. 若手机无法检测到蓝牙耳机, 请将蓝牙耳机重新进入配对模式或将蓝牙耳机恢复出厂设置, 若手机程序出错, 请把手机蓝牙关闭再开启或重启手机。
- 请勿以任何理由拆毁或修改耳机, 否则可能会导致起火、电子击穿甚至彻底损坏本品;
· 请勿将产品置于温度过低或过高(0°C以下或45°C以上的环境下);
· 请勿靠近儿童或宠物; 请勿将本产品指示灯;
· 请勿在恶劣天气下使用本产品, 雷暴可能导致本产品工作不正常, 并增加触电的危险;
· 请勿用油及其他挥发性液体擦拭本产品;
注意: 长时间使用耳机可能会导致听力损害, 请合理安排使用时间。

反面




BH22QT15A

Open Truly Wireless Earbuds




For better using experience, please scan to download QCY app before start-up.

Overview




Above pictures are for reference only yet practical accessories may vary.

How to Wear



How to Connect

Open lid and pick up earbuds to power them on. On phone, search "QCY Crossky GTR" and tap to connect. Earbuds will auto reconnect to the last device in connectivity records, if any.




One Press to Turn Connectable

1. Earbuds have been connected to phone.
2. Push earbuds into case, open case and keep pressing button on case for 3s or until LED turns solid white. Pick up earbuds again to turn them connectable to phone.

Factory Setting


Push earbuds into case and keep pressing button on case for 10s or until LED blinks while 5 times to reset and power on earbuds.



LED on Case
(Open lid or press button on case)
LED turns on white for 5s: middle or high battery
LED turns on red for 5s: low battery

LED will glow solid red when case is charging and turn white once it is topped up.

Instructions



- ① Power-on: keep touching the panel for 1.5s
- ② Power-off: push earbuds back in case
- ③ Answer/end call: double touch the panel
- ④ ignore call: keep touching the panel for 1.5s
- ⑤ Skip track backward: keep touching left panel for 1.5s
- ⑥ Skip track forward: keep touching right panel for 1.5s
- ⑦ Voice assistant: triple touch left panel
- ⑧ Playback/pause: double touch the panel
- ⑨ Low latency mode: triple touch right panel

Warranty Card

Warranty Period
12 months after you purchase this item for you may inquire your local shopper for more details.
Free Service:
Supposing any defects caused by quality issues occur within the warranty period, please take this warranty card and purchase receipts to your distributor for free exchange service.

Model Number:	
Date of Purchasing:	
User's Name:	
User's Phone:	
User's Address:	
Shop's Name:	
Shop's Address:	
Comments:	

Free exchange service will not be accessed under following circumstances:
1. Damages caused unauthorized disassembly;
2. Defects or physical damages caused by leaking or dropping off;
3. Damages by act of God. Supposing your item is within any damages or defects except the above circumstances, please return to us or your distributor for free repairing.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
--Reorient or relocate the receiving antenna.
--Increase the separation between the equipment and receiver.
--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
--Consult the dealer or an experienced radio/TV technician for help.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
FCC ID: RDR-BH22QT15A
FCC ID: RDR-BH22QT15AL

Hazardous substances and their contents in the item

Part Name	Hazardous Substances									
	Pb	Hg	Cd	Cr VI	PBB	DEHP	DBP	BBP	BBP	BBP
Main body	X	O	O	O	O	O	O	O	O	O
Battery	O	O	O	O	O	O	O	O	O	O
Ear tips	O	O	O	O	O	O	O	O	O	O
Accessories	O	O	O	O	O	O	O	O	O	O
Charging cable	X	O	O	O	O	O	O	O	O	O

The form is made by SJ/T 11364 regulation.
O: means that hazardous substance content in the homogeneous materials of this part is within the limits of EU 2015/863 regulation.
X: means that hazardous substance content in, at least, one certain homogeneous material of this part is beyond the limits of EU 2015/863 regulation, but there is no mature alternative in the industry at present, it still conforms to the EU RoHS Directive in the scope of exemption.

Notes: Please arrange using time properly as your hearing may be damaged by using the device for a long time.
Manufacturer: Dongguan Hale Electronics Co., Ltd.
Address: No. 325 Yushu Rd, Dapeng Town, Dongguan City, Guangdong Province, China



Tips

1. Before using the earbuds, please read the manual carefully and keep it for future references.
2. The earbuds need to be fully charged prior to first-time use.
3. If the earbuds are left unused for over two weeks, please recharge.
4. Please use the chargers made by qualified manufacturer.
5. If earbuds fail to be found by phone, please re-turn them connectable or restore factory settings. If a program error or phone occurs, please turn off and on Bluetooth function or reboot the phone.

Caveats

1. Never disassemble or modify your earbuds for any reasons to avoid any damages and danger.
 2. Do not store the earbuds in extreme temperatures (under 0°C or over 45°C).
 3. Avoid using the indicator close to the eyes of children or animals.
 4. Do not use the earbuds during a thunderstorm to avoid dysfunction and increasing risk of electrocution.
 5. Do not use harsh chemicals or strong detergents to clean the earbuds.
- Note: please do not use earbuds for a long time as may damage your hearing.

80g哑粉过哑油 97x65.5mm