


80 mm

55 mm



切换设备配对方法：

1. 关闭A手机蓝牙，耳机自动断开进入配对模式。
2. 刷新B手机蓝牙设备列表，点击配对IQ(Y-H)。

*不支持同时连接两手机。下次开机默认连接。

【配型】此方法适用于无法正常连接的情况)
有连接过手机。在手机蓝牙设备列表中，找到“CF-H710”进入设置。选择忽略或取消配对。
关机状态下。（适用于蓝牙耳机初次使用时）长按多功能键，红白灯同时闪烁3次后关机。则表示耳机重置成功。
发出出厂前预配对的方法选择即可正常使用。

1. 将耳模向下轻轻塞入耳道，以轻轻头部耳模不晃动为宜

2. 通话时，微张口来气，侧向咽喉部，使呼吸顺畅

1.3 开机状态下, 将主机与有源设备连接(见图 1)。任一耳机长期处于非工作状态时, 进入配对状态(见 4.1.4.4)

2. 打开手机蓝牙搜索配对, 选择 QY-H-T101C 作为连接。

3. 连接完成

给耳机电池充电

当耳机进入充电, 当耳机进入充电状态, 充电时红灯常亮, 其亮度与耳机充电量成正比。

给充电盒充电

当充电盒进入充电, 充电时指示灯显示如下:

充电时两个指示灯常亮

充电时两个指示灯常亮

充电盒电量显示

当充电盒进入充电, 当充电盒电量只能给耳机充电一次时, 左边指示灯常亮(指示灯常亮); 当充电盒电量可以给耳机充电两次时, 左边指示灯常亮; 当充电盒电量给耳机充电次数大于两次时, 左右指示灯常亮。

耳机型号: h3211A

耳机型号: L8 1240

充电盒电池型号: 102523

耳机电池容量: 50mAh

充电盒容量: 600mAh

耳机输入: $5V \sim 150mA$

充电盒输入: $5V \sim 600mA$

QCY藍牙耳機售後服務

[illegible][illegible][illegible][illegible]

提示

1. 使用本品前請詳細閱讀本產品說明書並請妥善保存；
2. 切勿自行拆卸、修理本品或更換產品零件；
3. 如果產品出現問題，請立即關閉電源，並請與售後服務；
4. 必須確保正確安裝及正確使用，並請遵照CCC認證的說明書；
5. 請勿將本品與水接觸，請勿將本品與火源或高壓電等“危險物”靠近，並請勿自行修理或更換零件。當遇到故障可以聯絡售後服務，並請將故障現象詳細描述“故障現象”、“使用環境”及“故障現象”；
6. 請勿將本品與火源或高壓電等靠近，並請將本品與火源或高壓電等分開。

警告

1. 切勿在存在任何可燃物或腐蝕性氣體環境，否則可能會導致起火或爆炸，導致人身傷亡或財產損失。

2. 切勿將本品置于“溫度低於攝氏（0）度以下或45℃以上的環境下。

3. 切勿將本品與兒童或寵物接觸，並請將本品與兒童或寵物分開。

4. 切勿在安裝及修理本品時使用油類、塗料、清潔劑或清潔用品工作不當，並請將環境清潔。

5. 切勿將本品與具有爆炸性物質或燃性物質混合。

注意


1. 在遇到任何故障時可以尋求售後服務人員，請與售後服務人員聯繫。

2. 本耳塞不持有任何專利權，本耳塞與電腦設備無關，若有故障請與電腦廠家。

330 mm

80mm

55mm



Pairing records
 Use try the following steps if earbuds fail to connect to cellphone, delete the connectivity records of QCW100 earbuds, hold MFBs for 10s or until LEDs blink red while 3 times to set earbuds to factory or factory setting, please refer How to Pair to build in connection with cellphone.

1. Rotate earbud and pop it into your ear then shake head to check wearing stability.

2. Please adjust mic towards your mouth to gain better calling experience.

Three-way calling and switch

Double press MFB to answer incoming call. If another call coming in sync, double press MFB to put the first call on hold while activating the second call or hold MFB to ignore the second call. Hold MFB for 1.5s to switch between hold call and active call.

1. Power off earbuds/you were paired with each other before, keep touching WFB on earbuds for 5s to enter pairing mode(LED blinks white).

2. On cellphone, search for QCYW702C and tap to connect.

Charging earbud

Push earbuds into case and earbuds will auto get charged. LEDs will glow solid red when charging and turn white for 1 minute once topped up.

Charging case

Please charge the case via USB cable.

Two LEDs blink white when charging.

Two LEDs glow solid white once topped up.

LEDs on charging case

Open or close lid, left LED on case breathes white if the case can only offer one touchp, the left LEDs glow white if the case can offer two touchp and two LEDs glow solid white if the case can offer more than two touchp.

Functions	Current status	Operation/result	LED	Prompt
Power-on	Powerwell	Model MF00 3s	LED glows white for 3s	power on
	Charging	Open lid	LED glows red	
Power-off	Powerwell	Push enter into case and close lid	LED glows red for 3s	power off
	Model MF00	Model MF00 3s		
T5's parking	First parking factory setting	1. Left wheel can't turn accessible to phone 2. Right wheel can't turn right 3. Left wheel can't turn left if they both go 4. Right wheel can't turn right if they both go 5. Right wheel can't turn left if they both go	LED Blink red and white	TOPE
	Answer/call call	Doubles MF00 3s		TOPE
Ignore call	Incoming call	Doubles MF00 3s		TOPE
Voice assistant	Connected	Triple press left MF00		TOPE
	Factory setting	Hold MF00 3s and out of case	LED Blink red and white 1 time	TOPE
Music player	Playing	Doubles MF00 3s		TOPE
	Music player	Model MF00 3s		TOPE
Skip track forward	Playing	Model MF00 3s		TOPE
	Model MF00	Model MF00 3s		TOPE
Switch call to external	Call handled by phone	Put on external car kit		TOPE
Switch call to phone	Call handled by car kit	Take off car kit, car kit		TOPE
Gaming mode	Connected	Triple press left MF00		TOPE
	Switching mode	Connected (no calling)	Model MF00 3s	TOPE

Warranty Period
12 months after you purchase this item (or you may inquire with your local shopper for more details.)

Free Service:
Supposing any defects caused by quality issues within the warranty period, please take this card and purchase receipts to your distributor for exchange service.

Model Number:
Date of Purchasing:
User's Name:
User's Phone:
User's Address:
Shop's Name:
Shop's Address:
Comments:

Free exchange service will not be accessed under the following circumstance:

1. Damages caused by unauthorized disassembly
2. Dropping or physical damages caused by user's defects or fall
3. Damages by act of God. Supposing any damages or defects except the above circumstances return to us or your distributor for free.

Part Number	Pb	Cr	Cd	Co	Ca	Al	Br	Bi	Be	Ba	As	Ag	Au	At	Am
Main body	X	O	O	O	O	O	O	O	O	O	O	O	O	O	O
Printed	X	O	O	O	O	O	O	O	O	O	O	O	O	O	O
Accessories	X	O	O	O	O	O	O	O	O	O	O	O	O	O	O
Chassis	X	O	O	O	O	O	O	O	O	O	O	O	O	O	O

This form is made by SJ/T 11364 regulation.

① means that hazardous substance content in the homogeneous materials of this part is within the limits of (EU) 2015/863 regulation.

② means that hazardous substance content in at least one of the homogeneous materials of this part is beyond the limits of (EU) 2015/863 regulation. But there is no mature alternative in the industry at present, it still conforms to the EU RoHS Directive in the absence of exemption.

Notes: Please arrange using this property as your best may be damaged by using the device for a long time.

Manufacturer: Dongguan Heli Electronics Co., Ltd.
Address: Daoqiao Town, Dongguan City, China

2. The headset need to be fully charged prior to first-time use.
3. If the headset is left unused for over two weeks, please recharge it periodically.
4. Please use the chargers made by qualified manufacturer.
5. If the headset cannot be found by your phone, please check whether it is in pairing mode. If left unconnected for a long while, the headset will exit pairing mode. Please re-enter the mode if a procedure error of your phone occurs, or reset it. If a procedure error of the headset occurs, reboot or reset it.

Caveats

1. Never disassemble or modify your headset for any reasons to avoid any damages and danger.
2. Do not store the headset in extreme temperatures (under 0°C or over 45°C).
3. Avoid the indicator close to the eyes of children or animals.
4. Do not use this headset during a thunderstorm to avoid lightning and increased risk of electrocution.
5. Do not use harsh chemicals or strong detergents to clean the headset.
6. Keep the headset dry.

330mm