






How to Wear



Adjust Mic towards your mouth.

Stereo Mode



Power off earphones then touch their Touch Bars for 5s or until LED blinks red and white with voice prompt to enter pairing mode.

1. TWS Mode: on cellphone, search for QCY-T3_L and tap to connect the master EarBud(left). Then your cellphone will receive a connecting request from slave EarBud(right), tap to accept it.(LED glows solid white for 2s)
2. TWS+ Mode: on cellphone, search for QCY-T3_L and tap to connect the master EarBud(left) and the slave EarBud will auto connect then.(Note: TWS+ mode is only available for cellphone with a Snapdragon 845 or newer chipset and Adroid v9.0.)

Stereo Mode

Power-on

Touch the Touch Bar for 1s to power on
(LED will glow solid white for 1s)
When charging, open the charging case's lid to power on
(LED will glow solid white for 1s)

Power-off

Touch the Touch Bar of either EarBud for 3s to power off
that EarBud(LED glows red for 2s)
Put EarBud into the case and close the lid.


Volume Control

Volume Up: when playing, slide up on the Touch Bar of
the left EarBud
Volume Down: when playing, slide down on the Touch Bar
of the left EarBud

Skip Track Forward/Backward

When plying, slide down/up on the Touch Bar of right
EarBud to skip track forward/backward.

Playback in Stereo Mode




Playback/pause

When playing in stereo mode, double click Touch Bar on
either EarBud to pause music and double click again to
resume playing.

Reconnecting

Double click Touch Bar of either EarBud to reconnect it to
cellphone(LED glows white for 1s with voice prompt)
When two EarBuds in the case, open the lid and earphones
will auto reconnect to cellphone in 5s
(two EarBuds need to be connected)
Note: earphones will auto enter pairing mode, if they fail
to reconnect in 5s

Mono Mode




1. Power off earphones, then touch the Touch Bar on either EarBud for 5s to enter pairing mode(LED will blink red and white)
2. On cellphone, search for the EarBud(QCY-T3_R/L) and tap to connect.
3. Pairing completed.

Mono Mode


Power-on

Touch the Touch Bar for 1s to power on
(LED will glow solid white for 1s)
When charging, open the case's lid to power on the EarBud
(LED will glow solid white for 1s)




Power-off

Touch the Touch Bar for 3s to power off.(LED glows red for 2s)
Put EarBud into the case and close the lid.




Ignore Call

Touch the Touch Bar for 1s to ignore incoming call.




Answer Call

Double click Touch Bar to answer incoming call and double click again to end it.




Playback/pause

When playing, double click Touch Bar to pause and double click again to resume playing.




Volume Control

When playing, slide up/down on Touch Bar to tune volume up/down.



Charging the Earphones


LEDs on EarBuds will glow solid red when charging and turn white for 10s once topped.



Put EarBuds into the case to charge (pogo pins need to be well-contacted).

Charging the Case

All LEDs on the case will glow solid green once the case is topped up.



Charge the case via USB cable.

Features

-  Up-to-date BT v5.0 chipset delivers signals stably with no lag
-  Touch control is easy to use
-  Noise isolation technology makes stereo talking crystal clear

产品参数

Model: In1832
BT version: V5.0
Standby time: approx. 150hr
Charging time: approx. 2hr
Music time: approx. 5 - 6hr
Operation range: 10m(with no obstacle)
Battery type: li-ion
Battery capacity(earphones): 3.7V 50mAh
Battery capacity(charging case): 3.7V 600mAh
Input parameter(charging case): 5V 500mA
BT profiles: HSP/HFP/A2DP/AVRCP
(All technical data shall be subject to practical performance)



Hazardous substances and their contents in the item

Part Name	Hazardous Substances					
	(Pb)	(Hg)	(Cd)	(Cr(VI))	(PBB)	(PBDE)
Main body	X	○	○	○	○	○
Battery	○	○	○	○	○	○
Ear tips	○	○	○	○	○	○
Accessories	○	○	○	○	○	○
Charging cable	X	○	○	○	○	○

This form is made by SJ/T 11364 regulation.
○: means that hazardous substance content in the homogeneous materials of this part is within the limits of GB/T 26572 regulation.
X: means that hazardous substance content in, at least, one certain homogeneous material of this part is beyond the limits of GB/T 26572 regulation.

Notes: Please arrange using time properly as your hearing may be damaged by using the device for a long time.

Perform standard: Q/HL 1-2016 ; Q/HL 2-2017
Manufacturer: Dongguan Hele Electronics Co., Ltd.
Address: Daojiao Town, Dongguan City, Guangdong, China

Tips

1. Before using the headset, please read the manual carefully and keep it for future references.
2. The headset need to be fully charged prior to first-time use.
3. If the headset is left unused for over two weeks, please recharge it periodically.
4. Please use the chargers made by qualified manufacturer.
5. If the headset cannot be found by your phone, please check whether it is in pairing mode; if left unconnected for a long while, the headset will exit pairing mode, please re-enter the mode; if a procedure error of your phone occurs, reboot it; if a procedure error of the headset occurs, reboot or reset it.

Caveats

1. Never disassemble or modify your headset for any reasons to avoid any damages and danger.
2. Do not store the headset in extreme temperatures (under 0°C or over 45°C).
3. Avoid using the indicator close to the eyes of children or animals.
4. Do not use this headset during a thunderstorm to avoid irregular function and increased risk of electric shock.
5. Do not use harsh chemicals or strong detergents to clean the headset.
6. Keep the headset dry.

FCC COMPLIANCE STATEMENT:
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Warranty Card

Warranty Period

12 months after you purchase this item.(or you may inquire your local shopper for more details.)

Free Service:

Supposing any defects caused by quality issues occur within the warranty period, please take this warranty card and purchase receipts to your distributor for free exchange service.

Model Number:
Date of Purchasing:
User's Name:
User's Phone:
User's Address:
Shop's Name:
Shop's Address:
Comments:

Free exchange service will not be accessed under following circumstances:

1. Damages caused unauthorized disassembly.
2. Defects or physical damages caused by leaking or dropping off.
3. Damages by act of God.Supposing your item is within any damages or defects except the above circumstances, please return to us or your distributor for free repairing.