

***Radiated Emissions Test Configuration – Transmit Mode***



## ***Radiated Emissions Test Configuration – Transmit Mode***



## ***Radiated Emissions Test Configuration – Digital Device***



## ***Radiated Emissions Test Configuration – Digital Device***



## ***Conducted Emissions Test Configuration***



## ***Conducted Emissions Test Configuration***

