



MOTORWORKS™

1:18 Radio Control Car

NASCAR

OWNER'S MANUAL

Please read carefully before operating your vehicle. Keep these instructions for future reference as they contain important information

FORD and TAURUS trademarks used under license from Ford Motor Company.

CHEVROLET, CHEVY, CHEVY RACING, TEAM MONTE CARLO, Chevrolet Red Bow Tie Emblem,

MONTE CARLO, and all emblems and related stock car body designs are General Motors

Trademarks used under license to Team Caliber, Inc.

©DaimlerChrysler Corp.2001

NASCAR® is a registered trademark of the National Association for Stock Car Auto Racing, Inc.

© 2004 Team Caliber, Inc.

Motorworks™ is a registered trademark of Wal-Mart Stores, Inc.

Other trademark usages are licensed by trademark holder. All logos are used under license.


CAUTION- ELECTRIC TOY:

Not recommended for children under 8 years of age. As with all electrical products, precautions should be observed during handling and use to reduce the risk of electric shock.


ATTENTION PARENTS:

It is recommended that this toy and all accessories be periodically examined for potential hazards and that any potentially hazardous parts be repaired or replaced.


Replacement or spare 6.0V battery packs and other accessories can be purchased by visiting your local Wal-Mart store.




Charger




Transmitter



Alkaline Battery Pack



6V Ni-Cd Battery Pack



Car Body

Marketed by Wal-Mart Stores, Inc.
Bentonville, AR72716
Shop at www.walmart.com

MADE IN CHINA

Radio Control Car
Sheet




1

CHARGE

IMPORTANT: 6V Ni-Cd Battery Pack is not charged when newly purchased-charge before using.

1. Insert battery pack into the charger as shown.
2. Plug the charger into a standard 110/120V electrical outlet.
3. Charge for approximately 8 hours for the first charge. Subsequent recharges require only 4-6 hours.
4. Unplug the charger from the outlet and remove the battery pack from the charger.

NOTE: Do not pull on wires, as they may come loose from the plug connectors.



2

FCC NOTES

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference,
2. This device must accept any interference received, including interference that may cause undesired operation of the device.

CAUTION: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



3

SAFETY

- Do not operate during thunderstorms.
- Avoid water, sand, and snow when operating your vehicle. In addition, do not submerge your vehicle or controller in water.
- Never operate your vehicle on the street or highway.
- Never operate your vehicle in a confined or crowded area, and do not use people or animals as obstacles.
- Do not run your vehicle into furniture, objects or hard surfaces, as this will cause damage to both the objects and the vehicle.
- Keep fingers, hair, and loose clothing away from the tires, gears, and motor while the vehicle is switched ON.
- Do not leave vehicle or controller near sources of heat or under direct sunlight for long periods of time.
- Do not leave vehicle or controller outside overnight- dampness is harmful to interior components.
- Remove all batteries when not in use to avoid accidental operation.

Adult supervision is recommended when operating this vehicle.



4

BATTERY PRECAUTIONS

THIS PRODUCT USES A NICKEL-CADMIUM RECHARGEABLE BATTERY PACK- BATTERY MUST BE RECYCLED OR DISPOSED OF PROPERLY.

- Batteries should be inserted with the correct polarity.
- Do not short circuit battery contacts.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- Remove batteries if vehicle will not be used for a long period.
- Check the batteries regularly for leakage.
- Exhausted batteries should be removed from the charger.
- Do not dispose batteries in a fire- batteries may leak or explode.
- Use only the recommended batteries or batteries of equal quality/type.

- Do not recharge non-rechargeable batteries.
- Remove battery pack from vehicle before recharging.
- Do not pull on wires when detaching the battery pack plug/connector.
- Do not recharge warm or hot battery packs- wait until pack has cooled.
- Do not overcharge - this may damage the battery pack.
- Recharging too early will shorten battery pack life.
- Do not recharge batteries that show wear or leakage.
- Do not recharge in high temperatures or bring the battery pack near a flame.
- Do not let the charger or battery pack get wet or damp.
- Do not take the charger or battery pack apart.
- Rechargeable batteries should always be charged under adult supervision.

BATTERY PERFORMANCE NOTE:




For best performance use alkaline batteries. If your vehicle is supplied with standard (carbon-zinc) batteries for initial use and/or demonstration purposes, we recommend replacing them with alkaline batteries when necessary. Battery life may vary depending on battery brand.



5

ALKALINE BATTERY PACK OPTION


1. You can use alkaline batteries as the power source for the car instead of the 6V Ni-Cd Rechargeable Battery Pack. Insert five AA alkaline batteries into the battery magazine included in the package. The Alkaline Battery Magazine will work the same way as the rechargeable battery pack. **DO NOT PLACE THE MAGAZINE IN THE Ni-Cd BATTERY CHARGER AS DAMAGE TO THE BATTERY MAGAZINE, CHARGER, OR FIRE MAY OCCUR.**




6

SET-UP


1. Remove the battery cover on the bottom of the transmitter and insert 9V battery to the wire plug. Insert battery into compartment and replace the battery cover as shown.



2. Remove the battery cover on the bottom of the car. Install either the 6V Ni-Cd Battery Pack or Alkaline Battery Pack into the battery compartment and replace the battery cover as shown.



3. Move the power switch on the car to the "ON" position.



Radio Control Car




7


START YOUR ENGINES!

1. Place car on smooth, flat surface and extend antenna fully.
2. To move car forward and backward in a straight line, move the left lever up and down.
3. To turn left or right while moving forward, move the right lever side to side while holding the left lever up.

NOTE: For maximum performance, hold the transmitter upright so the antenna points up (do not point the antenna at the car- this will reduce the signal range).



5. Adjust the steering alignment lever located on the bottom of the car if the car does not run straight when moving forward (refer to drawing on opposite page for location of steering alignment lever).



8

TROUBLESHOOTING

PROBLEM

PROBABLE SOLUTIONS

Car does not move or run slowly	• Make sure power switch on vehicle and transmitter are in the ON position • Make sure the batteries in the vehicle and transmitter are installed properly • Recharge vehicle's NiCd battery pack or replace if necessary • Replace 9V battery in transmitter with fresh battery
Car moves erratically or transmitter range is short	• There is radio interference in the area- change locations • There is another R/C vehicle operating on the same frequency near by-move away from any other vehicle operating on the same frequency • Make sure antenna in transmitter is screwed in tight and fully extended • Make sure transmitter battery connections are in good condition and replace battery
Car does not work after going through water or snow	• Allow car to dry thoroughly overnight • Avoid driving in water or snow