

2003 WM Radio Control Car
Instruction Sheet

#TAB **Front**
(Revision 01)
21-10-2003




1. Place two "AA" alkaline batteries into charger unit and replace battery cover.



2. To charge the car, align metal nodes on charger unit with the nodes on the car's and place car onto charger unit.
The charging indicator light will come on when car is charging and will turn off when a full charge is reached (approx. 60 seconds)



3. Place two "AA" alkaline batteries into control unit.
The control unit allows for fully directional control by pushing the forward and reverse buttons. The car will turn left or right when the left of right buttons are pushed. The car will only turn or right when moving in forward or reverse direction. The operating light will come on while the car is in use. When the light becomes faint, it is time to replace the batteries. While operating the car make sure the antenna is fully extended.



4. Occasionally, the car will not travel in a straight line. You can adjust the trim by using the directional guide on the bottom of the car as shown in the illustration. The may need to be done a few times for tuning the direction in order to enable the car to run properly.



5. For best results, operate on a smooth dry surface. Radio waves control this toy and can easily be interrupted. Avoid using near cell phones, electrical lines or CB's.

6. The manufacturer is not responsible for radio or TV interference caused by unauthorized modification of this equipment.
Such modifications could void the user's authority to operate the equipment.

Made by: Wei-Ming Sheng, Inc.
Bentonville, AR 72716
Shop at www.walmart.com

MADE IN CHINA

130mm

160mm

130mm

160mm

Back

This equipment has been tested and found to comply with limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio /TV technician for help.
- The packaging has to be kept since it contains important information.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference; and (2) This device must accept any interference received, including interference that may cause undesired operation.

WARNING!
Changes or modifications to this unit not expressly approved by party responsible for compliance could void the user's authority to operate the equipment.