


**Congratulations on purchasing your new Acoustic Research High Resolution Music Player.**

Please read these instructions for quick tips on using the Player.

## Getting Started

1. Charging your Player with provided AC/DC adapter
  - Connect the USB port of the included AC/DC power adapter to the Player
  - Plug the other end of the adapter to any standard 100-240V AC wall outlet. Charging should be started automatically
  - It should be **charged for at least 6 hours** before using for the first time
  - Alternatively, the Player charges automatically every time you connect it to your computer. Charging process may be slower and the charging time depends on the current output of the USB port



2. Install or remove microSD card
  - Open the protection cover of the microSD expansion slot. Gently insert a microSD card\* into the microSD expansion slot. Close the protection cover
  - Before removing a microSD card, tap on **SD card connected - Touch to unmount sdcard** on the notification bar. After that, open the protection cover and gently push the card to release it

\* Up to 128 GB microSD card is supported

v1.0 (1.0.0.0) (EN)

3. Transfer audio files to your Player
 

**Windows 7/Windows 8:**

  - Connect your Player to the computer
  - Open **Windows Explorer**, select **Computer**, open **AR-M2** under Portable Devices
  - Open the desired storage media **Internal SD card** or **SD card** (Optional, only if microSD card is installed)
  - Drag-and-drop audio files (or folders containing audio files) to the desired destination\*\*




**Mac OS X (10.5 or above):**

- Download and install **Android File Transfer** from [www.android.com/filetransfer/](http://www.android.com/filetransfer/) (First time installation only)
- Connect your Player to the computer
- Run Android File Transfer if it does not pop up automatically
- Select the desired storage media by clicking on the tab **Internal SD card** or **SD card** (Optional, only if microSD card is installed)
- Drag-and-drop audio files (or folders containing audio files) to the desired destination\*\*

4. Disconnect the Player from the computer and enjoy media on the go.
5. The device can be used on the hand, also can be used in the pocket.

\*\* Music files are automatically organized under different views according to embedded music tags in

## General controls



|                                                    |                                                                                                                                                          |
|----------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------|
| Switch on the Player                               | Press and hold the <b>Power</b> button for 3 seconds.                                                                                                    |
| Switch off the Player                              | Press and hold the <b>Power</b> button for 3 seconds. Select Power off.                                                                                  |
| Switch off the display and lock the touch display  | When the display is on, press the <b>Power</b> button. The display will also switch off automatically after a period of inactivity (1 minute by default) |
| Switch on the display and unlock the touch display | When the display is off, press the <b>Power</b> button. Swipe the lock icon towards any edges of the screen.                                             |
| Go to the Home screen                              | Tap on the Home icon to reached the Home screen                                                                                                          |
| Go to the APPS menu                                | At Home screen, tap on the APPS icons at the lower right corner                                                                                          |

|                                                     |                                                                                                                                |
|-----------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------|
| Navigate to an audio file                           | In APPS menu, tap on <b>AR Music Player</b><br>In AR Music Player, tap on your desired view by selecting the corresponding tab |
| Play an audio file                                  | Tap the music file in any view                                                                                                 |
| Pause playback                                      | Press the <b>Play/Pause button</b> during music playback, press again to resume.                                               |
| Show the Option menu                                | In any navigation view, tap and hold at any media item                                                                         |
| Adjust the volume                                   | Rotate the volume knob clockwise to reduce the volume or counter clockwise to increase it.                                     |
| Skip to the next file                               | Press <b>▶▶</b> .                                                                                                              |
| Skip to the previous file                           | Press <b>◀◀</b> within the beginning 4 seconds of the current audio file.                                                      |
| Delete files from the Player                        | Tap at the file and hold until the option menu appear<br>Select <b>Delete</b> and confirm the action                           |
| Force shutdown the Player (if it is not responding) | Press and hold Power button for 10 seconds to force shutdown the Player.                                                       |

**Need more help?** Do not return this product to the store.  
Visit [www.acoustic-research.com](http://www.acoustic-research.com) for the latest firmware, user manual and FAQ's.



For Customer Service  
Visit Our Website At  
[www.acoustic-research.com](http://www.acoustic-research.com)  
Product Information, Photos,  
FAQ's, Owner's Manuals

©2015 VOXX Accessories Corporation  
A wholly-owned subsidiary of VOXX  
International Corporation  
Indianapolis, IN  
Trademark Registered  
Printed in China

**FCC Caution:**

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Specific Absorption Rate (SAR) information**

SAR tests are conducted using standard operating positions accepted by the FCC with the device transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value, in general, the closer you are to a wireless base station antenna, the lower the power output.

For body worn operation, this model device has been tested and meets the FCC RF exposure guidelines that positions the handset a minimum of 5mm from the body.

Non-compliance with the above restrictions may result in violation of RF exposure guidelines.

## IC Warning

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

*Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement*

## IC SAR Waring

The device has been tested and compliance with SAR limits, users can obtain Canadian information on RF exposure and compliance

The minimum distance from body to use the device is 5mm.

Le présent appareil est conforme

Après examen de ce matériel aux conformité aux limites DAS et/ou aux limites d'intensité de champ RF, les utilisateurs peuvent sur l'exposition aux radiofréquences et la conformité and compliance d'acquérir les informations correspondantes

La distance minimale du corps à utiliser le dispositif est de 5mm.

### 7.1.4 Radio Apparatus Containing Digital Circuits (ICES-003)

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.