

CONTENTS:

- 5-Button iPod Remote Control
- Wireless iPod Receiver
- Universal Car iPod Mount
- Jaw Hooks, Air Vent Clips and Dashboard Mounting Kit
- Steering Wheel (or Handlebar) Remote Mount (Includes Steering Wheel Adjustment Pads)
- Wheel Mount Adjustment Tool
- Wristband Remote Mount
- Car Stereo Cassette Adaptor

CONTENU:

- Télécommande iPod à 5 boutons
- Récepteur sans fil pour iPod
- Fixation auto universelle pour tout iPod (avec agrafes de bonche d'air et montage sur tableau de bord)
- Montage de télécommande sur volant (ou guidon) (avec cales d'ajustement)
- Outil de serrage pour montage sur volant
- Bracelet pour télécommande
- Cassette adaptatrice auto radio


Wireless Mobile Remote Kit™

NYKO®

Everything you
need to wirelessly
control your iPod



for/pour
iPod®



Wireless Remote Control Kit for
Car, Home or On the Go

Kit Télécommande sans fil pour la
Voiture, à la Maison ou sur l'Aller

05 AUG 2005
No 4 24 6 5

FRONT Nyko Technologies, Inc. – Item # 88030 – "Wireless Mobile Remote Kit" for iPod – Instruction Manual BACK (French/Spanish) – Version 1 – May 25, 2005

WIRELESS MOBILE REMOTE KIT for iPod Item: 88030

Thank you for purchasing the Wireless Mobile Remote Kit, compatible for use with all full size iPods. Please review the instructions below to ensure proper installation and use of the product.

INSTALLATION
STEERING WHEEL MOUNT

Your Wireless Mobile Remote Kit includes a unique mount designed to attach to the inside of your car's steering wheel, enabling you to control your iPod without removing your hands from the steering wheel. The Steering Wheel Mount is adjustable to attach securely to most common automobile steering wheels. Additional custom pads are included for custom mounting to smaller diameter steering wheels.

To attach the Steering Wheel Mount:

1. Begin by unscrewing the centrally located hex screw. Please use the included Wheel Mount Adjustment Tool (Diagram 1).
2. Once the screw is loosened you can place the mount at a preferred position on your steering wheel with the circular Remote Control Unit easily facing the driver. We recommend a location that does not conflict with your normal grasp of the steering wheel.

IMPORTANT: The Steering Wheel Mount should be attached so that the Wireless Remote Unit is positioned on the steering wheel's RIM, NOT ONLY (Diagram 2).

3. Once you have selected the desired position on the steering wheel, tighten the mount screw using the included Wheel Mount Adjustment Tool.
- NOTE:** If the screw has been fully tightened but the diameter of your steering wheel is too small to hold the mount properly, you will need to use one or more of the included custom pads. Return to Step 1 and add one or two custom pads to the inside of the Steering Wheel Mount as required to securely attach the mount to the steering wheel (Diagram 3).
4. Press the Remote Control Unit into the circular cavity on the Steering Wheel Mount until it clicks into place. The Remote Control Unit will rotate so that the buttons are aligned to the mount position on the steering wheel (Diagram 4).
5. To remove the Remote Control Unit, simultaneously press the two buttons on opposite sides of the mount.

NOTE: Share the Wheel Mount Adjustment Tool in a safe location for future use.

Attaching the Wireless Remote Receiver to your iPod:

In order to control the iPod using the Remote Control Unit you will need to attach the included Wireless Remote Receiver to the top of your iPod. With the Nyko logo facing in the same direction as the front of the iPod, gently press the Receiver unit down into the iPod's headphone and remote jacks (Diagram 5).

IMPORTANT: When attaching the Wireless Remote Receiver, do NOT use force.

The receiver is designed to attach easily to the iPod. No force is necessary.

WIRELESS REMOTE FUNCTION AND FEATURES:

PLAY/PAUSE BUTTON: Press this button to Play or Pause the current track. Holding this button down for 4 seconds turns the iPod power OFF or ON if the iPod is OFF.

PLUS (+) BUTTON: Press this button to raise the volume of the iPod headphone jack output.

NOTE: Volume buttons do not control the volume of the Dock Connector audio output, which is present and cannot be adjusted.

MINUS (-) BUTTON: Press this button to lower the volume of your iPod's headphone jack output. Please note that volume buttons cannot adjust the volume of the Dock Connector audio output. The Audio output of your iPod's Dock Connector is set at a preset level and cannot be adjusted.

TRACK FORWARD (+) BUTTON: Press this button once to advance to the next track. Holding this button down will feed forward through the current track.

LAST TRACK (-) BUTTON: Press this button once to go to the beginning of the current track. Press the button twice quickly to go to the previous track in your play list. Holding this button down rewinds through the current track.

REMOTE WIDEBAND ADAPTOR

The Wireless Mobile Remote Kit can be used outside of the car as well. The included Wideband Remote Adaptor enables you to control your iPod while jogging, bicycling, or anywhere on the go.

Attaching the Wireless Remote Unit to the Wideband Adaptor: The Wireless Remote Unit attaches to the Wideband Adaptor by two tab locks located on the surface of the wideband (Diagram 6).

1. Align the two openings on the underside of the remote with the tabs on the wideband.
2. Gently twist the remote counter clockwise to lock the remote onto the Wideband Adaptor.
3. To remove the remote from the Wideband Adaptor, gently twist the remote clockwise a short distance until the tabs align with openings so that the remote can be pulled free.

NOTE: When attaching or removing the Wireless Remote Unit, no force is necessary. The unit is designed to attach and detach easily from the adaptor.

USING THE CASSETTE ADAPTOR

If your car stereo features a compatible cassette tape player, you can use the included Cassette Adaptor to play your iPod music through your car's stereo system.

IMPORTANT: Use only iPod car cassette players that support this type of cassette adaptor. In general, stereo with side-loading cassette tapes that leave the edge of the tape visible

while playing are compatible with this device. If the cassette player in your car draws the cassette in and has a mechanical gate that must close fully during play, we do not recommend using this adaptor. If you have any question regarding the compatibility of the Cassette Adaptor with your car stereo, consult the manufacturer of the car stereo system.

1. Insert the plug at the end of the Cassette Adaptor's cable into the headphone jack located on top of the Wireless Remote Receiver.

2. Measure the distance from the cassette player to the iPod mount, and fold and tie up the excess cable using the attached Nyko wrap.

3. Insert the Cassette Adaptor into the player with the cable end pointing towards you, outside of the cassette player.

4. Once the Cassette Adaptor is properly inserted into the player, play the cassette to activate your iPod. The iPod playback should be audible through the cassette mode of your stereo.

5. To stop playback, stop your iPod and press the stop button on the cassette player. Careful use of the device ensures a long life for your new accessory. Please be cautious while driving, and focus on the road.

INSTALLING THE UNIVERSAL CAR MOUNT (Diagram 7)

WARNING: For your safety, we recommend that you only access the iPod controls when your automobile is not in motion. Please keep your eyes on the road.

USING THE AIR VENT MOUNT

The vent clips allow for attachment to either vertical or horizontal blades of your dashboard air vents.

1. Attach the vent mounting plate (A) to the back of the Universal Car Mount.

2. Insert the vent clips (B) into the bottom center of the mounting plate, making sure they are oriented to match the direction of the air vent blades. Then slide them into the slots on the extreme left and right of the mounting plate.

3. Gently insert the vent clips onto the blades of the vent. Never use excessive force in attaching or removing the vent clips.

4. Make sure that the vent clips are spaced evenly to each side for optimal weight distribution.

IMPORTANT NOTE: You should redirect hot or cool air flow to the vent holding the Universal Car Mount and iPod by disabling that air vent. Excessive temperatures can cause serious damage to your Universal Car Mount and iPod. Refer to your automobile's owner's manual for instructions on controlling air flow to individual air vents.

USING THE STICKER MOUNT

The Sticker Mount is a permanent solution that requires the adhesive mounting plate (C) to be attached directly to a surface in your car with an adhesive material.

It is essential to remove any dirt, polish or conditioners – which can impair adhesion – from the area to receive the adhesive mounting plate. Consult with your car manufacturer as to which products to use for this purpose.

Once you have determined the location on your dashboard or console, double-check the orientation of the adhesive mounting plate before removing the protective paper, making sure the Universal Car Mount will slide DOWNWARDS into the plate.

Once the adhesive mounting plate has been attached, leave it in place for approximately 12 hours prior to first use.

IMPORTANT: Removing this adhesive mounting plate may cause damage to your dashboard material. For this reason be very sure of the position before installing the adhesive mounting plate. Nyko does not assume any responsibility for damage that may be caused by removing the adhesive mounting plate after it has been attached.

MOUNTING A FULL SIZE IPOD

1. Make sure that the Universal Car Mount arms (D) are in the open position by pressing the release button (E) located on top.

2. Place the iPod into the Universal Car Mount and gently push it back against the spring-loaded depth adjuster. Pull the arms together to lock onto the iPod.

3. To release the iPod, simply press the release button on the top of the Universal Car Mount.

MOUNTING THE IPOD MINI

1. Make sure that the Universal Car Mount arms are in the OPEN position.

2. Align the iPod mini to the guides at the inside bottom center of the base. Gently push it back against the spring-loaded depth adjuster. Pull the arms together to lock onto the iPod.

3. To release the iPod mini, simply press the release button on the top of the Universal Car Mount.

Universal Car Mount and iPod by disabling that air vent. Excessive temperatures can cause serious damage to your Universal Car Mount and iPod. Refer to your automobile owner's manual for instructions on controlling air flow to individual air vents.

USING THE STICKER MOUNT

The Sticker Mount is a permanent solution that requires the adhesive mounting plate (C) to be attached directly to a surface in your car with an adhesive material.

It is essential to remove any dirt, polish or conditioners – which can impair adhesion – from the area to receive the adhesive mounting plate. Consult with your car manufacturer as to which products to use for this purpose.

Once you have determined the location on your dashboard or console, double-check the orientation of the adhesive mounting plate before removing the protective paper, making sure the Universal Car Mount will slide DOWNWARDS into the plate. Once the adhesive mounting plate has been attached, leave it in place for approximately 12 hours prior to first use.

IMPORTANT: Removing this adhesive mounting plate may cause damage to your dashboard material. For this reason be very sure of the position before installing the adhesive mounting plate. Nyko does not assume any responsibility for damage that may be caused by removing the adhesive mounting plate after it has been attached.

MOUNTING A FULL SIZE IPOD

1. Make sure that the Universal Car Mount arms (D) are in the open position by pressing the release button (E) located on top.

2. Place the iPod into the Universal Car Mount and gently push it back against the spring-loaded depth adjuster. Pull the arms together to lock onto the iPod.

3. To release the iPod, simply press the release button on the top of the Universal Car Mount.

MOUNTING THE IPOD MINI

1. Make sure that the Universal Car Mount arms are in the OPEN position.

2. Align the iPod mini to the guides at the inside bottom center of the base. Gently push it back against the spring-loaded depth adjuster. Pull the arms together to lock onto the iPod.

3. To release the iPod mini, simply press the release button on the top of the Universal Car Mount.

USING THE STICKER MOUNT

The Sticker Mount is a permanent solution that requires the adhesive mounting plate (C) to be attached directly to a surface in your car with an adhesive material.

It is essential to remove any dirt, polish or conditioners – which can impair adhesion – from the area to receive the adhesive mounting plate. Consult with your car manufacturer as to which products to use for this purpose.

Once you have determined the location on your dashboard or console, double-check the orientation of the adhesive mounting plate before removing the protective paper, making sure the Universal Car Mount will slide DOWNWARDS into the plate. Once the adhesive mounting plate has been attached, leave it in place for approximately 12 hours prior to first use.

MOUNTING A FULL SIZE IPOD

1. Make sure that the Universal Car Mount arms (D) are in the open position by pressing the release button (E) located on top.

2. Place the iPod into the Universal Car Mount and gently push it back against the spring-loaded depth adjuster. Pull the arms together to lock onto the iPod.

3. To release the iPod, simply press the release button on the top of the Universal Car Mount.

MOUNTING THE IPOD MINI

1. Make sure that the Universal Car Mount arms are in the OPEN position.

2. Align the iPod mini to the guides at the inside bottom center of the base. Gently push it back against the spring-loaded depth adjuster. Pull the arms together to lock onto the iPod.

3. To release the iPod mini, simply press the release button on the top of the Universal Car Mount.

FCC Advisory

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or move the receiving antenna.
 - Increase the separation between the equipment and the receiver.
 - Connect the equipment to an outlet on a different circuit than that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- You are cautioned that any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.






TECHNICAL SUPPORT

We appreciate your support of NYKO products, and endeavor to guarantee your satisfaction with this product. If you experience difficulties, please contact us.

Email: customersupport@nyko.com
Phone: 1-888-444-NYKO (6566)

NYKO Product Limited Warranty

The NYKO product is warranted to be free from defects in material and workmanship for a period of ninety (90) days from the date of purchase. If a defect occurs within this warranty period, NYKO will replace or repair the product at its discretion, at no charge. Warranty does not apply to damage resulting from misuse or accidents. The product can be returned to the place of purchase accompanied with proof of purchase or shipped to NYKO Technologies Inc., 1500 Wilshire Blvd., 3rd Floor, Los Angeles, CA 90017, with freight charges prepaid. Please allow 3-4 weeks for processing.



NYKO

Wireless Mobile Remote Kit

for/iPod/iPod®

INSTRUCTIONS

Item# 88030

www.nyko.com

Pod is a trademark of Apple Computer, Inc., registered in the U.S. and other countries. Nike® and Wireless Mobile Remote Kit™ are trademarks of Nyko Technologies, Inc. ©2005 Nyko Technologies, Inc. All Rights Reserved.



03 JUN 2005

Wireless Mobile Remote KitTM

for/pour iPod[®]

Wireless Remote Control Kit for Car, Home, On the Go

- Everything needed to control your iPod wirelessly, including:
 - 5-button Wireless Remote Control Unit
 - Remote receiver with headphone pass-thru port
 - Steering Wheel (or Handlebar) Remote Mount
 - Universal Car Mount for all iPods
 - Stylish Wristband Remote Mount
 - Car Stereo Cassette Adaptor
- Safely control the iPod from steering wheel or bicycle handlebars
- Cassette adaptor plays the iPod through your car stereo
- Wristband remote mount controls iPod while jogging, hiking, or bicycling
- Use with other iPod accessories such as FM transmitters, car chargers and stereo cables

Kit Télécommande sans fil pour la Voiture, à la Maison ou sur l'Aller

- Tous qu'il vous faut pour contrôler votre iPod sans fil, comprenant :
 - Télécommande à 5 boutons
 - Récepteur avec prise casque
 - Montage de télécommande sur volant (ou guidon)
 - Fixation auto universelle pour tout iPod
 - Bracelet élégant pour télécommande
 - Cassette adaptatrice auto radio
- Contrôler iPod en sécurité du volant ou guidon
- Écouter iPod sur auto radio avec cassette adaptatrice
- Bracelet télécommande contrôle iPod en faisant du jogging, marche à pied ou du vélo
- Utilisez avec d'autres accessoires iPod tels que transmetteurs FM, chargeurs voitures, et câbles stéréo




NYKO[®] and Wireless Mobile Remote Kit[™] are trademarks of NYKO Technologies, Inc. iPod is a trademark of Apple Computer, Inc., registered in the U.S. and other countries. This is a NYKO product and is not endorsed, manufactured or distributed by Apple Computer, Inc.
©2005 NYKO Technologies, Inc. All Rights Reserved.


NYKO[®] and Wireless Mobile Remote Kit[™] sont des marques déposées par NYKO Technologies, Inc. iPod est une marque d'Apple Computer, Inc., enregistrée aux U.S. et à d'autres pays. Ceci est un produit NYKO. Il est ni fabriqué, ni distribué ni approuvé par Apple Computer, Inc.
©2005 NYKO Technologies, Inc. Tous Droits Réservés.

Register this product online:
Enregistrer sur Internet:
www.nyko.com







Wristband Mount



Steering Wheel Remote Mount



Wireless Receiver



Adjustable iPod Car Mount includes Vent and Dashboard Mounting Kits



Cassette Adaptor plays iPod through Car Stereo

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS
SUBJECT TO THE FOLLOWING TWO CONDITIONS:

- (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND
- (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING
INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.