

Nyko FM Trans Kit for iPod nano

Thank you for purchasing the Nyko FM Trans Kit for iPod nano. This product broadcasts your iPod nano songs to your car's radio, while allowing you to charge iPod nano at the same time using the car power outlet (cigarette lighter). The kit includes brackets for mounting the unit onto the dash or visor. Please review this instruction manual closely to familiarize yourself with this product.

FEATURES


- Listen to iPod nano on any car or home stereo (FM radio required)
- 5 preset frequencies for ease of use and quick selection
- Include 3 different mounting adaptors, including: adhesive, horizontal/vertical air vent clip and exclusive sun visor clip
- Includes car charger, so you can charge your iPod nano while listening to your favorite songs
- One touch operation helps keep your focus on the road
- Powered by the iPod nano, can be used independent of car charger
- An Apple Licensed "Made for iPod" product
- Compact and lightweight design

CONTENTS

- One FM transmitter
- One car charger
- One adhesive dash mount
- One horizontal / vertical air vent clip
- One sun visor clip

INSERTING IPOD NANO INTO FM TRANSMITTER

1. Lift the clear spring-loaded bracket located on top of FM transmitter, then slide iPod nano firmly onto the dock connector, being careful not to force it. (see Fig. 1)
2. Lower the clear spring-loaded bracket onto the top of iPod nano.



MOUNTING THE FM TRANSMITTER IN YOUR CAR

- USING THE ADHESIVE MOUNT

Please note that the adhesive mount is a semi-permanent solution. It may not be possible to remove the mount without damaging the surface to which it is mounted. You may prefer to use one of the other non-permanent solutions.

1. Clean the area you wish to mount to with a damp towel and dry thoroughly.
2. If the surface has been treated with a wax or polish, use a surface safe cleaner to remove excess wax that may interfere with the adhesion.
3. Before removing the 3M protective plastic sheet, make sure the adhesive mount is correctly attached to the FM transmitter (without iPod nano) to avoid the risk of attaching this mount upside down (see Fig. 2). Try the unit in various places on your dash or console before proceeding.
4. Remove the 3M protective plastic sheet, press the FM transmitter (with the adhesive mount attached) firmly against the surface for a few minutes to ensure a tight bond. Avoid placing excessive pressure or weight on the adhesive mount for several days after installation.


- USING THE UNIVERSAL AIR VENT CLIP

1. Attach the air vent mount to the back of the FM transmitter (see Fig. 2).
2. Attach the air vent clip to the air vent mount, being careful to orient the clip to match the horizontal or vertical vents of your car. (see Fig. 3)
3. Press the clip onto the desired AC vent.

NOTE: Never force the vent clip into place, or remove it rapidly, as this can damage the air vents or the FM transmitter. Operating a motor vehicle requires the drivers attention at all times. Focus on the road. If you need to divert your attention from the road, pull over to a safe area.

- USING THE SUN VISOR CLIP

1. Ensure that all other mounts are removed from the FM transmitter.
2. Attach the sun visor clip to the foot at the bottom of the FM transmitter (see Fig. 2).



3. Lower your car's sun visor, squeeze the clip and slide the FM transmitter onto the visor with iPod nano facing you.

NOTE: Never attach the car charger to the FM transmitter if you are using the sun visor mount, as the power cable may interfere with your driving. The FM transmitter does not require the use of the car charger - it is powered by the iPod nano. If you need to charge your iPod nano, remove the unit from the visor before attaching the car charger.

KEEP YOUR EYES ON THE ROAD. Operating a motor vehicle requires your complete attention. Avoid distractions. We suggest creating play lists prior to your trip, then simply activate the play list and focus on the road


SELECTING A STATION ON THE FM TRANSMITTER

1. Once the iPod nano has been inserted into the FM transmitter, press the <SELECT> button on the lower right corner of the FM transmitter.
2. An LED indicator will light up to show the station that the unit is currently transmitting on.
3. Press the <SELECT> button again to scroll through the other channels.
4. Tune your car or home radio to the station indicated on the FM transmitter
5. FM transmitters will perform differently depending on the region. Try different stations to find the one that works best for your area.

IMPORTANT NOTE: The volume knob of the iPod nano is disabled when using this device, and it will not affect the playback level. Please use the car radio's volume to set the playback level.

TROUBLESHOOTING

- Make sure that the iPod nano is charged prior to use.
- Verify that the iPod nano is properly connected to the FM transmitter.
- Ensure that your radio is set to exactly the same station indicated on the FM transmitter.
- Make sure that the iPod nano is playing. There should be no pause logo in the upper left corner of the screen (a play logo should be present).



NYKO®

Register this product online:
Coloque este producto en línea:
Enregistrer ce produit sur Internet:

www.nyko.com

Nyko® is a trademark of Nyko Technologies, Inc.
iPod is a trademark of Apple Computer, Inc., registered in the US and other countries.
©2006 Nyko Technologies, Inc. All Rights Reserved.

- Remember to use the car radio's volume control as this alone will adjust the sound volume.
- Make sure that the FM transmitter is on; there should be a red LED indicating the station of transmission.
- If one station is not providing good reception try another station.
- The area you are in may be saturated with interference; try the device in a different location.
- If you continue to have problems, please contact Nyko.

CARE AND MAINTENANCE

- Keep away from liquids and high temperatures.
- Only use the car charger supplied with the unit.
- Never attempt to open or modify the unit.
- For cleaning, use a lint free cloth.
- If the unit fails to perform properly, discontinue use and contact Nyko

TECHNICAL SUPPORT

We appreciate your support of Nyko products, and endeavor to guarantee your satisfaction with this purchase. If you are experiencing difficulties, please contact us:

Online: www.nyko.com

Email: customersupport@nyko.com

Phone: 1-888-444-6956

Nyko Product Limited Warranty

This Nyko product is warranted to the original purchaser for the normal intended use for a period of ninety (90) days from the date of purchase. If a defect covered under this warranty occurs, Nyko will replace or repair the product or its defective parts, at its option, at no charge. Warranty does not apply to defects resulting from modification or misuse of this product. The product can be returned to the place of purchase with proof of purchase or shipped to: Nyko Technologies, 1990 Westwood Blvd, 3rd Floor, Los Angeles, CA 90025, with freight charges prepaid. Please allow 3-4 weeks for processing.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment."

