

IMPORTANT SAFETY INSTRUCTIONS

When using an electrical appliance, basic precautions should always be followed, including the following:
Read all instructions before using (this appliance).

DANGER - To reduce the risk of electric shock.
Always unplug this appliance from the electrical outlet before cleaning.

WARNING - To reduce the risk of burns, fire, electric shock, or injury to persons:

1. Unplug from outlet before putting on or taking off parts.
2. Close supervision is necessary when this appliance is used by, or near children, invalid, or disable persons.
3. Use this appliance only for its intended use as described in this manual. Do not use attachment not recommended by the manufacturer.
4. Never operate this appliance if it has a damaged cord or plug. If it is not working properly, If it has been dropped or damaged, or dropped into water. Return the product to a service center for examination and repair.
5. Keep the cord away from heated surfaces.
6. Never drop or insert any object into any opening.
7. Do not use outdoors.
8. Do not operate where aerosol (spray) products are being used or where oxygen is being administered.
9. To disconnect, turn all controls to the off position, then remove plug from the outlet.

SAVE THESE INSTRUCTIONS

CAUTION -

To reduce the risk of electric shock, this appliance has a polarized plug (one blade is wider than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet. Do not change the plug in any way.

SERVICING OF DOUBLE-INSULATED PRODUCTS

In a double-insulated product, two systems of insulation are provided instead of grounding. No grounding means is provided on a double-insulated product, not is a means for grounding to be added to the product. Servicing a double-insulated product requires extreme care and knowledge of the system, and is to be done only by qualified service personnel. Replacement parts for a double-insulated product must be identical to the parts they replace. A double-insulated product is marked with the words "DOUBLE INSULATION" or "DOUBLE INSULATED". The symbol (square within a square)  is also able to be marked on the product.



CONFORMS TO UL STD. 962 CERTIFIED TO CSA STD. C22.2 NO. 12.

© HPI / CAN YOU IMAGINE

ITEM NO. : 4434

INPUT : 120V~ 60Hz, 0.25A MAX. 

DOUBLE INSULATION.

FOR HOUSEHOLD USE ONLY.

RESIDENTIAL USE ONLY.

Congratulations on your purchase of Morph Lamp II.

SET-UP

Install the Black Light

Your Morph Lamp II comes complete with it's own Black Light Bulb. To install the bulb, you will need to first remove the top cover from the Morph Lamp II. To do this, push in on the 2 tabs located on the backside of the top cover to unlock the top from the main unit (see Figure 1).

Figure 1





Figure 3



You will notice a drawstring with a push-tie lock that has been used to close the fabric securely. You will also notice that the fabric has 8 holes in it that are used to secure the fabric around the 4 Alignment Posts and the 4 Fabric Securing Posts (see Figure 2). To open the drawstring, simply squeeze in on the sides of the push-tie lock to loosen and pull the push-tie lock back along the drawstring (see Figure 3). Now, make sure that you remove the fabric carefully from around all 8 posts and carefully pull back the fabric, removing it one corner at a time, around the top square rim of the Morph Lamp II (see Figure 4A to 4B). Gently pull the fabric down so that the inside of the lamp is exposed (see Figure 4C).

Figure 4A



Figure 4B



Figure 4C



Now, to insert the Black Light Bulb, slide one end of the bulb into the outward facing slot at the bottom of the Morph Lamp II (see Figure 5). Now slide the other end of the Black Light Bulb into the outward facing slot at the top of the Morph Lamp II (see Figure 6). Now gently twist the bulb from both ends 1/4 turn to lock the bulb in place (see Figure 7).

Figure 5




Figure 6





Figure 7



Now gently take the fabric and carefully pull it towards the top of the Morph Lamp II, and up and over the top square rim of the lamp. Now, making sure that the fabric fits onto the 8 posts, tighten the drawstring by once again squeezing it on the sides of the push-tie lock to loosen and by pulling the push-tie lock back along the drawstring (see Figure 8 and Figure 9).

IMPORTANT: Now, on the back of the Morph Lamp II, you will notice a seam that runs down the length of the fabric (see Figure 10). For best results, before using the Morph Lamp II, it is best to start out with this seam as straight as possible.

Figure 8






Figure 10



Now, take the top cover, align the 4 holes with the 4 "Alignment Posts" and carefully press down onto the top of the Morph Lamp II (see Figure 11). You should hear a "SNAP" - this is an indication that the top cover is secured. The Morph Lamp II is now set up and ready for use!


Note: Along the bottom of your Morph Lamp II is a ring that is located just above the BASE of the lamp (see Figure 12). This ring helps to keep the fabric in place at the bottom of the lamp. It is possible that during shipping, this ring may come loose. If this is the case, simply snap the ring back into the base of the lamp.



USING YOUR MORPH LAMP II

First, plug your Morph Lamp II into any standard household electrical outlet. Next, you will notice that your Morph Lamp II has 2 switches on the back of the unit. One switch controls the MOVEMENT of the Morph Lamp II and the other switch controls the Black Light (see Figure 12). Both operate independently of each other. To begin the Morph Lamp II movement, turn the switch to the ON position. The Morph Lamp II will begin to move and turn. To turn on the Black Light, turn the switch to the ON position.

Figure 12



INSTRUCTIONS DE SÉCURITÉ IMPORTANTES

L'utilisation de tout appareil électrique demande des précautions élémentaires, y compris la suivante :
Lire toutes les instructions avant l'emploi (de cet appareil) :

DANGER : afin de réduire les risques de choc électrique :
Débranchez toujours l'appareil de la prise de courant avant de le nettoyer.

AVERTISSEMENT : afin de réduire les risques de brûlure, incendie, chocs électriques ou blessures :

1. Débranchez toujours l'appareil avant de placer ou retirer des pièces.
2. Une surveillance étroite est nécessaire quand l'appareil est utilisé par ou près d'enfants, invalides ou mutilés.
3. Utilisez cet appareil seulement aux fins qui lui sont destinées comme il est indiqué dans le manuel. N'utilisez que des pièces recommandées par le fabricant.
4. N'utilisez jamais cet appareil si le fil ou la prise sont endommagés. Si l'appareil ne fonctionne pas correctement, s'il est tombé ou endommagé, ou s'il est tombé à l'eau, renvoyez-le au service agréé pour le faire examiner ou réparer.
5. Maintenez le fil loin de surfaces chaudes.
6. Ne jamais lancer ou insérer des objets dans les ouvertures.
7. Ne pas utiliser à l'extérieur.
8. Ne pas faire fonctionner dans des endroits où des aérosols (spray) sont utilisés ou dans des endroits où l'on administre de l'oxygène.
9. Pour débrancher, éteignez tous les contrôles, puis retirez la fiche de la prise de courant.

CONSERVEZ CES INSTRUCTIONS

ATTENTION -

Afin de réduire les risques de choc électrique, cet appareil possède une prise polarisée (une lame est plus large que l'autre). La fiche électrique n'entrera dans une prise de courant polarisée que d'une façon. Si la fiche n'entre pas complètement dans la prise, inversez-la. Si elle n'y entre toujours pas entrez en contact avec un électricien qualifié pour installer une prise adéquate. Ne changez la fiche en aucune façon.

RÉPARATION DE PRODUITS ISOLÉS DOUBLEMENT

Les produits à isolation double présentent deux systèmes d'isolation au lieu d'une prise de terre. Il n'y a aucune prise de terre sur les produits à isolation double et il ne faut pas en installer au produit. Les réparations sur les produits à isolation double demandent une attention extrême et une bonne connaissance du système, et doivent être faites par des personnes qualifiées. Les pièces de rechange d'un produit à isolation double doivent être identiques aux pièces changées. Un produit à double isolation est marqué par les mots "DOUBLE ISOLATION" ou "ISOLATION DOUBLE". Le symbole (carré dans un carré)  peut aussi être indiqué sur le produit.

 **CONFORME AUX NORMES UL STD 962 CERTIFIÉ CONFORME AUX NORMES CSA STD C 22.2 N° 12**

CHPI / CAN YOU IMAGINE

ARTICLE N° 4434

ENTRÉE : 120 V ~ 60 Hz, 0,25A MAX.

ISOLATION DOUBLE

POUR UTILISATION DOMESTIQUE SEULEMENT.

UTILISATION RÉSIDENIELLE SEULEMENT.

Félicitations pour l'achat de votre Morph Lamp II.

INSTALLATION

Installation de la Lumière Noire

Votre Morph Lamp II est complète et équipée d'une Lampe de Lumière Noire. Pour installer la lampe, vous devrez tout d'abord retirer le couvercle supérieur de votre Morph Lamp II. Pour ce faire, tirez les 2 languettes situées à l'arrière du couvercle supérieur pour débloquer la partie supérieure du reste de l'appareil (voir Figure 1).

Figure 1




Figure 2




Figure 3



Fixations du Tissu

Vous remarquerez un cordon de fermeture utilisé pour fixer fermement le tissu. Vous remarquerez également que le tissu présente 8 trous utilisés pour fixer le tissu autour des 4 Goujons d'Alignement et des 4 Goujons de Fixation du Tissu (voir Figure 2). Pour ouvrir le cordon, il vous suffit de tirer sur les extrémités du Fil de Serrage pour le libérer et tirer le Fil de Serrage le long du cordon (voir Figure 3). Maintenant prenez soin de retirer délicatement le tissu autour des 8 goujons en tirant doucement sur le tissu et en l'ôtant de chaque coin, autour du bord du carré supérieur de votre Morph Lamp II (voir Figure 4A et 4B). Retirez doucement le tissu de façon à ce que la partie intérieure de la lampe soit exposée (voir Figure 4C).

Figure 4A



Figure 4B



Figure 4C



Maintenant, pour insérer la Lampe de Lumière Noire, faites glisser une extrémité de la lampe dans la fente du côté externe au bas de votre Morph Lamp II (voir Figure 5). Faites alors glisser l'autre extrémité de la Lampe de Lumière Noire dans la fente du côté externe en haut de votre Morph Lamp II (voir Figure 6). Tournez alors doucement les deux extrémités de la lampe d'1/4 de tour pour la fixer en place. (voir Figure 7).

Figure 5




Figure 6





Figure 7



Prenez délicatement le tissu et tirez-le vers le haut de votre Morph Lamp II, puis par-dessus le bord carré supérieur de la lampe. Maintenant, en prenant soin de vérifier que le tissu est fixé fermement sur les 8 gougeons, serrez le cordon en tirant sur les extrémités du Fil de Serrage pour le relâcher et en tirant le Fil de Serrage vers l'arrière le long du cordon (voir Figure 8 et Figure 9).

IMPORTANT : Maintenant, au dos de votre Morph Lamp II, vous remarquerez une couture qui descend le long du tissu (voir Figure 10). Pour de meilleurs résultats, avant d'utiliser votre Morph Lamp II, il est préférable de commencer avec cette couture en position la plus droite possible.

Figure 8



Figure 9





Figure 10



Prenez maintenant le couvercle supérieur, alignez les 4 trous avec les 4 "Goujons d'Alignement" et pressez soigneusement sur le haut de votre Morph Lamp II (voir Figure 11). Vous devrez entendre un "Déclic" - ceci indique que le couvercle supérieur est fixé. Votre Morph Lamp II est maintenant installée et prête à être utilisée.

Remarque : Au bas de votre Morph Lamp II il y a un anneau situé au-dessus de la BASE de la lampe (voir Figure 12). Cet anneau sert à maintenir le tissu en place au bas de la lampe. Il est possible que durant l'embarquement, cet anneau se soit desserré. Dans ce cas pressez tout simplement l'anneau sur la base de la lampe.

Figure 11





Figure 12



UTILISATION DE VOTRE MORPH LAMP II

Tout d'abord, branchez votre Morph Lamp II à une prise électrique normale. Ensuite, vous verrez que votre Morph Lamp II possède 2 boutons au dos de l'appareil. Un bouton contrôle le MOUVEMENT de votre Morph Lamp II et l'autre contrôle la Lumière Noire (voir Figure 12). Les deux boutons fonctionnent indépendamment. Pour commencer le mouvement de votre Morph Lamp II, tournez le bouton en position ALLUMÉ. Votre Morph Lamp II commence à bouger et tourner. Pour allumer la Lumière Noire, tournez le bouton en position ALLUMÉ.



Fabriqué par
Can You Imagine
Chatsworth, CA 91311

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B ISM equipment, pursuant to Part 18 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.

This product may cause interference to radio equipment and should not be installed near maritime safety communications equipment or other critical navigation or communication equipment operating between 0.45-30 MHz.



Manufactured by
Can You Imagine
Chatsworth, CA 91311