


Getting Started



Check the box contents:

You should have:

- 1 Speaker
- 2 Power Cable



Getting to know your SoundScene speaker



Charging the Battery

- Connect the power cable to the SoundScene
- Plug the power cable into a mains power outlet.
- The first time you use your SoundScene, let it charge for 12 hours to ensure the built-in Lithium battery is properly conditioned.

Listening to Bluetooth Music

- Turn on the Bayan SoundScene (press and hold the Power button until the SoundScene turns on)
- The SoundScene will automatically connect to the last Bluetooth audio source it was used with (if available) – if not you will be able to search for it and pair in the normal way

Bluetooth Pairing

You can use Bluetooth Secure Simple Paring to connect and stream music:

- To enter pairing mode, press and hold the Bluetooth Pairing button on the top of the SoundScene for 2 seconds
- Consult your audio source user manual for instructions on how to pair with Bluetooth devices – generally you will need to go into your settings, Bluetooth, scan for new Bluetooth devices and select ‘sounscene’ You will not be prompted for a passcode for pairing.

Note

- For secure simple pairing to work your MP3 /phone / tablet / laptop must be in close proximity to the SoundScene when trying to pair (within a range of 1 metre)
- After pairing is successful, paired devices will remember each other – unless pairing information is deleted there is no need to carry out pairing again. SoundScene can remember the last 4 audio sources that it was paired with
- SoundScene will automatically connect to the last audio source it was connected to (if it is in range). If you want to connect to an alternate audio source, press the Bluetooth button on SoundScene to disconnect it from the current audio source and enable pairing mode.

Note

To achieve the best audio quality, ensure your MP3 recordings are sampled at a high bit rate (ideally 320kbps stereo)

Connecting a source to the AUX input

Use a 3.5mm stereo jack cable to connect the headphone output from your source device to the AUX input on the back of the SoundScene.

Controlling Volume for Bluetooth and AUX music playback

There are 2 volume controls available to adjust how loud your music is playing back – on the audio source itself, and on the SoundScene. You will not be able to get maximum volume unless the volume is turned up to maximum both on the audio source, and the SoundScene.

Connecting speakers (multi-speaker mode)

You can connect up-to 8 SoundScene speakers together to create an all-encompassing sound environment. To use the speakers together:

1. Turn on all the speakers you wish to use together, and ensure they are within 30m (100ft) of the speaker you wish to use as the transmitting speaker.
2. Select which speaker you wish to use as the transmitter (for optimal performance this should be the speaker closest to your audio source device) – Note: you should select the speaker with which your phone is paired as the transmitter, or alternatively pair your phone with another speaker in order to use it as the transmitter.
3. Press the ‘T’ button on the transmitting speaker
4. Press the ‘R’ button on all other speakers you wish to connect to the transmitting speaker
5. Press the ‘LINK’ button on the transmitting speaker, then press the ‘LINK’ button on the first receiving speaker. Wait for the speakers to connect to each-other (it is helpful to be listening to music at this stage through the transmitting speaker as it will be obvious that the pairing has completed when the receiving speaker starts to play)
6. Repeat step 4 for each receiving speaker you wish to connect simultaneously with the transmitter.

Note

For maximum coverage, the transmitting speaker should be arranged at the centre of your sound environment, and the receiving speakers arranged around it at a distance of up-to 30m (100 feet)

Troubleshooting

The SoundScene will not turn on

Ensure that the battery is charged – connect the power cable to the back of the SoundScene. The charge indicator light will be ORANGE when the SoundScene is charging, and when fully charged will turn GREEN

I cannot hear any music

Ensure that the volume is turned up on both your source device (phone / mp3 player) and also on the SoundScene. Make sure that your source device has the correct output selected (for Bluetooth, select the output as 'SoundScene')

I cannot pair my Bluetooth media player with the SoundScene

For secure simple pairing to function; your Bluetooth device needs to be in close proximity to the SoundScene (nominally within 50cm).

Specifications

Bluetooth Version: 3.0 (can pair with devices back to Bluetooth version 2.1)

Profile: A2DP, HFP

Effective Bluetooth Range: 10m (30 feet)

Effective RF multi-speaker range: 30m (100 feet)

Dimensions: 125(W)*265(H)* 135(D)mm

Weight: 2.3KG

Frequency stabiliy:±20ppm

Operating Temperature:-20-55

voltage:120V

For support, please contact Bayan Audio via the website at

www.bayanaudio.com

Or email support at:

support@bayanaudio.com

iPod is a trademark of Apple Inc. Registered in the US and other countries
iPhone and iPod are trademarks of Apple inc.