





RFID Reader/Writer (068-50043)

CONNECTOR side	ANTENNER side
	
Right side	Left side
	
UP side	Under side
