

Getting Started

For the first time using the handsfree, please:

- Charge handsfree with the provided saver charger for 3 hours.
- Ensure a Bluetooth function supporting mobile phone is ready for pairing.

Charging

Charge with saver charger(cigarette light adaptor)

Switch on the handsfree.

Connect the saver charger to the in car cigarette socket, and then to the charging port of the handsfree.

Indicator light flashes red and blue alternately.



Notes:

- Charge the handsfree only with the saver charger supplier provided.
- Maximum charging time: 3 hours
- Indicator light stops flashing red when fully charged.
- Talking time: up to 10 hours
Standby time: up to 200 hours
- Low battery signals: indicator light flashes red and 'do' sound until handsfree is recharged.
- Do not charge up to 24 hours.

Switch On/Off

Switch on handsfree

Press and hold the Multifunction Key for 4/5 seconds until you hear a low to high 'dodo' sound and indicator light flashes blue.

Switch off headset

Press and hold the Multifunction Key for 4/5 seconds until you hear a high to low 'dodo' sound and indicator light flashes red and then goes off.

Pairing with a phone

Before using the handsfree, you must pair it with the mobile phone first. Once the handsfree and the phone has paired, they store the ID of each other. Thus they can connect to each other automatically. You can check, delete or rename the paired device in the devices list of the mobile phone.

1. Place the Bluetooth handsfree and the Bluetooth mobile within a distance of 1 meter.
 2. Switch on the Bluetooth mobile and enable Bluetooth feature. *If the phone have 'Profile' options, you are recommended to select 'Handsfree/Car Kit Profile' rather than 'Headset Profile'.
 3. Turn on the handsfree. The indicator light flashes blue every 5 second indicates it is in idle mode.
 4. On the Bluetooth mobile, searching for device, 'HF009' will appear in the device list.
 5. Select device 'HF009' and enter pass key '8888'. The indicator light turns blue steadily. Pairing completed.
 6. Make sure the paired mobile has returned to main menu. Check if the mobile displays any Bluetooth status info.
 7. The volume is automatically set to middle level. For best performance, press '+' or '-' to adjust a suitable volume level.
- * Some phones automatically connect to headset as the pairing is completed. Some phones require manually built up the connection. Please refer to your phone's user manual.

You should now be able to make wireless communication with the handsfree. Keep the distance between the handsfree and the mobile within 10 meters and free from obstacles. You can dial and receive calls by the phone, or activate the voice dialing, redial the last number and receive calls through the handsfree.

* 'Handsfree/Car Kit Profile' supports 'Caller ID display', 'Redial the last number', 'Call waiting' and 'Call transfer' functions. If the mobile phone only supports 'Headset Profile', those functions are not available.

Connect/Reconnect to phone

When the handsfree is switched on, press the Multifunction Key once and the handsfree will automatically connects to the paired mobile phones nearby. If the handsfree has paired with many mobile phones and they are within 10 meters, the handsfree will connect to the last connected mobile phone.

Different phones connect with handsfree in different methods. The following are the 2 methods, namely A and B:

A: When the handsfree is in standby mode and is dialing or receiving a call by the phone, the phone connects to handsfree automatically.

When receiving a call, redialing or activating the voice dial through the handsfree, the handsfree connects to the phone automatically.

B: After the handsfree and the phone are connected, the handsfree sends signals to the phone to keep the connection.

For method B, if the handsfree and the phone are disconnected, manual reconnection is required:

EITHER Press Multifunction Key once, the handsfree will connect to the phone again. If the phone confirms to the reconnection signal, reconnection completed.

OR In the setting menu of the phone, select 'HF009' from 'Paired Device'. Select the 'connect' and the phone will connect to the handsfree.

Status	Operation	Indicator Light & Sound	LCD Display
Switch to/ from waiting call	During a call, when another call dials in, press multifunction twice for switching to the 2nd call. Press twice again to switch back.	'do' sound	CALLER NUMBER
Transfer to phone	During a call, press and hold multifunction key.	-	TRANSFER
Re-dial last number	In standby mode, press multifunction key twice.	-	REDIAL
Voice dial	In standby mode, press multifunction key once.	A tone from the handsfree indicates the phone is ready to receive voice tag.	VOICEDIAL > CALLING
Mute/Unmute microphone	During a call, press together '+' and '-' buttons once.	'do' sound. You can still hear the other side.	-
Adjust Volume	Click '+' or '-' button to control the voice gain.	-	displays volume level
Privacy call	Connect external headphone to headphone port.	-	-
Disconnect with mobile	Press and hold '+' or '-' button.	-	DISCON
Lowbattery	-	Red on and 'do' sound.	LOWBATT
Charging	Connect to charger and switch on the power	Flashes red & blue	CHARGING
Charging completed	Within 3 hours	Stops flashing red	BLUETOOTH






Quick User Guide

Status	Operation	Indicator Light & Sound	LCD Display
Switch on	From off mode, press and hold multifunction key for 4/5 sec. Pull out the microphone handle.	A low to high 'dodo' sound. Flashes blue every 5 second indicates in idle mode.	POWERON > BLUETOOTH
Connect/ Reconnect (with paired phone.)	In Idle mode, press multifunction key once. OR On mobile phone, select paired device 'HF009' and then 'Connect'.	Flashes blue every half second indicates searching for paired devices. If connected to mobile, blue always on indicates in standby mode.	CONNECTED
Switch off	In standby mode, press and hold multifunction key for 4/5 sec.	A high to low 'dodo' sound & indicator light off.	POWEROFF
Pairing (for the first time using the handsfree)	1. Switch on the handsfree. 2. Enable Bluetooth feature of the mobile phone. 3. In the Bluetooth menu, select 'add device' or 'search device'. 4. 'HF009' appears in the device list, press 'yes'. 5. Enter pass key '8888'. Pairing completed. 6. Edit the device name if you would like to personalize it.	Flashes blue every 5 second indicates in idle mode. Blue always on, indicates in standby mode.	PAIRED
Receive call	When handsfree is ringing, press multifunction key once.	-	CALLER NUMBER
Reject call	When handsfree is ringing, press multifunction key twice.	-	REJECT
End call	During a call, press multifunction key once.	-	REJECT

Use in car



1. Inside the car, clip the provided bracket to the sun visor as shown.
2. Fix the handsfree on the bracket.
3. To flip the handsfree up or down, first release the screw of the bracket a little bit.
4. After the handsfree has adjusted to a comfortable view angle facing you, lock the screw.
5. Make sure the microphone handle is pull out.



Use in office / home

1. Pull up the stand at the backside.
2. Put it on a flat surface and pull out the microphone handle.



Handsfree functions

Receive call	When handsfree is ringing, the LCD displays the calling number. Press Multifunction Key once to receive the call and 'CONNECTED' will be displayed.
Reject call	When handsfree is ringing, the LCD displays the calling number. Press Multifunction Key twice to reject the call and 'REJECT' will be displayed.
End call	During a call, press Multifunction Key once. LCD displays 'REJECT'.
Switch to/from waiting call (Call waiting)	When a second call dials in during a call, the LCD displays the second calling number and 'dodo' sound from the handsfree. Press Multifunction Key twice to switch to the second call. Press twice again to switch back to the first call.
Transfer to phone (Call transfer)	During a call, press and hold Multifunction Key once. LCD displays 'TRANSFER'.
Redial the last number	In standby mode, press Multifunction Key twice. The last number will be redialed. LCD displays 'REDIAL'.
Voice dial	Ensure that the mobile phone supports Voice Control Dialing. In standby mode, press Multifunction Key once. LCD displays 'VOICEDIAL'. You will hear a tone from the handsfree. It indicates the mobile phone is ready to receive voice tag. Speak the name of the person you wish to call. Then the mobile starts the voice dial automatically.
Muting/Un-muting	To temporarily mute the microphone, press together the volume '+' and '-' buttons once. You will hear 'do' sounds. This will allow you to hear the other side but the other side does not hear you.
Adjust volume	Press '+' and '-' buttons to a suitable volume level. LCD displays the volume level.
Privacy call	Connect external headphone. This will allow you to hear the other side but the other people inside the car do not hear the other side.
Disconnect with mobile	For connecting the handsfree to another mobile, in standby mode, press and hold the handsfree '+' and '-' buttons. LCD displays 'DISCON'.

* Functions 'Caller ID display', 'Redial the last number', 'Call waiting' and 'Call transfer' are supported by Handsfree Profile instead of Headset Profile. For using those functions, please check if the mobile phone supports Handsfree Profile.

* Function 'Volume Level Display' is available if the phone supports 'Remote Volume Control'.


Overview

Bluetooth Portable Handsfree Car Kit
Model BTHF009

Thank you for selecting BTHF009 Bluetooth portable handsfree car kit. It is a rechargeable speakerphone which is easy to operate in car and portable to use anywhere. It is specially designed for connecting Bluetooth compatible mobile phones in car. No matter the car is ignited or not, you can enjoy the freedom to make and receive calls without connecting with wires.

This handsfree car kit is specially designed for Bluetooth mobile phones or other Bluetooth compatible devices that support the Handsfree or Headset profiles.

The Bluetooth wireless technology is a worldwide specification for a small form-factor, low-cost and short-range (about 10 meters) radio solution providing links between mobile computers, mobile phones, other portable and handheld devices and connectivity to the internet.



Care and maintenance

- Switch off the handsfree if not in use.
- Do not try to replace the rechargeable battery inside handsfree.
- Charge handsfree only with the supplied charger.
- Do not try to open the supplied charger.

Contents

Overview	3
Quick User Guide	4-5
Getting Started	6
Charging	6
Switching On/Off	6
Pairing with a phone	7
Connect/Reconnect to phone	8
Use in car	9
Use in office/home	9
Handsfree functions	10
Care and maintenance	11
Specification	11
FCC Notice	12

Specification

Bluetooth Specification	: Version 1.2 compliant
Bluetooth Profile Supported	: Headset and Handsfree Profiles
Frequency Range	: 2.4 GHz spectrum
Working Distance Range	: 10 meters (class 2)
Dimensions (main unit)	: 108 (L) x 57 (W) x 31 (T) mm
Weight (main unit)	: 129 g
DSP	: Full duplex transmission, noise suppression and echo cancellation.
Pairing	: Up to 4 mobile phones
Charging Time	: Within 3 hours
Talking Time	: Up to 10 hours
Standby Time	: Up to 200 hours
Rechargeable Battery	: Lithium Ion, 3.6 V, 1100 mAh installed
Battery Protection	: Over charge and over discharge protection
Input Current	: 350 mA (internal controlled)
Input Voltage	: DC 5 V
Speaker Power	: 2 W (max.)
Speaker Impedance	: 8 ohm
Sensitivity of Microphone	: -47 dB

Notice 1

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Notice 2

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

User Manual

For Model BTHF009
Bluetooth Portable Handsfree Car Kit