


IMAGE POINTER USER MANUAL

xpointer
XPM170YN


1. RECEIVER




2. CONNECT TO PC (USB PORT)



3. KEY FUNCTIONS



4. BATTERY REPLACEMENT



xpointer



* ImagePointer Software and User Manual Download
www.x-pointer.com - CUSTOMER - DOWNLOAD

Specification

Transmitter		ImagePointer program
Frequency	2.430~2.460GHz	ImagePointer Software
Number of channels	31 channel	*Private program Operating System Support
ID	65,536	Windows 10, macOS Catalina above
Distance of use	Max. 50m(Open Field)	ImagePointer
Antenna power	less than 10mW	Circle pointer
Modulation system	GFSK	Highlight
Operating time	Alkaline AAA Standard: Approx. 50	Magnifier
Consumption current	Under 20mA	Custom image pointer
Button	3 buttons, 1 touch	(Supports JPG, PNG, GIF, animation GIF, ICO, etc.)
Battery	1.5V AAA x 2	PC screen enlargement
Size	121 x 26 x 14	
Weight	22g(without batteries)	Zoom Pointer Line drawing
Receiver		
Interface	HID USB interface	
Power	5V (USB Power)	
Power consumption	less than 23mA	
Size	26 X 12 X 4.5 mm	
Weight	1.5g	

Certification



FCC Statement and Legal Notices

• This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

- Any changes or modifications (including the antennas) to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment.
- This equipment complies with FCC RF Radiation exposure limits set forth for an uncontrolled environment. This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

FCC ID: R/VBXP170YN Model: XPM170YN
Responsible Party: Choistechnology Co., Ltd. #8-1404 Songdo Technopark IT Center,
32, Songdogwahak-ro, Yeonsu-gu, Incheon, Korea (21984)

Cautions

- There is no compensation for accidents caused by misuse.
- Please be sure to read the following information carefully.
 - 1) Be careful not to let liquids such as water and drinks get into the product.
 - 2) Do not expose to direct sunlight for a long time that causes discoloration.
 - 3) Please keep the storage temperature at -10°C~50°C and appropriate temperature at -10°C~50°C.
 - 4) Do not damage the product nor use or modify the product for any purpose other than its original purpose.
 - 5) Please be careful not to lose the receiver.

Support

If there are some problems or something to improve while using the product, please contact us. We will consult about it kindly.

E-mail : choistec@choistec.com
TEL : +82 32-246-3409
FAX : +82 32-246-3406
Homepage : www.x-pointer.com
Company Name : Choistechnology Co., Ltd.

Warranty

We warrant this product is manufactured by Choistechnology Co., Ltd. and any defect of the product caused by materials and mechanical problems will be covered for free for a year. If our model you purchased is found to be defective within that time, we will promptly repair or replace it. However, this warranty does not cover problems or damages resulted from unauthorized repair, modification or disassembly.