

Xelfie™ User Manual SMARTPHONE Camera Shutter XSC100




made in KOREA
www.X-pointer.com

1. Product Configuration

Components	Qty.
Xelfie	1
Silicon Case	1
Battery (Button Cell CR2025)	1
Strap	1
User Manual	1

2. Designation of Part



No.	Designation
①	Status Indicator (LED)
②	Button (Pairing and Shot)
③	Battery Cover

※ Caution :The components and functions of the product may vary without notification to upgrade the performance.

3. Compatible devices

1) Please check compatible device list.
Check website
(www.choistec.com/en/xelfie/faq)
Scan the QR code
(<http://m.site.naver.com/0alxz>) to check the compatible devices.



※ Available with iPhone 4S or later

2) For iPhone (iOS7, iOS8)

- ① Select the Bluetooth section on the configuration screen and turn the Bluetooth on. (Activate the Bluetooth)
- ② Xelfie is automatically searched on the Bluetooth configuration screen.
- ③ Push the Xelfie button to set up the connection standby and the indicator LED blinks with a certain period (about 15 seconds).
- ④ The searched Xelfie appears on the smartphone Bluetooth device list. (Ex) Xelfie 48, Xelfie 54, etc.)
- Use the 2 digits following 'Xelfie' to identify your own device.
- ⑤ Select your searched Xelfie, you can see pop-up for pairing. Please select 'pair' on the pop-up screen.
- ⑥ The indicator LED of Xelfie blinks every 5 seconds for the normal connection.
- ⑦ Now, run camera App and take shot.

※ For Android, it depends on model and OS version.
Please check compatible devices before use.

Xelfie is available with Android OS 4.3 and OS 4.4.2.

It doesn't working although there is your model in compatible device list, please update OS. For more detail about update, please contact customer service center of Smartphone manufacturer.

3) For Android (OS 4.4.2)


- ① Select the Bluetooth section on the configuration screen and turn the Bluetooth on. (Activate the Bluetooth)
- ② Push the Xelfie button to set up the connection standby and the indicator LED blinks with a certain period (about 15 seconds).
- ③ Select 'Search' or 'Search other device' below the smartphone. (If there is no registered Bluetooth devices, it searched automatically.)
- ④ The searched Xelfie appears on the smartphone Bluetooth device list. (Ex) Xelfie 48, Xelfie 54, etc.) Use the 2 digits following 'Xelfie' to identify your own device.

- ⑤ Select your searched Xelfie to automatically register and connect the device.
- ⑥ The indicator LED of Xelfie blinks every 5 seconds for the normal connection.
- ⑦ Now, run camera App and take shot.

4) For Android OS 4.3

- ① Search for 'XSC100' in "Google Play" and install the exclusive APP (Xelfie) on the smartphone.
- ② Run the exclusive App (Xelfie) for pop-up Bluetooth activation screen. Click "Yes" for activation.
- ③ Push the Xelfie button to set up the connection standby and the indicator LED blinks with a certain period (about 15 seconds).
- ④ The searched Xelfie appears on the smartphone Bluetooth device list. (Ex) Xelfie 48, Xelfie 54, etc.) Use the 2 digits following 'Xelfie' to identify your own device.
- ⑤ Select your searched Xelfie to automatically register and connect the device. And then turn to shooting mode automatically.
- ⑥ The indicator LED of Xelfie blinks every 5 seconds for the normal connection.
- ⑦ Now, take shot with Xelfie App.

※ Notice (Galaxy S4, Note3) If camera zoom is activated when you push Xelfie button, please change your volume key setting on camera App. (some devices volume key is set as 'The zoom key'. Please change to 'The Camera Key')



► Status Indicator on Xelfie

Connection standby with the smartphone	The indicator LED blinks for every 0.5 second (about 15 seconds)	
Connected with the smartphone	The indicator LED blinks for every 5 seconds.	


※ LED doesn't work with button : Battery problem or failure.

※ For more detail about trouble shootings, please check on website (www.choistec.com/en/xelfie/faq)

4. How to change the battery

One battery is provided. Replace the battery when the inserted one is fully discharged for smooth operation.

- 1) Prepare one battery (CR2025).
- 2) Detach the battery cover of Xelfie.



- 3) Remove the existing battery from the battery cover and replace with new one.
- 4) Put back the battery cover of Xelfie.
- 5) It shows that the battery is normally replaced if the indicator LED blinks with a certain period (about 15 seconds) when you push the Xelfie button.
(The indicator LED blinks once in every 5 seconds if Xelfie is connected to the smartphone)
- 6) Check the battery insert status if the indicator LED does not blink with a certain period.

5. Caution

- 1) Do not apply excessive pressure, use the product out of the purpose and arbitrarily modify the product. ⚠
- 2) Take care for an infant and a child not to eat the product and keep the detached battery out of reach of children. ⚠
- 3) Dispose of the replaced battery following the instruction. ⚠
- 4) Do not make the water contact the water or wet. ⚠
- 5) Follow the temperature of -10 ~ +50°C for the product storage and use. ⚠
- 6) Take care not to lose your product.

6. Specification

Operating Range	Max 20m (Open)	Battery	CR2025 (DC 3V)
RF Protocol	Bluetooth 4.0 LE	Current	Less than 10mA
Frequency Range	2,402~2,480MHz	Weight	3.5g
Frequency Channel	40CH	Size	030 x 8.2mm
RF Power	Max 1mW	Operation	Temp. -10~50°C Humi. 30~75%
Modulation	GFSK	Storage	Temp. -10~50°C Humi. 75% less

7. Certification

• Separately marked on the box

FCC ID : RVBXSC100

Model name : XSC100
Choistechnology Co., LTD.

This device complies with part 15 of the FCC Rules.
Operation is subject to the following two conditions :
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

INFORMATION TO THE USER

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications.

Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

WARNING

Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

8. Customer Support

We will kindly help you in case you have problems or there is something to improve on the product or its use. Please refer to our contact information as below.

E-mail : inquiry@choistec.com
Homepage : www.X-pointer.com

9. Warranty

One year warranty.
If you have problem, please contact store you bought.