

C2 - Audrey - Generic IPiG

Rev20181002 by DL@Razer

Open size 240 x 85mm, one fold

Folded size: 120 x 45mm

Printing: 4C

Pages: 20 pp

Material: [COVER page] 220gsm art paper

[INNER page] 110gsm art paper

FOR GAMERS. BY GAMERS.™

RAZER.COM

© 2018 Razer Inc. and affiliated companies. All Rights Reserved.

IPiG-RC30-025903-181002DL

WIRELESS CHARGER

FOR RAZER PHONE 2

Page 20 (Back Cover)

Page 1 (Cover)

For your safety and that of your devices, follow these rules for handling your Razer Wireless Charger. Please keep these instructions handy for future reference.

NOTICE: Incorrect storage or use of your power adapter and wireless charger may void the manufacturer's warranty.

IMPORTANT SAFETY INFORMATION

WARNING: Failure to follow these safety instructions could result in fire, electric shock, or other injury or damage.

To safely use the Razer Wireless Charger and reduce the possibility of heat-related injuries, please follow these guidelines:

General

- Place your Razer Wireless Charger on a stable surface that allows adequate air ventilation. Don't place the wireless charger on any unstable surface as the device may fall without notice. This equipment damages to property, and even the product itself.
- Don't use or place the device near water, moisture, or other wet surfaces.
- Don't use or place near any heat, naked flame, or other hot surfaces such as radiators, stoves, fireplaces, and candles.
- Don't place the wireless charger close to any magnetic stripes or chip cards (e.g. ID card, bank cards, etc.) to avoid magnetic failures.

- Keep at least a 20 cm distance between the wireless charger and any implantable medical devices (pacemakers, implantable cochlear, etc.) to avoid potential interference to the medical device.

- Use caution when using the wireless charger to avoid electrical shock or damage, such as unplugging the charger during thunderstorms, ensuring that your hands are dry before using (and handling) the device, keeping it away from any source of liquid and/or heat source, and using all other reasonable precautions needed under the circumstances.

- Protect the charging cable from being walked on or pinched, particularly at plugs, convenience receptacles, or the point where they exit from the device.
- Don't puncture nor insert foreign objects into any of the wireless charger's openings.

- Don't overload wall electricity outlets, extension cords and plugs. This may result in fire or electrical shock.

Usage

- If the wireless charger is not working, check if the charging cable is firmly connected and/or its power adapter is plugged in.

- The Razer Wireless Charger should be used for compatible mobile devices only. Please check the packaging to know if the wireless charger is compatible with your mobile device. Razer shall not be responsible for any damages incurred to any device when using the wireless charger.

- Don't use the wireless charger under pillows, blankets or

on/near flammable surfaces as the device will generate heat while charging.

- The Razer Wireless Charger should only be operated using the type of power source indicated on the device. Only use the charging cable and power adapter provided with your product or by your local distributor and/or retailer. If you are unsure of the power source, please consult the local power company or a qualified technician.

Maintenance

- When cleaning the wireless charger, remove the charging cable first before gently cleaning it using a soft cloth or cotton swab. Don't use aerosols or liquid cleaning agents.

- Refer all servicing to qualified service personnel. This is required when the device has been damaged in any way, such as if the charging cable or power adapter is damaged, liquid has been spilled or objects have fallen on the device, the device has been exposed to rain or moisture, does not operate normally or has been dropped.

- Don't take apart the device (doing so will void your warranty) and don't attempt to operate it under abnormal current loads.



The exclamation point, within an equilateral triangle, is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying this product.



The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electrical shock to persons.

POWER ADAPTER FOR THE RAZER WIRELESS CHARGER

Use only the power adapter that came with your Razer Wireless Charger, or the Razer-authorized power adapter compatible with this product. Make sure the charging cable is fully inserted into the power adapter before plugging the power adapter into a power outlet.

The Power Adapter complies with the user-accessible surface temperature limits defined by the International Standard for Safety of Information Technology Equipment (IEC 60950-1).

Page 2

Page 3

WHAT'S INSIDE / PRODUCT REQUIREMENTS

WHAT'S INSIDE

- Razer Wireless Charger
- Power adapter*
- USB-C charging cable
- Important Product Information Guide

*May vary for specific regions.

SYSTEM REQUIREMENTS

Hardware requirements

- Razer Phone 2
- or
- Qi™ enabled or with external Qi™ receivers / case smartphones


Mobile app requirements

- iOS or Android mobile device with Bluetooth compatibility
- Internet connection

LET'S GET YOU COVERED

You've got a great device in your hands—now maximize its potential by registering online! You score exclusive Razer benefits, information on your wireless charger's 1 year warranty, and more.

Register now at razerid.razer.com/warranty



You'll find your product's serial number here.

Got a question? Ask the Razer Support Team at support.razer.com

Page 4

Page 5

EXPLORING YOUR WIRELESS CHARGER

- A USB-C port
- B Adjustable wireless charging surface
- C Underglow lighting Powered by Razer Chroma™
- D Night Mode button
- E Power Adapter*
- F USB-C charging cable

*May vary for specific regions


GETTING STARTED

- Optional: While firmly holding the base of the wireless charger, slide the charging surface away from the Night mode button, and then gently lift the charging surface upwards.



WARNING: Do not forcefully lift the charging surface immediately without sliding it upwards. Doing so will break the device and void your warranty.


- Use the USB-C charging cable to connect the power adapter to your wireless charger, and then plug it in. The underglow lighting will display the default spectrum of colors.



Page 6


Page 7

- Place your mobile device on the charging surface and wait for it to fully charge. The underglow lighting will briefly flash in green to indicate that it's now charging your device.



Note: If the underglow lighting continuously flashes in red due to a charging error, check if your device is compatible and/or properly placed at the center of the charging surface.

STAND MODE*



* Landscape charging only works for the Razer Phone 2

Page 8

Page 9

USING YOUR RAZER WIRELESS CHARGER

UNDERGLOW LIGHTING

The underglow lighting momentarily displays the status of the wireless charger before reverting to its current lighting effect.


Mode	Charging	Pairing	Paired	Charging Failure*
Status				

*Check if your device is compatible and/or properly placed at the center of the charging surface.

NIGHT MODE BUTTON

Turn on / off lighting

Press the Night Mode button to turn on / off the underglow lighting of the wireless charger.



Page 10

Page 11

SAFETY AND MAINTENANCE

In order to achieve maximum safety while using your Razer Wireless Charger, we suggest that you adopt the following guidelines:

- Only use the accessories provided in the package, and only purchase accessories made and/or approved by Razer.
- Should you have trouble using the wireless charger properly and troubleshooting does not work, unplug the charger and contact the Razer hotline or go to support.razer.com for support. Don't attempt to service or fix the charger yourself at any time.

- Don't take apart the device (doing so will void your warranty) and don't attempt to operate it under abnormal current loads.

- Keep the device away from liquid, humidity or moisture. Operate the device only within the specific temperature range of 0°C (32°F) to 40°C (104°F). Should the temperature exceed this range, unplug and/or switch off the device in order to let the temperature stabilize to an optimal level.


MAINTENANCE AND USE

The Razer Wireless Charger requires minimum maintenance to keep it in optimum condition. Once a month, we recommend you unplug it from the power adapter, remove the attached cable, and gently clean it using a soft cloth or cotton swab to prevent dirt buildup. Don't use soap or harsh cleaning agents.

CERTIFICATION AND COMPLIANCE

[POWER ADAPTER]

Model No. [型号/型號]
RC30-021501, RC30-021502, RC30-021503,
RC30-021504, RC30-021505, RC30-021510
Product Name/产品名称/產品名稱
Power Adapter/电源适配器/電源供應器
Input/輸出(輸入): 100-240V-50-60Hz, 0.8A
Output(輸出/輸出): 5V=3A, 9V=2.67A, 12V=2A



[WIRELESS CHARGER]

Model No. [型号/型號] RC30-025903
Product Name/产品名称/產品名稱
Wireless Charger/无线充电器/無線充電器
Rating(额定/額定): 12W=2000mA

SINGAPORE WIRELESS CERTIFICATION

Complies with
IMDA Standards
DA104511

NOTICE FOR KOREA EMI STATEMENT

R-C-raz-RC30-025903

해당 무선설비는 전파인증 기준에 적합하므로
인명안전과 관련된 서비스는 할 수 없음

Page 12

Page 13

FCC DECLARATION OF CONFORMANCE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.

FCC CAUTION STATEMENT

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

IMPORTANT NOTE:

FCC Radiation Exposure Statement:
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

INDUSTRY CANADA STATEMENT

This device complies with ICES-003 licence-exempt RSSs. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'ISED applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) le dispositif ne doit pas produire de brouillage préjudiciable, et (2) le dispositif doit accepter tout brouillage reçu, y compris un brouillage susceptible de provoquer un fonctionnement indésirable.

低功率電波輻射性電機管理辦法
第12條 經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自變更頻、加大功率或變更原設計之特性及功能。
第14條 低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。
前項合法通信，指依電信法規定作業之無線電通信。低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

Radiation Exposure Statement:

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.

Déclaration d'exposition aux radiations :
Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 20 cm de distance entre la source de rayonnement et votre corps.

This Class B digital apparatus complies with Canadian ICES-003.
Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

CHINA RoHS

The information in the following table is only applicable to products for sale in People's Republic of China.

Requirements for Concentration Limits for Certain Hazardous Substances in Electronic Information Products

关于符合中国《电子信息产品污染控制管理方法》的声明
Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 20 cm de distance entre la source de rayonnement et votre corps.

零件名称	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr (VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
外壳	0	0	0	0	0	0
电路板	0	0	0	0	0	0
其他及零配件	0	0	0	0	0	0

○ 表示该有害物质在该部件所有均质材料中的含量均符合 SJ/T 11363-2006 标准规定的限量要求。
× 表示该有害物质在该部件所有均质材料中的含量超出 SJ/T 11363-2006 标准规定的限量要求。备注: 符合“P” 表示符合部分有害物质限制法规。
RoHS法规: 欧洲议会和理事会第2002/95/EC号关于电子电气设备中限制使用某些有害物质的2002/95/EC号指令。
注: 环保使用期限的符号标注于产品正常工作温度和湿度条件下。

中国环保材料内容宣布: 仅适用于中国

Page 16

Page 17

AUSTRALIAN CONSUMER LAW COMPLIANCE

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. Please refer to [razer.com/warranty](http://www.razer.com/warranty) for further details.

Razer Gaming Accessories	1 Year
--------------------------	--------

THE FOLLOWING LIMITED WARRANTY ONLY APPLIES TO AUSTRALIA

Limited Warranty: Razer warrants the Product to be free from defects in materials and workmanship subject to the terms set forth herein when used normally in accordance with the official documentation for the applicable Warranty Period from the date of retail purchase. If the Product is, or contains, a rechargeable battery, Razer does not provide any warranties for the battery life, as all rechargeable batteries can be expected to lose charging capacity over time and this is not considered a defect. Your actual battery life will vary depending on the conditions in which it is used.

CORRECT DISPOSAL
This marking on the product, accessories or literature indicates that the product and it's electronic accessories (e.g. charger, power cord) should not be disposed of with other household waste. This product is RoHS compliant.

STATEMENT OF COMPLIANCE WITH EU DIRECTIVE

Herby, Razer (Europe) GmbH, declares that the product is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU.

The full Declaration of Conformity can be requested via the following:
Company: Razer (Europe) GmbH
Address: Essener Bogen 23,
22419 Hamburg, Germany
E-mail: compliance@razer.com

低功率電波輻射性電機管理辦法
第12條 經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自變更頻、加大功率或變更原設計之特性及功能。
第14條 低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。
前項合法通信，指依電信法規定作業之無線電通信。低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

LEGALESE

COPYRIGHT AND INTELLECTUAL PROPERTY INFORMATION
©2018 Razer Inc. All rights reserved. Razer, the triple-headed snake logo, Razer logo, "For Gamers. By Gamers.", "Powered by Razer Chroma" logo and Razer Phone 2 are trademarks or registered trademarks of Razer Inc. and/or affiliated companies in the United States or other countries. All other trademarks and trade names are the property of their respective owners and other company and product names mentioned herein may be trademarks of their respective companies.

Apple, the Apple logo and App store are trademarks of Apple Inc., registered in the U.S. and other countries. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

©2017 Google LLC. All rights reserved. Android, Google, Google Play, and the Google logo are registered trademarks of Google LLC.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc., and any use of such marks by Razer is under license.

The "Qi" symbol is a trademark of the Wireless Power Consortium.

Razer Inc. ("Razer") may have copyright, trademarks, trade secrets, patents, patent applications, or other intellectual property rights (whether registered or unregistered) concerning the product in this guide. Furnishing of this guide does not give you a license to any such

copyright, trademark, patent or other intellectual property right. The Razer Wireless Charger (the "Product") may differ from pictures whether on packaging or otherwise. Razer assumes no responsibility for such differences or for any errors that may appear. Information contained herein is subject to change without notice.

LIMITED PRODUCT WARRANTY
For the latest and current terms of the Limited Product Warranty, please visit razer.com/warranty.

LIMITATION OF LIABILITY
Razer shall in no event be liable for any lost profits, loss of information or data, special, incidental, indirect, punitive or consequential or incidental damages, arising in any way out of distribution of, sale of, resale of, use of, or inability to use the Product. In no event shall Razer's liability exceed the retail purchase price of the Product.

GENERAL
These terms shall be governed by and construed under the laws of the jurisdiction in which the Product was purchased. If any term herein is held to be invalid or unenforceable shall be given no effect and deemed to be excluded without invalidating any of the remaining terms. Razer reserves the right to amend any term at any time without notice.