





GAMING HEADSET
MODEL: RZ04-0540

WIRELESS DONGLE
MODEL: RC30-0540

USER MANUAL

WHAT'S INSIDE


- GAMING HEADSET(RZ04-0540)



- A. Adjustable padded headband
- B. Breathable memory foam ear cushions
- C. Volume control knob
- D. Mic mute toggle
- E. Power button
- F. Status indicator
- G. USB Type C port
- H. Microphone port
- I. SmartSwitch button
 - 2.4Ghz Mode
 - Bluetooth® Mode
- J. Game/Chat balance wheel*
- K. Hybrid Anti-Noise Cancellation (ANC) button*

**Customizable using Razer apps*

- Wireless Dongle (RC30-0540)




L. USB Type C port


M. LED indicator

N. Headset mode switch

- Detachable Mic



- Type A to Type C cable



- USB-C to 3.5mm TRRS analog converter cable



- Important Product Information Guide

WHAT'S NEEDED

PRODUCT REQUIREMENTS

- Xbox Series X|S
- Devices with Bluetooth audio capability or USB Type A port

RAZER SYNAPSE REQUIREMENTS


- Windows 10 64-bit (or higher)
- Internet connection for app installation

RAZER AUDIO APP REQUIREMENTS

- iOS 12 / Android 8.1 Oreo (or higher)
- Internet connection for app installation

LET'S GET YOU COVERED

*Your product's serial
number can be found here.*




Register your product and score exclusive benefits

razerid.razer.com/warranty


GETTING STARTED

CHARGE YOUR HEADSET

1




2



Charging Status	Status Indicator
Full	Static Green
High	Blinking Green
Mid	Blinking Yellow
Low	Blinking Red

i For best results, connect your GAMING HEADSET(RZ04-0540) directly to your computer's USB port using the provided cable.


POWER YOUR HEADSET ON/OFF




i Keep your headset powered on when connecting to other devices.

CONNECT TO YOUR DEVICE

WIRED MODE (USB)




WIRED MODE (3.5mm)




2.4GHz to XBOX


To an Xbox console via the Wireless Dongle

Set wireless dongle to **XBOX**.




Plug the wireless dongle into your Xbox console






Press and hold the Headset Power button. Wait until the status indicator briefly becomes static green, indicating that the headset is connected to the Wireless Dongle.





2.4GHZ MODE TO OTHER DEVICES

Set wireless dongle to **USB**.




Plug the wireless dongle into your device



i Customize the LED indicator to show the headset's connection status, battery status (default) or low battery warning using Razer Synapse.

Set Up For PC

Make sure to set the GAMING HEADSET(RZ04-0540) as your PC's default input and output device.



Personalize your PC experience

Use the Razer Synapse app to customize your headset's EQ, enable audio enhancements, and fine-tune other advanced features. Install Razer Synapse when prompted, or download the installer from razer.com/synapse


Activate THX® Spatial Audio*

Unleash the full potential of your GAMING HEADSET(RZ04-0540) by enabling 360° positional audio for a natural and lifelike experience through Razer Synapse.




**Only available on Windows 10 64-bit and above.*

BLUETOOTH® MODE




2



Search for the headset on your Bluetooth device


3




If pairing times out, follow the next procedure to reinitiate pairing.

Reactivating Bluetooth Pairing Mode


1



2




3



Search for the headset on your Bluetooth device

4



Set Up For Mobile


Download the Razer Audio App to customize your headset's EQ settings, auto shutoff feature, gaming mode, and much more — anytime, anywhere.



Razer Audio



OR




RZR.TO/AUDAPP
(For China only)


1. Download the mobile app on your mobile device.
2. Launch the app and follow the onscreen instructions.

i When using the Razer Audio app, ensure the headset is connected to your mobile device via Bluetooth.

PAIRED TO BOTH WIRELESS MODES



CYCLE THROUGH WIRELESS MODES




i To cycle through wireless modes, the headset must be connected to both 2.4GHz and Bluetooth.


USING YOUR GAMING HEADSET(RZ04-0540)

RAZER HYPERCLEAR FULL BAND MIC


PLUG IN THE MIC




PROPER MIC PLACEMENT




SET THE MIC TO MUTE/UNMUTE




CHANGE THE VOLUME




CHANGE THE GAME/CHAT BALANCE




SWITCH EQ PRESETS



UTILIZING THE HYBRID ANTI-NOISE CANCELLATION




BLUETOOTH CALL FUNCTION REFERENCE



Action	Call Status	Effect
Single press	Incoming call	Accept an incoming call
	Active call	End the current call
	Active primary call and incoming secondary call	Put a call on hold and accept an incoming call

	Active primary call and secondary call on hold	End call and swap to on-hold call
Double press	Incoming call	Reject incoming call
	Active primary call and incoming secondary call	Reject incoming secondary call
	Active primary call and secondary call on hold	Switch between calls

ADJUST FOR COMFORT



i Gently stretch the headbands before wearing the headset but do not overstretch it to avoid permanent damage.

Find out more about your gaming-grade headset at support.razer.com

SAFETY AND MAINTENANCE

SAFETY GUIDELINES

In order to achieve maximum safety while using your GAMING HEADSET(RZ04-0540), we suggest that you adopt the following guidelines:

Should you have trouble operating the device properly and troubleshooting does not work, unplug the device and contact the Razer hotline or go to support.razer.com for assistance.

Do not take apart the device (doing so will void your warranty) and do not attempt to operate it under abnormal current loads.

Keep the device away from liquid, humidity or moisture. Operate the device only within the specific temperature range of 0°C (32°F) to 40°C (104°F). Should the temperature exceed this range, unplug and/or switch off the device in order to let the temperature stabilize to an optimal level.

We recommend stretching the headset gently apart before placing them over your head to minimize headband stress. However, please avoid overstretching the headset beyond its technical limits.

The device isolates external ambient sounds even at low volumes, resulting in lowered awareness of your external surroundings. Please remove the device when engaging in any activities that requires active awareness of your surroundings.

Listening to excessively loud volumes over extended periods of time can damage your hearing. Furthermore, legislation of certain countries permits a maximum sound level of 86dB to affect your hearing for 8 hours a day. We therefore recommend that you reduce the volume to a comfortable level when listening for prolonged periods of time. Please, take good care of your hearing.

MAINTENANCE AND USE

The GAMING HEADSET(RZ04-0540) requires minimum maintenance to keep it in optimum condition. Once a month we recommend you clean it using a soft cloth or cotton swab to prevent dirt buildup. Do not use soap or harsh cleaning agents.

LEGALESE

COPYRIGHT AND INTELLECTUAL PROPERTY INFORMATION

©2025 Razer Inc. All rights reserved. Razer, the triple-headed snake logo, Razer logo, "For Gamers. By Gamers.", and "Razer Chroma" logo are trademarks or registered trademarks of Razer Inc. or affiliated companies in the United States and other countries. All other trademarks are the property of their respective owners.

Android, Google, Google Logo, Google Play, and the Google Play logo are trademarks of Google LLC. Apple, the Apple logo, and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.

Copyright © 2003-2023 by Bluetooth SIG, Inc. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc.

Windows and the Windows logo are trademarks or registered trademarks of the Microsoft group of companies.

Razer Inc. ("Razer") may have copyright, trademarks, trade secrets, patents, patent applications, or other intellectual property rights (whether registered or unregistered) concerning the product in this guide. Furnishing of this guide does not give you a license to any such copyright, trademark, patent, or other intellectual property right. The GAMING HEADSET(RZ04-0540) (the "Product") may differ from pictures whether on packaging or otherwise. Razer assumes no responsibility for such differences or for any errors that may appear. Information contained herein is subject to change without notice.

LIMITED PRODUCT WARRANTY

For the latest and current terms of the Limited Product Warranty, please visit [razer.com/warranty](https://www.razer.com/warranty).

LIMITATION OF LIABILITY

Razer shall in no event be liable for any lost profits, loss of information or data, special, incidental, indirect, punitive or consequential or incidental damages, arising in any way out of distribution of, sale of, resale of, use of, or inability to use the Product. In no event shall Razer's liability exceed the retail purchase price of the Product.

GENERAL

These terms shall be governed by and construed under the laws of the jurisdiction in which the Product was purchased. If any term herein is held to be invalid or unenforceable, then such term (in so far as it is invalid or unenforceable) shall be given no effect and deemed to be excluded without invalidating any of the remaining terms. Razer reserves the right to amend any term at any time without notice.

REGULATORY AND COMPLIANCE INFORMATION



STATEMENT OF COMPLIANCE WITH EU DIRECTIVE

Razer (Europe) GmbH, declares that this Razer marketing name (Gaming Headset: GAMING HEADSET(RZ04-0540), Wireless Dongle: RC30-0540) is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU & 2015/863/EU.

[GAMING HEADSET]

Bluetooth (For EU)

Operating Frequency: 2402 - 2480Mhz
Modulation: GFSK, $\pi/4$ -DQPSK, 8-DPSK
RF Output power: < 15.16 dBm (e.i.r.p.)
Transfer rate: 1 Mbps, 2 Mbps, 3 Mbps

Bluetooth LE (For EU)

Operating Frequency: 2402 - 2480Mhz
Modulation: GFSK
RF Output power: < 15.17 dBm (e.i.r.p.)
Transfer rate: 1 Mbps, 2 Mbps


2.4GHz SRD (For EU)

Operating Frequency: 2402 - 2480Mhz
Modulation: GFSK
RF Output power: < 14.10 dBm (e.i.r.p.)
Transfer rate: 1 Mbps, 2 Mbps, 4 Mbps

[WIRELESS DONGLE]

2.4GHz SRD (For EU)

Operating Frequency: 2402 - 2480Mhz
Modulation: GFSK
RF Output power: < 14.17 dBm (e.i.r.p.)
Transfer rate: 1 Mbps, 2 Mbps, 4 Mbps



The power delivered by the charger shall be between min 2.5 Watts required by the radio equipment, and max 15 Watts in order to achieve the maximum charging speed.

FCC COMPLIANCE STATEMENTS

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off

and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help. For more information, refer to the online help system on razer.com.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. This device has also been tested against this SAR limit.

ISED COMPLIANCE STATEMENTS

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device.

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- 1) L'appareil ne doit pas produire de brouillage;
- 2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Le dispositif rencontre l'exemption des limites courantes d'évaluation dans de RSS 102 et la conformité à l'exposition de RSS-102 rf, utilisateurs peut obtenir l'information canadienne sur l'exposition et la conformité de rf.

BATTERY WARNING

The equipment contains a Li-ion rechargeable battery. In general, the life expectancy of such batteries is dependent upon usage. If you suspect that the Li-ion rechargeable battery inside the equipment may be drained (has a low charge), try charging it. Caution: Do not open, mutilate, or expose to conducting materials (metal), moisture, liquid, fire, or heat. Doing so may cause batteries to leak or explode, resulting in personal injury. Do not leave the rechargeable battery discharged or unused for extended periods. Battery life varies with usage.


BATTERY INFO

Risk of fire or explosion or defeat the safeguard of equipment if the battery is replaced by an incorrect

type. Replace only with the same or equivalent type. Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion. High or low extreme temperatures or low air pressure at high altitude that the battery can be subjected to during use, storage or transportation. Leaving the battery in an extremely high temperature and/or low air pressure surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.



This equipment is for home use, and has acquired electromagnetic conformity registration, so it can be used not only in residential areas, but also other areas.



This product complies with Appliance Efficiency Program